
Sainsbury's Argos



Stone Effect Firepit

Assembly Instructions - Please keep for future reference

9653898



Important! Read the user instructions carefully before use. Save them for future reference.

If you need help or have damaged or missing parts, call the Customer Helpline: 03456 400800. Please visit the website www.argos.co.uk for more information.

Instructions for use

Please follow the instructions, to avoid some potential damage.

IMPORTANT:

Read this manual carefully before assembling and using.

For outdoor use only.

Not for commercial use.

Keep this manual for future reference.

Safety Instructions

Improper assemble, installation, adjustment, alteration, service or maintenance can cause injury or property damage.

Do not store or use petrol or other flammable vapor or liquids in the vicinity. Be careful, accessible parts may be very hot. Keep away from young children and pets.

Use your fire-pit at least 3 feet away from any wall or surface.

Do not move the fire pit when in operation


Do not move the fire pit during use after until the temperature has cooled down

Do not use spirit or petrol for igniting or re-igniting! Only use firelighters in accordance with EN 1860-3!


Notice!

- Build a pyramid from small pieces of wood.
- Put the dry lighter in the pyramid.
- Connect the dry lighter.
- When the small pieces of wood are well burned, you can add somewhat larger pieces of wood.
- Fill the fire bowl as much as possible so that you can use the spark p rotection grille without problems.
- To put out the fire, use sand or let it burn out. Do not use water as this can damage the item.
- Do not inhale the smoke or allow it to get into your eyes.
- The metal surface can be slightly discolored through use.

Explosion view



Part list



No barbecue, just a heating function



Carbon Monoxide Hazard



CARBON MONOXIDE HAZARD

Danger of carbon monoxide poisoning - NEVER light this product or let it smoulder or cool down in confined spaces.

If you need help or have damaged or missing parts, call the Customer Helpline: 03456 400800.