# **DOOR GASKET**



#### **GENERAL METHOD TO REPLACE GASKET**



**Step 1**Pull gasket out from the

corner.



**Step 2**Install a new gasket, starting from the corner.




### Step 3

Make sure base of gasket is pressed into trough completely.



### Step 4

Make sure gasket is properly aligned with edges of trough.



## Step 5

After closing the door, make sure gasket is well attached to door.

Note	

# **HANDLE**

# B<u>US</u>H



GENERAL METHOD TO REPLACE THE HANDLE



Step 1
Unscrew handles with Hex wrench.



Step 2
Lift up the handle. Take away the handle.



Step 3
Replace the handle with new one.



Step 4
Tighten the handle screws.

Note			

# **HINGE AND DOOR**

## BUSH





6×300 Slotted Screwdriver



6×300 Cross-head Screwdriver



8mm Inner Hexagon Spanner



GENERAL METHOD TO DISASSEMBLE THE DOOR AND **HINGE** THE METHOD IS SUITABLE FOR FRIDGE DOOR AND

FREEZER DOOR.



Step 1 Unscrew hinge cover.



**Step 2**Remove the cover.



**Step 3**Disconnect the terminals.



**Step 4**Unscrew 3 bolts and remove the top hinge.





Step 5

Remove the door.



#### Step 6

Tilt cabinet.



#### Step 7

Unscrew 4 bolts and remove bottom hinge.




**PROCEDURE 2** 

REPLACE THE DOOR OR HINGE WITH NEW ONE.
REVERSE PROCEDURE 1 ABOVE TO REINSTALL IT, AND PAY
ATTENTION TO THE KEY POINTS BELOW.



When installing door onto hinge, please check the alignment between door-stopper and hinge.





**Tip 2**Make sure gasket is attached well.



**Tip 3**Make sure gaps between doors are even.

Note		

# INTERNAL ACCESSORIES

B<u>US</u>H



### Drawer or crisper

Pull out and lift up to take it out.



#### **Shelves**

Lift up the inner side and pull out.



#### **Balconies**

Repeatedly alternate pushing left and right ends to remove balconies.





## Tip

When install the new balconies, make sure the balconies are pushed into proper final position.

Note	
	***************************************
	***************************************