



Spare Part Service Manual
Undercounter Retro Freezer
MEUCFR55BLK MEUCFRWHT
BD-130RA



General method to replace gasket

Step 1

Pull gasket out from the corner



Step 2

Install a new gasket, starting from the corner.






General method to replace gasket

Step 3
Make sure base of gasket is pressed into trough completely.

Step 4
Make sure gasket is properly aligned with edges of trough.



Step 5
After closing the door, make sure gasket is well attached to door.





General method to replace drawer

Step 1

Pull out and take the drawers out.

Step 2

Install a new drawer along the slots.





General method to replace door hinge

Step 1

Unscrew the screws on the hinge.

Step 2

Replace with new hinge, fix the screws.





General method to replace handle

Step 1

Unscrew the screws on the handle, remove the old handle.



BUSH

General method to replace handle

Step 2

Put the handle into the two fixed screws, match the two holes on the handle.



Step 3

Install screws at the bottom of handle and fasten tightly.

