

Spare Part Service Manual
Table Top Beverage Chiller
TTCHILL0
SC-46

Step 1
Pull gasket out from the corner

Step 2 Install a new gasket, starting from the corner.

### General method to replace gasket







#### General method to replace gasket

Step 3
Make sure base of gasket is pressed into trough completely.

Step 4
Make sure gasket is properly aligned with edges of trough.



Step 5
After closing the door,
make sure gasket is well
attached to door.



Step 1
Pull out and take the shelf out.

Step 2 Install a new shelf along the slots.

### General method to replace shelf





Step 1
Pull out hinge cover.

Step 2
Unscrew the hinge screws, then replace a new hinge directly if need.


### General method to replace door hinge






#### General method to replace the door and hinge

Step 3 Hold the door up with both hands, pull out the door and put it aside.







#### Step 5

Door assemble: align the bottom hole of the door with the shaft of the lower hinge, then install the door.

Step 6 Install the top hinge.

### General method to replace the door and hinge





# Step 7 Ensure the door is installed flat, it can be adjusted if not flat, then fix the screws of top hinge.

Step 8
Everything is perfect,put
on the hinge cover,door
replace finish.

#### General method to replace the door and hinge



