




**I-BEAM**

# CLEVERSPA® HOT TUB QUICK SETUP GUIDE

## WHAT'S IN THE BOX:

- Hot Tub
- Top Cover
- Protective Ground sheet
- Filter Cartridge
- Filter Cover
- Inflation Hose
- Repair Patches
- Drainage Plug
- Locking Keys
- Air Outlet Cap
- Inflation Valve Cap
- LED Lighting Kit (*selected models*)



**Please check all parts are present in your box before first use.  
To order new or missing parts please visit: [clevercompany.com](http://clevercompany.com)**

## IMPORTANT INFORMATION!

**For all safety & chemical advice we recommend that you read the full instruction manual first before setting up your hot tub.**

## CLEVERSPA® HOT TUB SETUP


- Lay groundsheet (A) on a flat, even surface, clear of sharp objects.  
**TIP: Set up out of direct sunlight with access to an IP66 rated outdoor socket. Do not use an extension lead.**
- Fully uncoil the lead & plug, located under pump & heating system.
- Screw Inflation Hose (D) on to Air Outlet (J).
- Push Inflation Hose (D) into Inflation Valve (K).
- Plug into mains & switch on. (Do not unscrew inner valve).
- Press air jets on control panel to start inflation (Light will appear).
- Once inflated, press air jets on control panel to stop inflation.  
**TIP: Do not over inflate. You should be able to push your hand approximately 4-5cm into the top rim using moderate force.**



- Screw Filter Cartridge (B) onto Filter Connector (N), followed by Filter Protector Cover (C) onto Filter Cartridge (B). **TIP: Clean filters after every use. Use filter cleaner to prolong the life of your filters**
- Before filling with fresh tap water, please consider the below:
  - Where supplied with LED Lights, fit before filling (see FIG 1).
  - Where supplied with CleverLink® App, locate strongest WiFi signal first**IMPORTANT! Whenever you fill your hot tub with fresh clean water, you will need to perform a Chlorine 'Shock Treatment', to sanitise the water, destroying any bacteria.**
- Setting temperature.** Press SET TEMP/LOCK on control panel, then Temp Up or Temp Down to desired temperature. Press SET TEMP/LOCK again to confirm.
- Clip Top Cover on (E). **TIP: In order to keep your running costs to a minimum, don't forget to purchase your EVA Flooring, Inflatable Cover Support and Thermal Cover.**



SCAN ME FOR  
FILTER CLEANING TIPS



## LED LIGHTING SETUP (Selected Models Only)

### INITIAL SETUP

1. Assemble LED Lighting Kit.
2. Remove plastic tape from the battery compartment on the remote.
3. Turn lights on with the power button.





FIG 1 - HOW TO FIT LED LIGHTS CORRECTLY



**FIT LIGHTS LOOSELY - HOT TUB WILL EXPAND WHEN FILLED!**  
Correct installation is extremely important.  
Failure to follow instructions carefully may result in failure.

## CLEVERLINK® APP SETUP (Selected Models Only)

1. Search CleverLink® on App Store/Play Store and download app.
2. Once CleverLink® is installed on your device, tap the icon to launch.
3. Setup an account, following all the relevant steps.

### PAIRING YOUR CLEVERSPA®

4. Ensure your device is set to the same 2.4GHz wireless network as the CleverSpa® hot tub you are connecting to.

**IMPORTANT! You need a strong WIFI signal to connect.**



5. Select the control panel version that your hot tub is fitted with.
6. Input the 'Network Name' and 'Security Password' for your wireless network. This can usually be found on your wireless router.
7. Review the tip about hot tub placement and press 'NEXT'.
8. Hold the CleverLink® Pairing button on control panel, (wait for beep) then tick the confirmation box on-screen and tap, **Pair your CleverSpa®**.
9. CleverLink® will now try to establish a connection between your device and your CleverSpa® hot tub. This can take up to 60 seconds to complete. **(DO NOT leave the setup screen)**.
10. Once the pairing process is complete you should see a **'Green Tick'**. Click "finish" to finalise the process. If you see the **'Red Tick'** "Pairing Failed" on screen, try completing the pairing process again. Be sure to check your wireless network settings are correct and that your device and hot tub are both in range and connected to a 2.4Ghz network.
11. Once you see the green tick, activate a function on the hot tub control panel such as the air jets. This will sync the control panel and app. Setup is now complete.



SCAN ME FOR  
CLEVERLINK® SETUP



**FOR BEST SIGNAL QUALITY WE RECOMMEND  
THE USE OF A 2.4GHz WIFI RANGE EXTENDER**

## IMPORTANT INFORMATION

### HARDWATER/LIMESCALE

If you live in an area with hard water, you may experience limescale build up and residue in your CleverSpa® pump & heating system which could significantly reduce the lifespan of some internal components, stopping the hot tub from working.

In order to reduce the effects of limescale build up please check the water hardness in your area. If you are affected please ensure that CleverSpa® Descaler is used weekly to prevent scale formation and build up.

### AIR JETS

Air jets will stop automatically after 20 minutes of continuous use, to avoid internal pump overheating. They can be started again after 10 minutes (indicated by beep). Air jets can be stopped or started again at any time during their 20 minute cycle.



### Contact Us:

General Enquiries, Returns, Spare Parts, Accessories,  
Repairs & Chemical Advice

**+44 (0) 151 318 6163 or visit: [clevercompany.com](http://clevercompany.com)**

### UK Address:

Clever Company Ltd. Oldgate St. Michael's Industrial Estate,  
Widnes, Cheshire, WA8 8TL.

### European Address:

Clever Company Ltd. Radarweg 29, 1043 NX Amsterdam, Netherlands.