


TOTAL[®] Control

URC-2910




TV

Quick & Easy Set Up (Direct code set up)

Your **TOTAL CONTROL TV** universal remote requires 2 new AAA alkaline batteries.

1

Bennet TV
(example)



Page 6 - 11

lex	0032	Beko	0370	0488	0037	0606
cent	0037	Bennett	0556	0037		
ec	0012	Beon	0037	0418	0002	
miral	0087 0093 0363 0418	Best	0337	0370	0421	
lyson	0305 0213 0264		0037	0370	0374	
	0068 0217 0216 0032					


2



3



4



Keypad



TV : Television / LCD / Plasma / Projector
/ Rear Projector.....6 - 11



POWER (On/OFF) - Red LED


Low Batterie


The TOTAL CONTROL will indicate low batterie level by lighting up 5 times after a key press.


In TV : AV / C/P


Direct code set up

Example: To set up the TOTAL CONTROL for your television:

- 1  Find the code for your device in the Code list (page 6 - 11). Codes are listed by device type and brand name. The most popular code is listed first. **Make sure your device is switched on (not on standby).**

2.  **Press and hold down the SETUP key until the red LED underneath the POWER key blinks twice (the red LED will blink once then twice).**

3.  Enter your **(four-digit device code)** using the number keys. The red LED will blink twice.

4.  Now, aim the TOTAL CONTROL at your device and **press POWER. If your device switches off, the TOTAL CONTROL is ready to operate your device.**


- Some codes are quite similar. If your device does not respond or is not functioning properly with one of the codes, try another code listed under your brand.
- Some TV's do not switch on pressing the POWER key. Please try pressing a "number" key or the "TV-text off" key to switch your TV back on.
- If your device does NOT switch off? Please repeat steps 1 - 4 trying the next code listed for your brand.


Search Method


If your device does NOT respond to the TOTAL CONTROL after you have tried all the codes listed for your brand, try searching for your code. The Search Method allows you to find the code for your device by scanning through all the codes contained in the memory of the TOTAL CONTROL. The Search Method may also work if your brand is not listed at all.


Example: To search for your TV code:


- 1 Switch your television on (not on standby) and aim your TOTAL CONTROL at your TV.

- 2  **Press and hold down the SETUP key until** the red LED underneath the POWER key blinks twice (the red LED will blink once then twice).

- 3  Press **9 9 1**. The red LED will blink twice.

- 4  Next, press **POWER**.

- 5  Aim the TOTAL CONTROL at your Television. Now press **CH+** over and over, until your Television switches off (everytime you press the CH+ key the TOTAL CONTROL will send out a POWER signal from the next code contained in the memory). You may have to press this key many times (up to 150 times) so please be patient.

- 6  As soon as your television Switches off, press the **SETUP key** to store the code.

- Some TV's do not switch on pressing the POWER key. Please try pressing a "number" key or the "TV-text off" key to switch your TV back on.

TV

888 0264
 A.R. Systems 0037 0556
 Accent 0037 0556
 Accusound 0860
 Acentic 0556
 Acer 1339 3630
 Acoustic Solutions 1667 1727 1545 2279 1585
 1523 1865 1037 2676 1163
 Adcom 0625
 Addison 0653 0108
 Admiral 0093 0264
 Advent 1613
 AEA 0037 0556
 AEG 0606 1556 1324 1037 1667
 1163 2239 2197 2241
 Aftron 2037
 Agashi 0264
 Agfaphoto 2719 2239
 Agora 2279 1585 2676 0037
 Aiko 0037 0556 1681 0880 0264
 Aim 0037 0556 0208 0706 0698
 0634 0606 0499
 1833 0556
 Airis 0701 1916 1505
 Aiwa 1326 1413 0208 0556 0037
 Akai 0714 0706 0698 0715 0812
 0264 0178 0606 1037 1248
 1727 1308 1865 2676 3067
 1163 1523 1652
 Akashi 0860
 Akiba 0037 0556
 Akira 2241 0037
 Akito 0037 0556
 Akura 1770 2289 1687 0264 0714
 1709 1667 1037 0037 1645
 0556 0668 1585 1983 1363
 2239 2059 3268
 Alba 1037 1585 0714 0037 0556
 3067 2676 0668 0587 0443
 2007 1865 1163 3587 3005
 2561 2214
 Alios 2168
 Allstar 0037 0556
 Allure 2714
 Amitech 1849
 Amstrad 0037 0264 0556 1037 1324
 Anam 0037 0556 0650
 Anam National 0037 0650 0556
 Andersson 2676 1163 1667 1585 0037
 Anglo 0264
 Anitech 0264 0037 0556
 Ansonic 0037 2799 0556 0668
 AOC 1588 0625 2214 0093 0108
 0178
 Aolinpike 0264
 AquaVision 1606
 Arçelik 0714 2125 0037 1308
 arctic 1652
 Ardem 0714 0037 0633 0556 0715
 Arena 0037
 Aristona 0556 0037
 ART 1037
 Art Mito 1585 1667
 Asberg 0037 0556
 Astra 0037 0556
 Asuka 0264
 Asus 3340
 ATD 0698 0706
 Atec 1606
 Atlantic 0037 0556
 Audiosonic 0037 0820 0556 1308 1681
 0714 0715 2059 0264 1983
 Audiotion 0264
 Audioworld 0698 0706
 Autovox 2676
 AWA 2241 0037 0698 0178 0556
 0606 0108 0264 1681
 Axxon 0714
 Azuki 2239
 Baier 1324 2165 2239
 Baihe 0264
 Baile 0661
 Baird 0208 0606 2212
 Bang & Olufsen 0620
 BaoHuaShi 0264
 Base 0698

Basic Line 1667 1163 0037 0668 0556
 1037
 Bauer 2197 0698 0706 0264
 Bauhn 2461
 Baur 0037 0512 0195 0556 1505
 BBK 1523 1645
 Beaumark 0178
 Beijing 0208 0226 0264 0661 0812
 Beko 0714 0715 0037 2279 0556
 1308 0606 0808 1652 2125
 0698 0706 2241 2032 2714
 2868 3296 1667
 Belson
 Belstar 1037
 Bennett 0556 0037
 BenQ 1523 2214
 Bensten 1326 1413
 Beon 0037 0556
 Beond 1833
 Berthen 0668 0556
 Bestar 0037 0556
 Bestwell 1326
 Bexa 2493
 Black Diamond 0820 1037 0556 1163 0587
 Blaupunkt 0195 1709 2106 0170 2426
 Blauren 2275
 Blusens 1849 2241 2481 2714
 Blue Media 1606
 Blue Sky 0037 1324 1037 0556 0668
 0714 1709 1667 0715 0625
 1652 0808 1363 1916
 BlueDiamond 2106 2426
 Bluetech 2561 2799
 Blush 1709
 Boca 1652
 bogo 2561
 Boman 1324
 Bork 1363
 BPL 0037 0556 0208 1208
 Brand Unknown 2197
 Brandt 0625 1585 0560
 Brimax 1709
 Brinkmann 0037 0556 0668
 Brionvega 0037 0556
 Brother 0264
 Bush 1037 2032 3005 3589 1326
 2214 0037 1585 2125 1667
 0714 0668 1556 1916 1652
 0698 0264 0208 0706 0556
 1248 1682 0587 1687 1308
 2053 1983 2212 2241 2719
 2239 1865 2676 1720 2673
 0443 2007 2059 2223
 Buxtron 0698
 Cameron 1523 0556
 Camper 0037 0556
 Capsonic 0264
 Carad 0037 0556 0668 1037
 Carena 0037 0556
 Carrefour 0037 0556
 Carver 0170
 Cascade 0037 0556
 Casio 0037 0556
 CAT 1682
 Cathay 0037 1727 0556
 CCE 0037 0556
 Celcus 1163 1667 1585 0037 1037
 2676
 Celestial 0820
 cello 1770 2246 2673
 Centrex 0698
 Centrum 1037
 Centurion 0037 0556
 Changcheng 0264 0661
 Changfeng 0264
 Changhong 3434 0820 0264 0508
 Chimei 1666 1852 1505
 CHL 3067
 Chunfeng 0264
 Chung Hsin 0108 0653
 Cinex 2197 1556
 Clarity 1720
 Clarivox 0037 0556
 Clatronic 0037 0714 0264 0556 0606
 1324 1163
 Clayton 1037
 CMX 2799 2868 3296 3067
 Condor 0037 0556 0264
 Conia 1687 1645 2032 0820 1523
 2410
 Conrac 0808
 Conrad 0037 0556
 Conrowa 0264 0698
 Contec 0264 0037 0556

Continental				Enzer	0860
Edison	2241			Erisson	1682
Cosmel	0037 0556			Erres	0037 0556
CPTEC	0625 1363			Essentials	2486
Crown	0712 0037 0556 0714 0606			Etron	0037 0556 0820
	0715 0208 0653 1037 1652			Eurofeel	0264
	0668			EuroLine	0037
Curtis Mathes	0093			Euroman	0264 0037 0556
CWR-Tech	1324			Europa	0037 0556
Cyberpix	1667			Europhon	0037 0556
Cytronix	1298			Evesham	1248 1667 1606
D.Boss	0037			Evotel	2561 3589
Daewoo	0634 0661 2125 1849 2246			Excel	0037 0556
	0499 0037 0556 0178 0170			Excello	1037
	0880 0108 0698 0714 0706			Exquisit	0037 0556
	2275 2037			F&U	2676
Dansai	0037 0556 0264 0208			Fagor	0037 0556
Dantax	1652 1916 0714 0606 1037			Family Life	0037 0556
	0715			Feiyan	0264
Datron	0625			Ferguson	0037 0625 1037 0560 2393
Datsura	0208				0556 0653 0108 0443 2007
Dawa	0037 0556				1916 2053 2275 1865 2426
Daytek	0698 0706 0264				3005 3455 3067 2106 2676
Daytron	0037 0556			Fidelity	0512 0037 0556 0264
Dayu	0661			Finlandia	0208
de Graaf	0208			Finlux	0037 0556 0714 1585 1667
DECA	0860 1326				0715 1556 0606 0808 1248
Decca	0037 0556				2676 1163
Deitron	0037 0556			Firstline	0037 0556 0668 0714 0208
Denko	0264				1037 0808 1363 1163 1308
Denver	0037 1324 0556 0606 1849			Fisher	0208
	0587 2239 1709 2139 2197			Flint	0037 0556 0264
	3067 1770 2481			Foehn & Hirsch	0178 1840
Desmet	0037 0556			Force	1667
Dew	1770			Formenti	0037 0556
DGM	2239 2059			Fortress	0093
DGTEC	2714			Fraba	0037 0556
Diamant	0037 0556			Freesat	1636
Diamond	0264 0698 0860 0820 1681			Friac	0037 0556 0499
	0706			Frontech	0264
DiBoss	0037 0556			Fujicom	1709
Dick Smith				Fujimaro	1687 1645
Electronics	1326 2241 3296			Fujimaru	1687
Digatron	0037 0556			Fujitsu	0037 0556
Digihome	1667 2676 1163			Fujitsu Siemens	1666 1298 1248 1163 0808
Digiline	0037 0556 0668			Funai	1817 0264 1394 1037 1666
DigiLogic	0037 0556				1595 0668 1505 0714 1652
Digimate	2239			Furi	0264
Digital Device	1606			Furichi	0860
Digitek	1709			Futronic	0264 0860 0698
Digitex	0820			Future	0037 0556
Digitor	0037 0556 0888 0698 0706			Gaba	1037 0037
Digitrex	3194 3067			Galaxi	0037 0556
DigiX	0880			Galaxis	0037 0556
DiK	0037 0556			Garza	0556
Dikom	2799 2561			GE	0178 0560 0625
diVision	2197			GEC	0037 0556
Dixi	0037 0556			Genesis	0037 0556
DL	0037 0587 1363 1326			Genexxa	0037 0556
DMTECH	1849 2001 2223			Gericom	1606 1298 0880 0808
Domeos	0668 0037 1037			G-Hanz	1681 1363
DSE	0698 0888 1556 0820 0706			Godrej	1585
	1682 2241 2032 1326 3296			GoGen	2676 1163 1667 0037 1037
Dual	0037 0556 1667 1037 2032			Gold	1833 1770
	2241 1324 1163 1585 2676			Goldfunk	0668
	0714 2197			GoldStar	0037 0178 0556 0606 0714
Dunlop	2799				0715
Durabrand	0037 0178 0556 1652 1037			Goodmans	0634 1248 2393 1667 0037
	0714				1585 1687 1037 1983 0499
Dux	0037 0556				0556 1916 0714 0668 1163
D-Vision	0037 2197 0556				0264 0560 0661 0880 1308
Dynatron	0037 0556				0587 1727 1645 1682 1720
Dyon	2799 2241				2053 2223 2676 1523 1709
E.S.C.	0037 0556				0808
e:max	1324 0606			Gorenje	1585 1667 2676
Easy Living	1248 1709 1613 1308 2005			Gradiente	0653 0170 0037 0556
	2007 1556 1666			Graetz	0714 0037 0556 1163
Easy Touch	2059			Gran Prix	2197
Ecco	0706 0698			Granada	0037 0556 0208 0226 0108
ECE	0037 0556				0560
ECG	2197 3067 2239 2165 2125			Grandin	0037 1652 0556 0714 0715
	0037 1037				0668 1037 0880
Elbe	0037 0556			Grundig	0195 0508 1223 0037 2059
Electron	1585				2676 3296 0443 3067 1687
Elekta	0037 0556 0264				0556 0587 0706 1037 2007
Elfunk	1208 1037				1916 1308 0178 1667 2053
ELG	0037 0556				2239 2125 1324 2561 1645
Elin	0037 0556				1523
Elite	0037 0556			Grunkel	1163
Elonex	1776			GVA	1326 2037
Elta	0264			H&B	0808 2001
Emerson	0714 0178 0037 0556 0668			Haaz	0706
e-motion	1709 2426 2106				

Haier	0698 0264 0706 2212 1588 2214 2241 0037 0508 0587	JTV	0860
Haiyan	0264	Jubilee	0556
Halifax	0264	Juhua	0264
Hallmark	0178	JVC	0653 1818 2676 1163 2118 0606 1653 0508 0093 0650 2714
Hammerstein	0264	Kaige	0264
Hankook	0178	Kaisui	0037 0556
Hanns.G	1613	Kambrook	0264
Hannspree	2786 1613 1776 2214	Kangli	0264 0661
Hanseatic	0037 0556 0499 0661 0634 0714 0808 0625 2001	Kangyi	0264
Hantarex	2197 0037 0556	Karcher	0037 0556 0264 0714 1556 0606 2125 1308
Hantor	0037 0556	Kathrein	0556 0037 0880
Harwood	0037 0556	Kendo	0037 2676 0556 0512 1585 1037 1667 1163
Hauppauge	0037 0556	Kenmark	2393
Havermy	0093	Kennex	1037
HB	1324	Kenstar	2331
HCM	0037 0556 0264	Keymat	1326 1413
Hedzon	0556 0037	Kingsbrook	1037
Hicon	1298	Kioto	0556 0706
Highline	0264 0037 0556	Kiton	0556 0037 0668
Hikona	1983	KLL	0037
Hinari	0208 0037 0556 0443 2007 0264	Kneissel	0037 0499 0556
Hisawa	0714	Kobra	1298
Hisense	1363 2341 2371 0208 0556 2037 0508 0698 0860 1208	Kolster	0653 0108 0037 0556
Hitachi	1576 0578 2207 0108 0744 1585 1037 1687 1667 0634 0178 2214 2676 1163 0499 2005 0508 2007 0443 0037 0556 2279	Kongque	0264
Hitachi Fujian	0108 0037 0556 0860 0499	Konka	0037 0556 0714 0587 0606
Höher	3434 0714 1556 1163	Korpel	0037 0556
Home		Kosmos	0037 0556
Electronics	0606	Kotron	0264
Hongmei	0093 0264	Kuaille	0264
Hongyan	0264	Kunlun	0208 0226 0264 0661
Hornlyphon	0037 0556	Küppersbusch	2676 0037 1667
Huangshan	0264	Kyoshu	0264
Huanyu	0264	L&S Electronic	0714
Huaqiang	0264	Lavis	1037 0037
Huari	0264	Lecson	0037 0556
Hugoson	1666	Lenco	2799 0037 0556 0587 1037 1983
Humax	1295	Level	2373
Hypson	0037 0264 0556 0714 0715 1037 0668	Levis Austria	0037 0556
Hyundai	0037 0860 2139 0556 0698 1326 1681 1770 0264 0888 1037 1606 0706 1556 2676 1163	Leyco	0037 0264 0556
Iberia	0037 0556	LG	1423 1840 2182 1305 0178 0037 1842 0714 0556 0606 0108 0715 1681 0698 0706 1859 1667
ICE	0264 0037 0556	Liesenkötter	0037 0556
Ict	0037 0556	Lifetec	0037 0668 1037 2001 0512 0556 0714 0264 1248
Ideal	1556	Linetech	2676 1163
ISonic	1613	Linsar	1585 2676 2279 1667 1163 1037
i-Joy	2868 2165	Local	
Ikasu	2246	Calcutta TV	0208 1208
Imperial	0037 0508 0556 2197	Local	
Imperial Crown	0264 0661	Chennai TV	1413 0264
Indiana	0037 0556	Local Delhi TV	0508
Ingelen	0714	Lodos	1037 1667
Ingo Devices	2239	Loewe	0512 0633 1884 0556 0698 1865 0706 2486 3432
Inno Hit	1037 0037 0556 1163 1585	Logik	0264 1585 0880 1037 1687 1645 2241 0037 3005
Innova	0037	Logix	0668 2426
Innovation	0037 0556	Longjiang	0264
Innowert	1298	Lowry	3268
Inotech	0820	Luma	0037 0556
Inspira	1324 1556	Lumatron	0037 0556 0264
Interactive	0037 0556 0512	Lumenio	0037
Interbuy	0037 0264 0512 0556	Lux May	0037 0556
Interfunk	0037 0556 0512	Luxor	0208 1037 2676 1667 1163 0178
Internal	0037 0556 0499	LXI	0178
Intervision	0037 0264 0556	Madison	0037 0556
Irradio	0037 0556 0714	Magnavox	0037 0556 0706
IRT	0698	Magnum	0714 0037 0556 0715 1556 2799
Isis	2676 1163 1037	Majestic	0264
Isukai	0037 0556	Mandor	0037 0556 0264
ITS	0037 0264 0556	Manhattan	0037 0556 0668 1037
ITT	2125 0208 1523 2675 2676 1163	Maqma	1298 1709 1606
ITT Nokia	0208 0606	Marantz	0037 0556
ITV	0037 0264 0556	Mark	0037 0556 0714 0715
Jay-tech	3067 2239	Marks & Spencer	2246 1770 2673
JGC	1709	Mascom	1556 0556 0037 2125 1585 2197
Jialicai	0264	Master's	0499 0037
Jinfeng	0208 0226	Masuda	0264 0037 0556
Jinque	0264	Matsui	0443 1163 1037 2007 1916 2486 0037 0195 0208 0556 0714 1666 0880 2279 1667 2676 0744
Jinta	0264		
Jinxing	0264 0698 0037 0556		
JMB	0037 0499 0634 0556 0443 2007 2676		
Jocel	0712		

Matsushita	0650	Nu-Tec	0698 0820 0037 0556 0706
Matsuiama	0587		0264 2481
Maxam	0264	O.K.Line	1037 1324 1556
Maxdorf	0698 0706 0264	Oceanic	0208 2001
Maxess	2493	Odeon	0264
Maxim	1556	Odys	2799 2719 2239 2165 2241
Mediator	0037 0556	OK.	3434 2676 3432 3047
Medion	0668 0714 0808 1037 0037	Okano	0037 0556 0264
	0556 0512 2719 2239 0698	OKI	1037 2125 1667 3434 1585
	0706 1248 0880 1916 1556		2676 1308 2947 1163
	1667 2001 2279 1849 2676	Ölevia	1588
	1163	Omega	0264
Megatron	0178	Omni	0698 0706
MEI	1037 0037 0556	Onei	1667
Meile	0264	Onida	0653
Meletronic	0037 0512 0556 0634 0195	Onimax	0714
	0661 0714 1652	Onix	0698 0706
	0178 1037 0650	Onn	1709 1556 1667 2125 0556
Memorex	1983		1770 2279
Memory	0037 0698 0264 0556 0706	Onyx	1709 1770
Mercury	0037	Opera	0037 1308 0556 0714 1585
Mermaid	0625	Optimus	0650
Metronic	1533 0447 1163 0195 0037	Optonica	0093
Metz	0556 0587 0668 1037	Orava	1037 1667 1163
	0178 0037 0556	Orbit	0037 0556
MGA	0037 0556 0668 1037 0808	Orbitech	2422
Micromaxx	1324 2001 0714	Orion	0037 2007 2032 2005 0443
	1614		0714 2108 0556 0264 1916
Microspot	0808		0880 2001 1037 2676
Microstar	0820 0698 0860 0706 0264	Orline	0037 0556
MicroTEK	1667 1163 0744 1585 0037	Ormond	0668 1037 0037 0556
Mikomi	0037 0556	Osaki	0264 0037 0556
Minato	1248 0195 0108	Osio	0037 0556
Minerva		Osume	0037 0556
Ministry of		OTIC	1687 1645 1983
Sound	1667	Otto Versand	1505 0037 0512 0093 0556
Minoka	0037 0556		0195 0226
Mirai	1666 1852 1651 1505	Pacific	0037 1916 0556 0714 1037
Mitsai	1556		0443 1324 2007
Mitsubishi	0108 0093 0512 0178 0037	Palladium	0037 0714 1505 0556
	0650 0556 0208 1037	Palsonic	0698 2461 2481 0264 0037
Mivar	0609		0706 0556 1326 1681 2410
Moree	0037		1585
Morgan's	0037 0556	Panache	0264 0037 0556
Moserbaer	1667 1585	Panama	0650 1636 1650 0226 0037
Motorola	0093	Panasonic	0556 0208 0508 0108
mp man	3296		0037 0556
MT	0512	Panavision	0208 0226 0264 0508 0698
MTlogic	0714 1308	Panda	0706
Mudan	0208 0226 0264	Papouw	0037 0556
Multitec	0037 0556 0668 1037 1556	PEAQ	2676
Multitech	0037 0556 0264	Penney	0178
Murphy	2005 1849 0443 2673 2246	Perdio	0037 0556
	2007 2676 1667 1163	Perfekt	0037 0556
	0037 0556	Philco	0037 0556 0178
Musikland	1687 1983 1645	Philips	0037 0556 1744 1506 0605
Mx Onda	0178		2768 1887 2800 0178 0108
MyCom	0556 0037		1505 2214 3614
Myriad	0178	Phocus	1308 0714 1652
NAD	0037 0606 0556	Phoenix	0037 0556
Naiko	0037 0556	Phonola	0037 0556
Nakimura	0264	Pilot	0556 0037 0712 0706
Nanbao	0264	Pioneer	1260 1457 0170 0679 0037
Nansheng	0226		0556 0512
NAT	0226 0208 0508	Plantron	0037 0556 0264
National	0170 2461 0587 0178 0037	Playsonic	0714 0037 0715 1652
NEC	0653 0264 0556 0508 0499	Polar	0037
	0661	Polaroid	1523 3589 2676 1720 1645
Neckermann	0037 0556 1505 0512		1687 2125
NEI	0037 0556 1037	Powerpoint	0037 0556 0698 0706 1770
NEO	1324	Premier	0264
Neon	2246 1770 2673	President	0860
Netsat	0037 0556	Prima	0264
Neufunk	0037 0556 0714	PrimeView	1606
Nevir	2799 2676	Princess	0698 1326
New Tech	0037 0556	Prinston	1037
Newave	0178 0093	Pro Vision	0499 0037 0556 1037 0714
Nikai	1163		1324
Nikkai	0037 0556 0264 1667	Profilo	1556
Nikkei	0714 2197	Profitronic	0037 0556
Nikko	0178	ProLine	1613 1727 0634 1037 1545
Nokia	0606 0208		0625 0037 0556 2223 2676
Nordmende	0560 2331 2001 0195 0037	Prosonic	2393
	0556 1248 0714 1413 0443		0037 0556 1865 0880 0668
	2007 1585 1667 1163 1308		0714 2139 2676 2001 1324
	0625		1770 2106 1709 1163 0606
Normerel	0037 0556		2197 2100 2125 1545 1849
Nortek	0668		0715 1523 2481 2279
Novak	0037 0556	Protech	0037 0556 0264 0668 1037
Novatronc	0037 0556	Proton	0178
Novex	1523	Proview	1687 1645
Novita	1585	PVision	2001
NPG	3434	Pye	0037 0556

Q.Bell	2561	Shencai	0264
Q.Media	2799	Sheng Chia	0093
Qingdao	0208 0226 0264	Shenyang	0264
QONIX	2165	Shinelco	2241
Quadro	1326 0556 0037 1667 1163	Shintoshi	0037 0556
Quartek	1606	Shivaki	0037 0556 0443 2007 0178
Quasar	0650	Show	0698 0264 0706 0037
Quelle	0037 1505 0512 0668 0556 0195 0264 1037	Siemens	0037 0195 0556
Radialva	0037 0556	Siera	0037 0556 0587
Radiola	0037 0556	Silva	0037 0556
Radiomarelli	0037 0556	Silva Schneider	1556 2125 2197
Radionette	0714	Silver	0037 0556 0715
RadioShack	0037 0556 0178	SilverCrest	1037 0037 0556 2676
Radiotone	0037 0556 0668 0264 1037	Singer	0698 1556 0037 0556
RCA	0625 0093 0178 0560 0618 0679	Sinotec	2012 0606 0698
Realistic	0178	Sinudyne	1324 1505 0037 0556 0606
Recor	0037 0556	Sky	0037 0880 1614 0178 0556 1613 1606 1709 0661
Rectiligne	0037 0556	Skyworth	0037 0556 0264 0698
Red	2032	Sliding	0880 1324
Red Star	0037 1556 0556	SLX	0668
Reflex	0037 0556 1037 0668	Soemtron	1298
Relisys	1298 1585 1645	Sogo	3067
Reoc	0714 0634 2197	Solavox	0037 0556
Revox	0037 0808 0556	Soniko	0037 0556
Rex	0264	Soniq	2493 2474 3168 1298 3005
RFT	0264 0037 0556	Sonitron	0208
Ricoh	0037 0556	Sonneclair	0037 0556
Rinex	0698 0264 0706	Sonoko	0037 0556 0264
R-Line	0037 0556	Sonolor	0208 1505
Roadstar	1037 0715 0264 0037 0556 0714 0668 1916 1326	Sontec	0037 0556
Rodex	0037 0556	Sontech	1983
Rolsen	0037 0556 2037 2001	Sony	1825 2778 1505 1651 0650 1625
Rowa	0037 0264 0698 0712 0706 0587 0556	Sound & Vision	0037 0556
Royal	0606	Soundesign	0178
Rukopir	0556 0037	Soundwave	0037 2246 0556 0715
Saba	2676 0625 0560 0650 0714 1588	SOVOS	2239
Saga	2197	Sowa	0226 0178
Sagem	0618	Soyo	1709
Saisho	0634 0264	Standard	0037 2032 0556 1682 1037 1709 2799
Saivod	0037 0556 1163 1556 0668 0712 1037	Starion	1037
Salora	0208 1556 2125 2197 2001 2676	Starlite	0037 0556 0264
Sampo	0093 0178 0650	Stern	0264
Samsung	0812 2051 2137 0618 0587 1458 1619 0556 1249 1312 1630 1235 0037 0178 0264 0208 0226	Stevision	1556
Sandström	2197 3432	Strato	0037 0556 0264
Sanjian	0264	Strong	1163 1667 1037 0037 0556
Sansui	0037 1682 1709 0706 0556 1413 0888 1523 0698 0264 0714 1248 1681 1556	Sungoo	1248 2037
Sanyo	0208 1208 0508 0037 0556 0170 0264 1037 1667 1163 1585 2279 2676 2461	Sunic Line	0037 0556
Sanyuan	0093	Sunkai	0037 0556
Save	0037 0556	Sunny	0037
SBR	0037 0556	Sunstar	0037 0556 0264
Schaub Lorenz	2241 0714 2197 0606 1324 1363 2100 1667 2125 1308 2676 1163 3268	Sunstech	2001 2676 2241
Schneider	0037 2676 0556 1585 0668 1037 0714 1916 1324	Sunwood	0037 0556
Schönotech	1037	Supersonic	0208 0556 0698 0264 0037
Scotch	0178	SuperTech	0037 0556
Scott	0178 1523 1983	Supervision	0698 0264
Sears	0178	Supra	0178 0037
Seaway	0634	Supratech	2208 3067
Seeltech	3268	SVA	0587 0698 0264 0208 0706
Seelver	0556 1037 0037	Svasa	0698 0208 0706 0264
SEG	1037 2239 1709 0037 0264 1163 0668 3434 0556 0634 1667 2125 2165 2673 2719 1523 1585	Swedx	1606
SEI	1505 0037 0556	Sweex	2474
Sei-Sinudyne	1505 0037 0556	Swisstec	1709 1614 1606 1613 0880 1776 1849 2059
Seitech	1324	Synco	0093 0178
Selecline	3296	Sysline	0037 0556
Seleco	0264	T+A	0447
Sencor	0714 3067 2239 2197	Tacico	0178
Sense	1849	Tandy	0093
Serie Dorada	0178	Targa	0618
Serino	0093 1193	Tashiko	0650 0170
Shancha	0264	Tatung	1720 0037 1248 1556 0556 1324 1916
Shanghai	0208 0226 0264	Taurus	2197
Sharp	0093 1659 1193 2676 2214 0650 0653 1163	TCL	3047 2675 0587 1916 0625 0698 0706
		TCM	0714 0808 2001 1308
		Teac	0698 1645 2168 0037 3005 0264 0712 1037 0556 0512 0706 0668 0178 0170 0714 1667 1363 0587 1770 1709 2032 2241 2714 1983
		TEC	0037 0556
		Tech Line	1585 0037 0556 0668 1163 0650
		Technics	2106 2032 2426 1865 2168 2059 1849 2212 1667 1983 1585 2125 2197 3005 2676 3067
		Technika	0037 0556 2422
		TechniSat	0714 1652
		Technisnon	

Techno	1585 1037	Vestel	0037 1037 2676 1163 1585
Technol Ace	0698 0264 0634		1667 0668 0556
Technosonic	0625 2032 0499 0556 1324	Vexa	0037 0556
	0880 0037 1326 0714	Victor	0653 0650
Techvision	1709 2032	Videocon	0508 2331 3296 1508
Techwood	1163 1037 1667 2279	VideoSystem	0037 0556
Tecnimagen	0556	Vidtech	0178
Teco	1523 0093 0178 0264 0653	ViewSonic	1588
Tedelex	0698 0706 0606 0037 0208	Vision	0037 0264 0556 2481
	0587 0556 1709 1681 0264	VisionPlus	2426 2106
	1682	Vistron	1363
Tek	0820 0037 0698	Visual	
TELE System	2125 1585 1037 0037 2241	Innovations	2106
Telecor	0037 0556	Vivax	1326 1308 0037 1709
Telefunken	0625 1667 2799 2239 0808	Vivo	2032 2100 2410
	0560 0587 0698 0712 0820	Vortec	0037 0556
	1681 0706 0037 0556 0714	Voxson	0178 0037 0556 2197
	1556 1585 1588 1163 2676	VSA	1413
Telefusion	0037 0556	VU	2037
Telegazi	0037 0264 0556	Walker	1667 2279 2676 1163 0037
Telemeister	0037 0556		1037 1585
Telesonic	0037 0556	Waltham	0037 0556 0668 1037 0443
Telestar	0037 0556 1849		2007
Teletech	0037 0556 0668 1037	Wards	0178
Televue	0037 0556	Warumaia	0661 0634
Tempest	0037 0556 0264	Watson	0037 1037 1248 0556 0668
Tennessee	0037 0556	Wega	0037 0556
Tensai	0037 0556 0715 1037	Wegavox	0037 0556
Tesco	2426	Welltech	0714 1652
Tesla	1037 0037 0668 0714 1652	Weltblick	0037 0556
	0715 0556	Weltstar	1037
Tevion	1248 1298 1645 0556 1556	Weston	0037 0556
	1667 0808 0668 2032 2100	Westwood	1585
	1037 1687 2241 2373 3268	Wharfedale	1983 1613 1667 1324 0860
	1585 0714 0037 2125 2197		0698 2212 0706 0037 1037
	1849 2947		1681 0714 0556 1556
Thes		White	
Thomson	0560 0625 3047 1588 0037	Westinghouse	0037 0556
	0556 2675	Wilson	0556
Thorn	0108 0037 1505 0499 0512	Windsor	0668 1037
	0556	Windy Sam	0556
Thorn-Ferguson	0108 0499	Wintel	0714
Tiane	0093	World-of-Vision	0880 1298 1606
TMK	0178	XDome	0508
Tobo	0264	Xenius	0634 0661
Tokai	0037 0556 0668 1037	Xiahua	0264 0698
Tokaido	1037	Xiangyang	0264
Tongguang	0264	Xihu	0264
Tongtel	0587	Xinghai	0264
Top Show	0698 0264 0706	Xiron	1983 1037
Topline	1037 0668	XLogic	0698 0860 0706
Toshiba	1508 0508 2676 2732 0093	Xomax	1770
	0714 3242 0264 1667 0618	Xoro	1324
	0650 1457 0195 1916 0037	Xrypton	0037 0556
	1556 1037 1163 1652	Yakumo	1613
Tosumi	1770	Yamaha	0650 1576
Toyoda	0264	Yamishi	0037 0556
Trakton	0264	Yapshe	0650
TRANS-		Yokan	0037 0556
continents	0668 1037 0556 0037	Yoko	0037 0264 0556
Transonic	0037 0698 0556 0712 0587	YU-MA-TU	0037
	0512 0264 1363 1326 0706	Yusmart	1613
Triad	0037 0556	Zenith	0178
Trio	1687 1248 1645	Zepto	1585
Tristar	0264	Zonda	0698
Triumph	0556 0037		
TVE	2239		
TVTEXT 95	0556		
Uher	0037 0556		
Ultravox	0037 0556		
UMC	1606 2426 1709 1614 1849		
	2059 2106 2165 2168		
Unic Line	0037 0556		
Uniden	1585 1037 0037 1667 1163		
	2676		
United	0714 1983 0037 0715 2799		
	0556 2481 1916 3242 1037		
	0587 2241 1849 1652 3296		
	3434 1770 0508 1523 2125		
	1163		
Unitek	1709		
Unitron	1681		
Universal	0714 0037 0556		
Universum	0037 0808 1037 1163 0264		
	0668 0195 1667 0512 0556		
	1505 0170 0618		
Univox	0037 0556		
V7 Videoseven	0178 0880 1666 0618 1651		
	1505		
Vanguard	0037 0556		
VD-Tech	2799 3067		
Venturer	1727 1545 1865 3005		
Venus	1326		



UNIVERSAL ELECTRONICS INC./TOTAL CONTROL warrants to the original purchaser that this product will be free from defects in materials and workmanship under normal and correct use for a period of one (1) year from the date of original purchase. This product will be replaced free of charge if it has been proven to be defective within the one (1) year warranty period. This warranty does not cover cartons, carrying cases, batteries, broken or marred cabinets or any other item used in connection with the product. Any further obligation than listed above is excluded. Please notice that we need your purchase receipt so that we may establish your eligibility for service.

If you have bought this product for purposes which are not related to your trade, business or profession, please remind that you may have legal rights under your national legislation governing the sale of consumer goods. This guarantee does not affect those rights.



TOTAL CONTROL
P.O. Box 3332
7500 DH, Enschede
The Netherlands



URC-2910
709736
RDN 2201113

