BUSH_4-DEV_RDN-1150415_URC-3541 Manual_gedrukt 15-04-15 10:57 Pagina 1

BUSH

Instruction Manual

URC3541





POWER (ON/OFF)

AV funtion

Electronic Program Guide

As a safety feature you need to press "REC" twice to start recording.

Batteries



Your Bush universal remote requires 2 new AAA alkaline batteries (included).

Low Battery Indication (Red LED)
The Bush Universal Remote will indicate low battery level by lighting up 5 times after a key press.

Keypad

TV — TV : Television / LED / LCD / Plasma / Projector. 7

VCR — VCR: Video Cassette Recorder / TV/VCR Combi/ DVD/VCR Combi / PVR. 14

DVD — DVD: DVD Player / DVD-R / DVD Home Cinema / DVD Combi / DVD/HDD. 21

SAT — SAT: Satellite Receiver / Set-Top-Box / DVB-S / DVB-T / Freeview / SAT/HDD. 15


CBL: Cable Converter / Set-Top-Box / DVB-C. 20

VAC: Video Accessory like Media Centres / AV Accessories / AV Selectors. 20

Direct Code Set

1 **Example: To set up the Bush Universal Remote for your television:**

Find the code for your device in the Code list (page 7 - 23).
Codes are listed by device type and brand name.
The most popular code is listed first.
Make sure your device is switched on (not on standby).




2 TV Press the **TV key** on the Bush Universal Remote for the device you wish to Set-Up. (example TV).

3 

Press and hold the red & blue keys for 3 seconds. The red LED will light up twice.

4 4 GHI 0 3 DEF 7 PQRS Enter your **(four-digit device code)** using the number keys. The red LED will blink twice.

4 Now, aim the Bush Universal Remote at your device and **press POWER.**
If your device switches off, the Bush Universal Remote is ready to operate your device.



- Some codes are quite similar. If your device does not respond or is not functioning properly with one of the codes, try another code listed under your brand.
- Some TV's do not switch on pressing the POWER key. Please try pressing a "number" key or the "TV-text off" key to switch your TV back on.
- If your device does NOT switch off? Please repeat steps 1 - 5 trying the next code listed for your brand.

Search Method

If your device does NOT respond to the Bush Universal Remote after you have tried all the codes listed for your brand, try searching for your code.
The Search Method allows you to find the code for your device by scanning through all the codes contained in the memory of the Bush Universal Remote. The Search Method may also work if your brand is not listed at all.

Example: To search for your TV code:

1 Switch your television on (not on standby) and aim your Bush Universal Remote at your TV.

2 

Press the **TV key** on your Bush Universal Remote.

3 

Press and hold the red & blue keys for 3 seconds. The red LED will light up twice.

4 
Aim the IRC Bush Universal Remote at your device. Press and hold the "POWER KEY until your device switches OFF (this may take up to 8 minutes). Release the "POWER key" as soon as your device switches OFF.

- To search for the code for another device follow the instructions above only press the appropriate device key instead of TV during step 2.
- Some TV's do not switch on pressing the POWER key. Please try pressing a "number" key or the "TV-text off" key to switch your TV back on.

Volume Lock

This feature allows you to lock the volume from a certain device (e.g. TV Volume) for any other mode. So, for example you may want to lock the volume (VOL+/- and MUTE) to TV mode so it can be controlled from all other device modes.

Example: TV volume control in every mode;

1 

Press **TV**.

2 

Press and hold the red & blue keys for 3 seconds. The red LED will light up twice.

3 

Press **9 9 3.**

4 

Press the **Volume (+)** key and the red LED will blink twice.

Result: within every mode, whenever you press the VOL+/- or MUTE keys, this will be send out from TV mode.

To cancel the „Volume Lock" for per mode (e.g. DVD mode):

1 

Press and hold the red & blue keys for 3 seconds. The red LED will light up twice.

2 

Press **9 9 3.**

3 

Press **DVD.**

4 

Press **the Volume (-)** key and the red LED will blink four times.

Result: DVD mode will control its own VOL+/- and MUTE again.

TV

A.R. Systems	0037 0556
Accent	0009 0037 0556
Acentic	0556
Acer	1339
Acoustic Solutions	1667 1727 1149 1523 1585 1865 1037 2676 1163
Adcom	0625
Admiral	0093 0264
Advent	1613
AEA	0037 0556
AEG	0606 1556 1372 1037 1149 1163 1667 1585 2239 2197 2241
Agashi	0264
Agfaphoto	2239
Agora	1585 2676 0037
Aiko	0009 0037 0556 0371 0035 1681 0880 0361 0191 0264
Aim	0037 0556 0753 0208 0706 0698 0634 0606 0499
Airis	0556
Aiwa	1916 1505
Akai	0361 0208 2197 0371 0037 0191 0035 0009 0753 0714 0706 0698 0715 0556 0548 0480 0264 0178 0606 1037 0473 0648 0812 1248 1727 1308 1865 2676 1163 1523 1652 3981
Akashi	0009
Akiba	0037 0556
Akira	2241 0753 0037
Akito	0037 0556
Akura	1770 0714 1709 1667 1037 0037 0556 1645 0668 1585 0009 0264 1983 1363 2239 2059
Alba	1037 1585 0714 0037 2676 0668 0556 0009 0371 0587 0443 2007 1865 1163 3587 3005 3790 2214 1667 3810
Alios	2168
Alkos	0035
Allstar	0037 0556
All-Tel	0865
Amitech	1849
Amstrad	0009 1149 1667 1163 0264 0371 0037 0556 1037 0648 1372
Anam	0037 0556 0009 0650
Anam National	0037 0556 0650
Andersson	2676 1163 1149 1585 0037
Anglo	0009 0264
Anitech	0009 0264 0037 0556
Ansonic	1582 0037 0556 0009 0668 0292
AOC	3790 0625 1588 2111 2214
Apollo	0473
AquaVision	1606
Arc en Ciel	0109
Arçelik	0714 2125 0037 1308
arctic	1652
Ardem	0486 0714 0633 0037 0556 0715
Arena	0037
Aristona	0556 0037
ART	1037
Art Mito	1585 1667
Asberg	0037 0556
Asora	0009
Astra	0037 0556
Asuka	0264
ATD	0698 0706
Atec	1606
Atlantic	0037 3981 0556
Atori	0009
Auchan	3981
Audiosonic	0009 0037 0556 0109 1308 1681 0714 0715 2059 0264 0486 1983
Audioton	0486 0264
Audioworld	0698 0706
Autovox	1163 1585 2676 1667
AWA	2241 0037 0698 0178 0009 0011 0556 0606 0108 0264 1681
Axxent	0009
Azuki	2239
Baier	1372 2239
Baird	0109 0343 0208 0606 3573
Bang & Olufsen	0620
Base	0780 0698
Basic Line	1149 1163 0037 0668 0556 0009 1037
Bauer	0009 2197 0698 0706 0264
Bauhn	2461
Baur	0009 0535 0195 0512 0037 0556 0191 0361 1505
BBK	1523 1645
Beaumark	0178
Beko	0714 0035 0486 0715 0037 0556 1308 0606 0808 1652 2125
Belson	0698 0706 2241 2032 1667
Belstar	1037
Bennett	0556 0037
BenQ	1562 1523 2214
Bensten	1413
Beon	0037 0556
Berthen	0668 0556
Bestar	0037 0556
Bexa	2493
Black Diamond	1037 0556 1163 0753 0587
Black Strip	0035
Blaupunkt	1709 2106 0195 0191 0535 0170 3810
Blu:sens	1849 2241
Blue Media	1606
Blue Sky	0037 1372 1037 0714 1709 1149 0668 0715 0625 1652 0624 0556 0808 1363 1916
BlueDiamond	2106
Blush	1775 1709
Boca	1652
Boman	1372
Boots	0009
Bork	1363
BPL	0037 0556
Brandt	0625 0109 0287 0335 0343 0560 1882 2676 1585 1667
Brandt Electronique	0287 0335
Brimax	1709
Brinkmann	0037 0556 0668 0486
Brionvega	0037 0556
Brother	0264
Bruns	0486
BSR	0361
Bush	1037 2032 3589 2676 3005 2127 2214 1585 2125 3964 1149 0371 0714 1556 0037 0668 1916 1652 1667 0009 0264 0361 0208 0698 0706 0556 1248 1682 0587 1308 2053 1983 2241 2239 1865 1720 2673 3573 0443 2007 2059 3763 3790 3587 3719 3810 3981 3175 3340
Cameron	1523 0556
Camper	0037 0556 0486
Capsonic	0264
Carad	0610 0037 0556 0668 1037

Carena	0037 0556
Carrefour	0037 0556
Carver	0170
Cascade	0009 0037 0556
Casio	0037 0556
CAT	1682
Cathay	0037 1727 0556
CCE	0037 0556
Celcus	1163 1149 1667 1585 0037 1037 2676 3981
cello	1770 2673
Centrex	0780 0891 0698
Centrum	1037
Centurion	0037 0556
CGE	0074
Chimei	1666
Cimline	0009
Cinex	0648 1556
City	0009
Clarity	1720
Clarivox	0037 0556
Clatronic	0037 0371 0714 0264 0556 0009 0648 0606 1372 1163
Clayton	1037
Cobolt	0891
Concorde	0009
Condor	0037 0556 0009 0264
Conia	0754 1645 2032 1523
Conrac	0808
Conrad	0037 0556
Contec	0009 0011 0264 0037 0556
Continental Edison	0109 2241 0287
Cosmel	0009 0037 0556
CPTEC	0625 1363
Crosley	0074
Crown	0009 0712 0486 0037 0556 0714 0606 0715 0208 0653 1037 1652 0668
Curtis Mathes	0093
CWR-Tech	1372
Cyberpix	1667
Cytronix	1298
D.Boss	0037
Daewoo	0634 1849 2125 0661 0499 0624 0037 0556 0009 1137 0880 0865 0698 0714 0706 2037
Dansai	0037 0556 0264 0035 0009 0208
Dantax	1652 0486 0714 1916 0606 1037 0715
Datron	0625
Datsura	0208
Dawa	0009 0037 0556
Daytek	0698 0706 0264
Daytron	0009 0037 0556
de Graaf	0208 0548
DEC	0891
Decca	0037 0556 1137
Deitron	0037 0556
Denko	0264
Denver	0037 1372 0556 0606 1849 0587 2239 1709 2197 1770
Desmet	0037 0556 0009
Dew	1770
DGM	2239 2059
Diamant	0037 0556
Diamond	0264 0698 0009 0371 1681 0706
DiBoss	0037 0556
Dick Smith Electronics	2241
Digatron	0037 0556
Digihome	1149 3175 1667 3340 1163 2676
Digiline	0037 0556 0668
DigiLogic	0037 0556
Digimate	2239
DigiMax	0891
Digital Device	1606
Digitek	1709
Digitor	0037 0556 0888 0698 0706
Digivision	0361
DigiX	0880
DiK	0037 0556
Dikom	2676
diVision	2197
Dixi	0009 0037 0556
DL	0891 0780 0037 0587 0865 1363
DMTECH	1163 1849 2001
Domeos	0668 0037 1037
DSE	0698 0888 1556 0706 1682 2241 2032
DTS	0009
Dual	3719 0343 0037 0556 1137 1149 1037 2032 2241 1372 1163 1667 1585 2676 0714 2197
Durabrand	0037 0556 1652 1037 0714
Dux	0037 0556
D-Vision	0037 2197 2239 0556
DVX	0891
Dynatron	0037 0556
Dyon	2241
E.S.C.	0037 0556
e:max	1372 0606
Easy Living	1248 1709 1613 1308 2005 2007 1556 1666
Easy Touch	2059
Ecco	0706 0698
ECG	2197 2239 2125 0037 1037
Elbe	0610 0292 0037 0556 0191 0361
Electrion	1585
Elekta	0009 0037 0556 0264
Elfunk	1208 1037
ELG	0037 0556
Elin	0037 0556 0548 0361 0009
Elite	0037 0556
Elta	0009 0264
Emerson	0714 0178 0037 0556 0371 0361 0624 0486 0668
e-motion	0865 1709 2106
Enox.	2673
Enzer	0753
Erisson	1682
Erres	0037 0556
Essentials	2486
Etron	0037 0556 0009
Eurofeel	0264
EuroLine	0037
Euroman	0264 0037 0556
Europa	0037 0556
Europhon	0037 0556
Eurovision	1163 1149
Evesham	1248 1667 1606
Evotel	3589
Excel	0037 0556
Excello	1037
Exquisit	0037 0556
F&U	2676
Fenner	0009 1667 1163
Ferguson	0625 1882 0335 1037 0287 0109 0560 0343 2393 0037 0556 0035 0653 0108 0361 0548 0443 2007 1916 2053 1865 3005 2106 2676
Fidelity	0512 0037 0556 0371 0264 0361
Finlandia	0208 0548 0361 0287 0343
Finlux	3719 0037 0556 0714 1585 1667 0715 0480 1556 0473 0606 0808 1248 2676 1163 3175 3340
Firstline	0037 0556 0668 0714 0624 0009 0208 0361 1037 0808 1363 1163 1308
Fisher	0208 0361
Flint	0037 0556 0610 0264
Foehn & Hirsch	0178 1840
Force	1149

Formenti	0037 0556 0486
Fortress	0093
Fraba	0037 0556
Freesat	1636
Friac	0009 0037 0556 0499 0610
Frontech	0264 0009
Fuchsware	0780
Fujimaro	0865
Fujitsu	0009 0037 0556 0361
Fujitsu General	0009
Fujitsu Siemens	1666 1298 1248 1163 0808
Funai	1817 1394 1037 1666 0668 0264 1505 0714 1652 3719
Futronic	0264 0698
Future	0037 0556
Gaba	1037 0037
Galaxi	0037 0556 0361
Galaxis	0037 0556
Galeria	0009
Garza	0556
GBC	0009
GE	0343 0178 0560 0287 0109 0335 0625
GEC	0361 0037 0556
Geloso	0009
General	0109 0287
General Electric	0343 0287
General Technic	0009
Genesis	0009 0037 0556
Genexxa	0037 0556 0009
Gericom	0865 1606 1298 0880 0808
G-Hanz	1681 1363
Giant	0009
GoGen	2676 1163 1667 0037 1037 3175 1585
Gold	1770
Goldfunk	0668
GoldStar	0037 0009 0178 0556 0361 0109 0606 0714 0715
Goodmans	0634 1248 2393 1667 1585 1037 0624 0037 1983 0499 0556 1916 0714 0668 1163 0264 0009 0371 0343 0035 0480 0560 0335 0661 0880 1308 0587 1149 1727 1645 1682 1720 2053 2127 2676 1523 1709 0808 2214
Gorenje	1585 1667 2676
GP	0753
Gradiente	0653 0170 0037 0556
Graetz	0361 0371 0037 0556 1163 1585 1149 1667
Gran Prix	0648 2197
Granada	0037 0556 0226 0108 0208 0473 0335 0560 0343 0548
Grandin	0037 1652 0556 0009 0610 0714 0715 0668 1037 0865 0880 2125 2676
Grundig	0195 1223 1582 2059 2676 0443 0191 2127 0535 1037 0037 2007 0706 0556 0587 0009 1916 1308 0178 0343 1667 2053 2239 2125 1372 1645 1523
Grunkel	1163 1523
GVA	2037
H&B	0808 2001
Haaz	0706
Haier	0698 0264 0706 2214 3790 2241
Halifax	0264
Hammerstein	0264
Handic	2676
Hanns.G	1613
Hannspree	1613 2214
Hanseatic	0037 0556 0499 0361 0292 0634 0661 0009 0714 0808 0486 0625 2001
Hantarex	2197 0009 0037 0556 0865
Hantor	0037 0556
Harsper	0865
Harwood	0009 0037 0556
Hauppauge	0037 0556
HB	1372
HCM	0009 0037 0556 0264
Hedzon	0556 0037
Hema	0009
Hicon	1298
Hifivox	0109
Highline	0264 0037 0556
Hikona	1983
Hinari	0208 0037 0556 0009 0443 2007 0264
Hisawa	0610 0714
Hisense	2341 1363 0208 2037 0698 0891 0780
Hitachi	1576 2676 3175 2207 3340 1772 1585 0481 0578 0108 1149 0744 1037 1484 2127 1667 0634 0473 0343 2214 1163 0499 2005 2007 0480 0443 0037 0556 0109 0548 0178 1137 0361 3981 3719
Hitachi Fujian	0108 0037 0556 0499
Hitsu	0009 0610
Höher	0714 1556 0865 1163
Home Electronics	0606
Hornyphon	0037 0556
Hugoson	1666
Humax	1295 1539
Hyper	0009
Hypersonic	0361
Hypson	0037 0556 0714 0715 0264 1037 0668 0486
Hyundai	0698 1681 1770 0264 0888 1037 0865 1606 0706 1556 2676 1163
Iberia	0037 0556
ICE	0264 0037 0371 0009 0556
Ict	0037 1137 0556
Ideal	1556
IISonic	1613
Imperial	0037 0074 0508 0556 2197 0361
Indiana	0037 0556
Ingelen	0610 0714 0361
Ingersoll	0009
Ingo Devices	2239
Inno Hit	0009 1037 1667 1308 0037 0556 2676 1149 1163 1585
Innovation	0037 0556
Innowert	0865 1298
Inspira	1372 1556
Interactive	0037 0556 0512 0361 0109
Interbuy	0009 0037 0264 0512 0556
Interfunk	0037 0556 0512 0361 0109
Internal	0037 0556 0624 0499
Intervision	0037 0371 0486 0264 0009 0556
Irradio	0009 0037 0556 0371 0714
Isis	2676 1163 1037 3340
Isukai	0037 0556
ITS	0037 0371 0264 0009 0556
ITT	2125 0480 0361 0473 0548 0208 0610 1523 2676 1163 3175
ITT Nokia	0361 0548 0473 0480 0208 0606 0610
ITV	0037 0264 0556
Jay-tech	2239
JEC	0035
JGC	1709

BUSH_4-DEV_RDN-1150415_URC-3541 Manual_gedrukt 15-04-15 10:58 Pagina 1

JMB	0037 2676 0499 0634 0556 0443 2007 3810
Jocel	0712
Jubilee	0556
JVC	0653 1818 2676 1163 3175 3981 2118 3340 0606 0371 0093 0650 2005 3719
Kaisui	0037 0556 0009
Kambrook	0264
Kapsch	0361
Karcher	0037 0556 0610 0264 0714 1556 0606 2125 1308
Kathrein	0556 0037 0880
Kawa	0371
Kendo	2676 0037 0610 0556 0512 0648 1585 1037 0486 1149 1163 1137
Kenmark	2393
Kennex	1037
Keymat	1413
Kingsbrook	1037
Kiota	0371
Kiton	0556 0037 0668
Kneissel	0037 0610 0499 0556 0292
Kobra	1298
Kolster	0037 0556
Konichi	0009
Konka	0037 0556 0371 0714 0587 0754 0606
Korpel	0037 0556
Kosmos	0037 0556
Kotron	0264
Koyoda	0009
Küppersbusch	2676 0037 1667
Kyoshu	0264
L&S Electronic	0865 0714
LaSAT	0486
Lavis	1037 0037
Leader	0009
Lecson	0037 0556
Legend	0009
Lenco	0009 0037 0556 0587 1037 1983
Lenoir	0009
Levis Austria	0037 0556
Leyco	0264 0037 0556
LG	1840 2182 1423 1663 0178 0037 2741 1305 0714 1637 0606 0556 0715 1681 0698 0706 1859 1149
Liesenkötter	0037 0556
Lifetec	0037 0668 1037 1137 2001 0009 0512 0556 0714 0264 1248
Linetech	2676 1163
Linsar	1585 2676 1667 1163 1037 3719 3175 3981 3340
Lloyd's	0009
Lodos	1037 1149
Loewe	0512 0633 1884 0292 0556
Logik	0698 2486 3005 0706 1865 1037 0880 0009 0264 1585 1645 2241 0037 0011 0371
Logix	0668
Luma	0037 0556 0009
Lumatron	0037 0556 0361 0264
Lumenio	0037
Lux May	0037 0009 0556
Luxor	3175 0480 0361 0208 0548 0473 1037 2676 1667 1163
LXI	0178
Madison	0037 0556
Magnavox	0037 0556 0780 0753
Magnum	0648 0714 0037 0556 0715 1556
Mandor	0264
Manesth	0037 0556 0264 0035
Manhattan	0037 0556 0668 1037
Maqma	1298 1709 1606
Marantz	0037 0556
Mark	0037 0556 0009 0714 0715
Marks & Spencer	1770 2673
Mascom	1556 0556 0037 2125 1585 2197
Master's	0499 0037
Masuda	0371 0009 0264 0037 0556
Matsui	0443 1163 1037 2007 1916 2486 0037 0195 0556 0009 0011 0371 0035 0208 0191 0335 0714 1666 0880 1667 2676 0744
Matsushita	0650
Maxam	0264
Maxdorf	0698 0706 0264
Maxess	2493
Maxim	1556
MCE	0009
Mediator	0037 0556
Medion	0714 0808 0037 0668 0556 0512 2239 1137 0698 0706 1037 1248 0880 1916 1556 1149 2001 1667 1849 2676 1163 3175
Megas	0610
Megatron	0178
MEI	1037 0037 0556
Melectronic	0037 0512 0109 0343 0009 0480 0287 0556 0624 0634 0361 0191 0195 0661 0714 1652
Memorex	0009 0178 0650
Memory	1983
Memphis	0009
Mercury	0037 0009 0698 0264 0556 0706
Merritt	0548 0361
Metz	1533 0746 0447 1163 0195 0535 0191 0037 0556 0668 1037 1637
MGA	0178 0037 0556
Micromaxx	0037 0556 0668 1037 0808 1372 2001 0714
Microstar	0808
MicroTEK	0698 0706 0264
Mikomi	1149 1163 0744 1585 1667 0037
Minato	0037 0556
Minerva	1248 0535 0195 0191 0108
Ministry of Sound	1667
Minoka	0037 0556
Mirai	1666 1852 1651
Mitsai	1556
Mitsubishi	0108 0512 0093 0178 0037 0535 0556 0208 1037
Mivar	0609 0292
Monaco	0009
Moree	0037
Morgan's	0037 0556
Motorola	0093
MTC	0512 0361
MTlogic	0714 1308
Multitec	0037 0556 0486 0668 1037 1556
Multitech	0009 0486 0037 0556 0264
Murphy	2005 1849 0443 2673 2007 3175 2676 1667 1149 1163
Musikland	0037 0556
Mx Onda	1983 1645
MyCom	0178
Myryad	0556 0037
NAD	0178 0865 0361
Naiko	0037 0606 0556
Nakimura	0037 0556
NAT	0226
National	0226
NEC	0170 2461 0587 1775 0009 0037 0556 0011 0499 0653 0661
Neckermann	0037 0191 1505 0556 0512

BUSH_4-DEV_RDN-1150415_URC-3541 Manual_gedrukt 15-04-15 10:58 Pagina 1

NEI	0037 0556 0371 1037
NEO	0754 1372
Neon	1770 2673 0753
Neovia	0865
Netsat	0037 0556
Neufunk	0037 0009 0556 0610 0714
Nevir	2676 3719
New Tech	0037 0009 0556 0343
Nikkai	0037 0556 0264 0035 0009 1667
Nikkei	0714 2197 3790 1585 2676 1667
Nikko	0178
Nintaus	0891
Nogamatic	0109
Nokia	0361 0480 0548 0473 0208 0606 0610 0109
Nordmende	0560 0891 0109 0287 2001 0343 0195 0037 0556 0335 1248 0714 1413 0443 2007 1585 1667 1163 1308 1882 0625 1149 2676
Normerel	0037 0556
Nortek	0668
Novak	0037 0556
Novatronic	0037 0556
Novex	1523
Novita	1585
Nurnberg	0361
Nu-Tec	0698 0037 0556 0706 0264
O.K.Line	1037 1372 1556
Oceanic	0361 0208 0473 0548 0480 2001
Odeon	0264
Odys	2239 2241
OK.	3810 2676 2239 3981
Okano	0037 0556 0264 0009
OKI	1037 2125 1667 1585 2676 1308 1163
Ölevia	1588
Omega	0264
Omni	0780 0891 0698 0706
Onei	1667
Onimax	0714
Onix	0698 0706
Onn	1709 1556 1149 2125 0556 1667 1770
Onwa	0371
Onyx	1709 1770
Opera	0037 1308 0556 0714 1585
Optimus	0650
Optonica	0093
Orava	1037 1149 1163
Orbit	0037 0556
Orion	2007 3981 2005 2032 0037 0443 0714 2108 0556 0011 0009 0264 1916 0880 2001 1037 2676
Orline	0037 0556
Ormond	0668 1037 0037 0556
Osaki	0264 0037 0556
Osio	0037 0556
Osume	0037 0556
OTIC	1645 1983
Otto Versand	1505 0093 0512 0037 0556 0535 0195 0191 0361 0109 0226 0009 0343
Pacific	0037 1916 0556 1137 0714 1037 0443 1372 2007
Palladium	0037 0714 1137 0191 1505 0556
Palsonic	0698 2461 0264 0037 0706 0556 1681
Panache	1585
Panama	0009 0264 0037 0556
Panasonic	1636 0650 1650 0226 0361 0037 0556 0548 0108 3981 2676
Panavision	0037 0556
Papouw	0037 0556
Pathe Cinema	0292
Pathe Marconi	0109
Pausa	0009
PEAQ	3175 2676
Perdio	0037 0556
Perfekt	0037 0556
Philco	0074 0037 0556
Philips	0556 1744 1506 0037 0639 2015 0605 1887 2800 0343 0009 0361 2214
Phocus	1308 0714 1652
Phoenix	0037 0556 0486
Phonola	0037 0556
Pioneer	1260 0760 0011 1457 0170 0679 0037 0556 0343 0361 0109 0287 0486 0512
Pionier	0486
Plantron	0037 0556 0264 0009
Playsonic	0714 0037 0715 1652
Polar	0037
Polaroid	3589 1523 2676 3719 1667 1720 1645 3340 2125
Policom	0109 0361 0074 0535
Poppy	0009
Portland	0624
Powerpoint	0037 0556 0698 0706 1770
Pragma Digital	0808
Prandoni-Prince	0361
Premier	0009 0264 0891
Prima	0009 0264
Princess	0698
Prinston	1037
Prinz	0361
Pro Vision	0499 0037 0556 1037 0714 1372
Profex	0009 0361
Profi	0009
Profilo	1556
Profitronic	0037 0556
ProLine	0634 1613 1727 1037 0625 0037 0556 2676 2393 1163 1585 1667
Prosonic	0037 0556 1865 0371 0880 0668 0714 2676 2001 1372 1770 2106 1709 1163 0606 2197 2125 1849 0715 1523
Protech	0037 0556 0009 0264 0668 0486 1037
Proton	0178
Proview	1645
PVision	2001 2676
Pye	0037 0556
Pymi	0009
Qilive	3981
Quadro	0753 0556 0037 1149 1163 1667
Quartek	1606
Quasar	0650 0865 0009
Quelle	0037 1505 0011 0109 0512 0535 0191 0361 0074 0668 0556 0195 0264 1037 0009
Radialva	0109 0037 0556 0287
Radiola	0037 0556
Radiomarelli	0037 0556
Radionette	0714
RadioShack	0037 0556 0178
Radiotone	0009 0037 0556 0648 0668 0264 1037
Rank Arena	0753
RCA	0625 0093 0560 0335 0343 0753
Realistic	0178
Recor	0037 0556
Rectiligne	0037 0556
Red	2032
Red Star	0037 1556 0556
Rediffusion	0361 0548
Reflex	0037 0556 1037 0668
Relisys	0865 1298 1585 1645
Reoc	0714 0624 0634 2197
Revox	0037 0808 0556
Rex	0264

BUSH_4-DEV_RDN-1150415_URC-3541 Manual_gedrukt 15-04-15 10:58 Pagina 1

RFT	0292 0264 0037 0556 0486
Ricoh	0037 0556
Rinex	0698 0264 0706
R-Line	0037 0556
Roadstar	1037 0715 0009 0037 0556 0714 0668 0264 1916
Rolsen	0037 0556 2037 2001
Rowa	0264 0698 0712 0009 0706 0587 0037 0556
Royal	0606
Royal Lux	0335
Rukopir	0556 0037
Saba	0625 0109 0560 0343 0287 0361 0335 0548 0650 0714 1588 1882 2676 1585 3175
Saga	2197
Sagem	0610 0618
Saisho	0634 0009 0011 0264
Saivod	0037 0556 1163 1556 0668 0712 1037 1667 1149
Salora	0361 0548 0208 0480 1556 2125 2197 2001 2676
Salsa	0335
Samsung	2051 0812 0618 0587 2094 0556 1249 1312 2137 1630 1235 0009 0037 1584 0264 0178
Sandstrøm	2197
Sansui	0037 1682 0556 0706 0371 0888 0753 0698 0264 0714 1248 1681 1556
Santon	0009
Sanyo	0208 1208 0292 0011 0009 0037 0556 0486 0170 1037 1667 1149 1163 1585 2676 2461
Save	0037 0556
SBR	0037 0556
Schaub Lorenz	0548 2241 0714 0361 2197 0606 0486 1372 1363 1667 2125 1308 2676 1163 1585 1149 3981
Schneider	1137 2676 0037 0556 1585 0343 0371 0361 0668 1037 0648 0714 0624 1916 1372
Schöntech	1037
Scott	0178 1523 1983
Sears	0178
Seaway	0634
Seelver	0556 1037 0037
SEG	1037 2239 0037 1709 1163 0556 0668 0009 0264 0634 0624 1149 2125 2673 1523 1585
SEI	1505 0037 0556
Sei-Sinudyne	1505 0037 0556
Seitech	1372
Selecline	3981
Seleco	0371 0264
Sencor	0714 2239 2197
Sencora	0009
Sense	1849
Sentra	0035 0009
Serie Dorada	0178
Serino	0610 0093
Sharp	1659 2676 0093 1193 2214 1163 3175 3719 3340
Shinelco	2241
Shintoshi	0037 0556
Shivaki	0037 0556 0443 2007 0178
Show	0009 0698 0264 0706 0037
Siemens	0191 0535 0195 0037 0556 0361
Siera	0037 0556 0587
Silva	0037 0556 0361 0648
Silva Schneider	0753 1556 0648 2125 2197
Silver	0361 0715
SilverCrest	1037 0037 0556 2676
Singer	0009 0698 1556 0037 0556 0335
Sinotec	0606 0698
Sinudyne	1372 2676 1667 0361 1505 0037 0556 0606
Sky Media	0037 0880 0178 0556 1613 1606 1775 1709 0661 0865
Skysonic	0753
Sliding	0865 0880 1372
SLX	0668
Soemtron	0865 1298
Solavox	0361 0548 0037 0556
Sonic	0753
Soniko	0037 0556
Soniq	2493 1298 3005
Sonitron	0208
Sonneclair	0037 0556
Sonoko	0037 0556 0009 0264
Sonolor	0208 1505 0548 0361
Sontec	0037 0556 0009
Sontech	1983
Sony	1825 2778 1505 1651 1751 1551 1625 0011
Sound & Vision	0037 0556
Soundesign	0178
Soundwave	0037 0556 2673 0715
SOVOS	2239
Soyo	1709
Ssangyong	0009
Staksonic	0009
Standard	0037 2032 0556 1682 1037 0009 1709
Starion	1037
Starlite	0009 0037 0556 0264
Stern	0264
Stevison	1556
Strato	0037 0556 0264 0009
Strong	1163 1149 1037 0037 0556
Sungoo	1248 2037
Sunic Line	0037 0556
Sunkai	0610 0037 0556 0865 1523
Sunny	0037
Sunstar	0371 0037 0556 0009 0264
Sunstech	2001 2676 2241
Sunwood	0037 0556 0009
Supersonic	0009 0208 0556 0698 0264 0037
SuperTech	0009 0037 0556
Supervision	0698 0264
Supra	0178 0009 0037
Susumu	0335 0287
Sutron	0009
SVA	0698 0264 0208 0706
Svasa	0698 0208 0706 0264
Swedx	1606
Swisstec	1775 1709 1606 1613 0880 0865 1849 2059
Sysline	0037 0556
T+A	0447
Tandberg	0109 0361
Tandy	0093
Targa	0618
Tashiko	0170
Tatung	1720 0037 1248 1556 0556 0011 1372 1916
Tauras	2197
TCL	1916 0625
TCM	0714 0808 2001 1308
Teac	0698 1645 2168 3005 0037 0712 1037 0556 0512 0668 0706 0264 0624 0178 0009 0170 0714 1149 1363 0587 1770 1709 2032 2241 1983
TEC	0009 0335 0037 0556 0361
Tech Line	1585 0037 0556 0668 1163
Technical	1667 2676
Technics	0650

BUSH_4-DEV_RDN-1150415_URC-3541 Manual_gedrukt 15-04-15 10:58 Pagina 1

Technika	2106 2032 1865 2676 2168 2059 1849 1667 1983 1585 2125 2197 3005 3810
TechniSat	0037 0556
Technisson	0714 1652
Techno	1585 1037
Technol Ace	0698 0264 0634
Technosonic	0625 2032 0499 0556 1372 0880 0037 0714
Techvision	1709 2032
Techwood	1163 2676 1037 1667
Tecnimagen	0556
Teco	1523
Tedelex	0698 0706 0606 0037 0009 0208 0891 0587 0556 1709 1681 0264 1682
Teiron	0009
Tek	0037 0698 0009
TELE System	2125 1585 1037 0037 2241 1667 2676
Teleavia	0109 0287 0343
Telecor	0037 0556
Telefunken	0625 2239 1667 0560 0808 0587 0074 0109 0698 0712 0343 0754 0780 0891 0287 0335 1681 0753 0706 0037 0556 0486 0714 1556 1585 1588 1163 2676 3175 3719 3981 1882
Telefusion	0037 0556
Telegazi	0037 0264 0556
Telemeister	0037 0556
Telesonic	0037 0556
Telestar	0009 0037 0556 1849
Teletech	0037 0556 0668 0009 1037
Teleview	0037 0556
Tempest	0009 0037 0556 0264
Tennessee	0037 0556
Tensai	0037 0556 0009 0371 0715 1037
Tenson	0009
Tesla	1037 0037 0668 0714 1652 0715 1137 0371 0753 0556 0610
Tevion	1248 1298 1645 0556 0648 1556 1667 2032 0668 0808 0865 1137 1037 2241 1585 0714 0037 2125 2197 1523
Texet	0009
Thes	1849
Thomson	0625 0560 1882 0343 0287 0109 0335 1588 0037 0556
Thomson Life	1882
Thorn	0108 0109 0343 0361 1505 0074 0499 0535 0037 0556 0011 0335 0512 0035
Thorn-Ferguson	0108 0109 0361 0499 0335 0035
TMK	0178
Tokai	0037 0556 0668 0009 1037
Tokaido	1037
Tokyo	0035
Tongtel	0780 0587
Top Show	0698 0009 0264 0706
Topline	1037 0668
Toshiba	1508 2676 0508 0035 1667 0714 1582 0195 0191 0618 1916 0009 0037 1556 0650 1037 1163 1652
Tosumi	1770
Toyoda	0371 0009 0264
Trakton	0009 0264
TRANS-continents	0668 1037 0865 0556 0037 0486
Transonic	0037 0556 0587 0512 0264 0698 0712 0009 1363 0780 0706
Triad	0037 0556 0009
Trio	1248 1645
Tristar	0264
Triumph	0556 0037
Tucson	2676
TVE	2239
TVTEXT 95	0556
Uher	0037 0556 0486 0480
Ultravox	0037 0556 1585
UMC	1606 1775 1709 1849 2059 2106 2168
Unic Line	0037 0556 0473
United	1983 0714 0037 0715 0556 1916 1037 0587 2241 1652 1849 1770 0508 1523 2125 1163
Unitek	1709
Unitron	1681
Universal	0037 0556
Universum	0808 1037 0037 1163 0668 0480 0195 0473 1149 0535 0361 0011 0512 0264 0556 0074 1505 0109 0009 0170 0618
Univox	0037 0556
V7 Videoseven	0178 0880 1666 0618 1651 1505
Vanguard	0037 0556
Venturer	1727 1865 3005
Vestel	2676 1037 1163 1585 1667 0037 0668 0556
Vexa	0009 0037 0556
Victor	0653
VideoSystem	0037 0556
Vidtech	0178
ViewSonic	1588 2111
Vision	0037 0264 0556
VisionPlus	2106
Vistar	0361
Vistron	1363
Visual Innovations	2106
Vivax	1308 0037 1709
Vivo	2032
Vortec	0037 0556
Voxson	0037 0556 0178 2197
Walker	1667 1149 2676 1163 0037 1037 1585
Waltham	0287 0037 0556 0668 0109 1037 0443 2007
Watson	1037 1248 0556 0037 0009 0668
Watt Radio	0486
Wega	0037 0556
Wegavox	0009 0037 0556 1149 1667
Welltech	0714 1652
Weltblick	0037 0556
Weltstar	1037
Weston	0037 0556
Westwood	1585
Wharfedale	1983 1613 1667 0891 1372 0698 0706 0037 1037 1681 0714 0556 1556
White Westinghouse	0037 0556 0624
Wilson	0556
Windsor	0668 1037 3719
Windy Sam	0556
Wintel	0714
World-of-Vision	0880 0865 1298 1606
XDome	0508
Xenius	0634 1667 2676 1585
Xiron	1983 1037
XLogic	0698 0706
Xomax	1770
Xoro	1372
Xrypton	0037 0556
Yakumo	1613
Yamaha	0650 1576
Yamishi	0037 0556
Yokan	0037 0556
Yoko	0037 0556 0264 0009

BUSH_4-DEV_RDN-1150415_URC-3541 Manual_gedrukt 15-04-15 10:58 Pagina 1

YU-MA-TU	0037
Yüsmart	1613
Zenith	0624
Zepto	1585

VCR

Aim	0278 0642 0348
Aiwa	0348 0352 0037 0742 1137 0032 1032
Akai	0037 0315 0642 0352 0240 0348
Alba	0278 0352 0315 0348 0081
Allorgan	0240
Allstar	0081
Amstrad	0278
Aristona	0081
ASA	0037 0081
Asuka	0037 0081
Audiosonic	0278
AVA Technology	0615
AVP	0352
AWA	0037 0278 0642
Baird	0278 0104
Basic Line	0278 0104
Beko	0104
Bestar	0278
Black Diamond	0642 0278
Black Panther	0278
Blaupunkt	1562 0226 0081
Blue Sky	0037 0348 0352 0278 0642 1137 0742
Brandt	0320
Brinkmann	0348
Broksonic	0742 0352
Bush	0742 0278 0315 0352 0348 0081 0642
Carena	0081
Carrefour	0045
Cathay	0278
Centrum	0593
Combitech	0352
Condor	0278
Crown	0037 0278 0642
Cyrus	0081
Daewoo	0278 0642 0348 0352 0045
Dansai	0278
Dantax	0352 0742
Daytron	0278
de Graaf	0042 0081 0104 0048
Decca	0081 0067 0348 0352
Deitron	0278
Diamant	0037
Diamond	0278
Digitor	0642
DSE	0642
Dual	0081 0278 0348
Dumont	0081 0104
Durabrand	0642 0593
E.S.C.	0278 0240
Elbe	0278
Elin	0240
Elta	0278
Emerson	0045 1137
EuroLine	0348
Ferguson	0320 0278 0348 0742
Fidelity	0240 0432 0352
Finlandia	0104 0081 0042 0048 0037 0226
Finlux	0081 0104 0042
Firstline	0348 0037 0045 0042 0278 1137
Fisher	0104
Flint	0348
Fujitsu General	0037
Funai	0593
Galaxis	0278
GE	0320
GEC	0081
General Technic	0348
Genexxa	0104
GoldStar	0037
Goodmans	0742 0240 0278 0037 0081 0348 0352 0642
GPX	0037
Graetz	0104 0240
Granada	0104 0048 0081 0240 0037 0226 0042
Grandin	0037 0278
Grundig	0347 0081 0226 0320 0348 0352 0742
Haaz	0348
Hanimex	0352
Hanseatic	0037 0278 0081
Hinari	0352 0278 0240
Hisawa	0352
Hischito	0045
Hitachi	0042 0240 0081 0104 0593
Höher	0278 0642
Hornyphon	0081
Hypson	0348 0278 0352 0037
Imperial	0240
Ingersoll	0240
Inno Hit	0240 0278
Interbuy	0037
Interfunk	0081 0104
Internal	0278
International	0278 0037
Intervision	0278 0037 0348
Irradio	0037 0081 1137
ITT	0104 0240
ITT Nokia	0048
ITV	0278 0037
JMB	0352 0348
JVC	0067 0593
Kambrook	0037
Karcher	0278
Kendo	0315 0348 0037 0278
Kneissel	0352 0348 0037 0278
Kolster	0348
Lenco	0278
LG	0037 0278 1137
Lifetec	0348
Loewe	0081 1562 0226 0037
Logik	0240
Lumatron	0278 0593
Luxor	0104 0048 0315
Magnavox	0081 0642
Magnum	0642
Manesth	0045 0081
Marantz	0081
Mark	0278
Mascom	0642
Mastec	0642
Master's	0278
Matsui	0348 0037 0240 0352 0742
Maxton	0081
Mediator	0081
Medion	0348 0352
Melectronic	0037
Memorex	0104 0037 0048
Metronic	0081
Metz	1562 0347 0836 0081 0226 0837 0037
Micormay	0348
Micromaxx	0348
Mitsubishi	0067 0081 0642
Multitec	0037
Multitech	0104
Myryad	0081
NAD	0104
Naiko	0642 0348
National	1562 0226
NEC	0067 0104 0037 0278 1137
Neckermann	0081
Nesco	0352
Neufunk	0037
Nikkai	0278
Nokia	0104 0315 0278 0240 0048 0042 0081
Nordmende	0320 0067 0642
Nu-Tec	0348
Oceanic	0320 0048 0081 0104
Okano	0315 0348 0278
Onimax	0642
Orion	0348 0352 0742
Osaki	0037

BUSH_4-DEV_RDN-1150415_URC-3541 Manual_gedrukt 15-04-15 10:58 Pagina 1

Otto Versand	0081
Pace	0352
Pacific	0742
Palladium	0315 0037 0240 0348 0432
Palsonic	0642
Panasonic	1562 0226 0836 0837
Philips	0081 0593
Phoenix	0278
Phonola	0081
Pioneer	0067 0081 0042
Portland	0278
Pro Vision	0278
Profitronic	0081 0240
ProLine	0278 0615 0642 0320
Prosco	0278
Prosonic	0278
Protech	0081 0278
Pye	0081
Quasar	0278
Quelle	0081
Radialva	0037 0081 0048
Radiola	0081
Radionette	1137 0037
RCA	0320
Reoc	0348 0278
Roadstar	0240 0037 0278 0742 0081
Saba	0320 0278
Saisho	0348
Salora	0104
Samsung	0240 0432 0081
Sansui	0067 0348
Sanyo	0104 0048 0067 0348
Saville	0352 0278 0240
SBR	0081
ScanSonic	0240
Schaub Lorenz	0104 0315
Schneider	0037 0081 0278 0240 1137 0042 0352 0642
Scott	0593
Seaway	0278
SEG	0278 0240 0642 0081 0593
SEI	0081
Sei-Sinudyne	0081
Seleco	0037
Sharp	0048 0037
Shintom	0104
Shivaki	0037
Siemens	0037 0104 0081 0320 0347
Siera	0081
Silva	0037
Silver	0278
SilverCrest	0642
Singer	0348 0045
Sinudyne	0081 0352
Skantic	0348
Smaragd	0348
Sonoko	0278
Sonolor	0048
Sontec	0037 0278
Sonwa	0642
Sony	0032 1032
Soundwave	0037 0348
Standard	0278
Starlite	0037 0104
Stern	0278
Sunkai	0348 0278
Supra	0037 0240 0348 0278
T+A	1562 0226
Tandberg	0278
Targa	1137
Tashiko	0048 0240 0081 0037
Tatung	0081 0048 0348 0352 0742
Tchibo	0348
TCM	0348
Teac	0278 0642 0037 0081 0593
TEC	0278
Technics	0226
TechniSat	0348
Tedelex	0037 0348 0642
Telefunken	0642 0593 0320 0278
Telestar	0037
Teletech	0278
Tensai	0037 0278
Tesla	0081
Tevion	0348 0642
Texet	0278
Thomson	0320 0067 0278
Thorn	0104 0037
Thorn-Ferguson	0320
Tokai	0037 0104
Topline	0348
Toshiba	0045 0081 0742 0352
Tradex	0081
Tredex	0278
Triad	0278
Uher	0037 0240
Ultravox	0278
Unitech	0240
United	0348 0742
Universum	0081 0240 0037 0348 0104
Victor	0067
Watson	0081 0352 0278 0642
Weltblick	0037
Wharfedale	0593 0642 0615
World	0348
Yamishi	0278
Yoko	0037 0240
ZX	0348 0352

VCR

SAT

@sat	1300
@Sky	1334
ABsat	1323 0713
Acoustic Solutions	1284
ADB	2553 1473 2367
Adcom	0200
AEG	2738 2813
AGK	2139
Agora	1284
Airis	1659 1993 2813
Akai	0200
Akira	2813 2738
Akura	1626
Alba	2296 3601 1284 1659 0713 2568 2034
Allsat	0200
AllTech	0713
Allvision	1232 1334
Alpha	0200
Altech UEC	1959 2097 1960 2059
Amitronica	0713
Ampere	0396 0132
Amstrad	0132 1693 0847 1175 1662 1113 2139 0396 0713 0501
AMTC	2738 2813 1993
Anglo	0713
Ankaro	0713
Ansonic	2418
Antiference	1284
Apro	1672
Arcon	0132
Arena	1736
Argos	2568
Armstrong	0200
Arnion	1300
ASA	0299 0740
Asat	0200
ASCI	1334 0114
Asda	1284
ASLF	0713
AssCom	0853
Aston	1129
Astra	0713
Astratec	1743 1929
Astrell	1986 2418
Astro	0173 2026 0501 0658 1113 1099 1100 0200
Atlanta	2418 1993 2813
Atom	2289
Audiola	2418
Audioline	1429
Aurora	0879 1433
Austar	1459 0879
Austriasat	1195 1197

SAT

BUSH_4-DEV_RDN-1150415_URC-3541 Manual_gedrukt 15-04-15 10:58 Pagina 1

Auvisio	2531 2738 2813
Avalon	0396
Avanit	0299 1631
AWA	1659
Axil	1777 1993 1659 1720 2418 2738
Axis	1111
Axitronic	1626
B.net	1672
B@ytronic	0299 0740
Balmet	1232
Base	1718
Belson	2418 2139 1993
Best Buy	1993 2139 2728 2418
Biostek	2738
Black Diamond	1284
Blaupunkt	0173
Blizoo	2145 1736
Blue Sky	0713
Boca	2797 0132 1366 0713 1232 2026 2308 2458 2533 2813
Boshmann	1413 1631
Boston	0132
Botech	2738
Boxer	1458 1957 1692 2429 2443
Brainwave	0658 1672
British Sky Broadcasting	1662 1175 0847
Broco	0713
BSkyB	1662 1175 0847
BT	3140 1176
BT Vision	1176 3140
Bubu Sat	0713
Bulltech	2738
Bush	1284 1626 1672 2418 1645 2813 3439 1743 2376 1291 1935 2568 2034 3652 3346 3699 3800
Cablecom	1195 1197 1545
Cabovisão	1300 1631
Caiway	2443
Cambridge	0501
Canal Digitaal	0853 1499 2561
Canal Digital	0853 1780 1004 1046 2553 1334
Canal Plus	2107 2657
Canal+	0853 2107 2657 1722 1986 2748 1232
CanalSat	2107 2657 0853
CanalSatellite	0853 2107 2657
CDV	1993
CGV	1413 1567 2034 1232 1986
Challenger	1956
Cherokee	1323
Chess	1334 0114 0713 2026 1626
Chili	1718
CityCom	1176 1232 0299 1720 0658
Clarke-Tech	1806
Clatronic	2738 1413
Clayton	1626
Clemens Kamphus	0396
Cobra	0396 2531 2728
Colombia	0132
Columbia	0132
Com Hem	1176 1915
Comag	1413 1232 2026 1366 0132 2101 2308 2533 2458 2797 2813
Comsat	1413
Comwell	1956
Connexions	0396
Conrad	0573 0501 0132
Continent	1986
Coship	1672
Croner	2813
Crown	1284
CS	1631
Cyfra+	2593 1409 0853
Cyfrowy Polsat	0253 0853 1409
Cyrus	0200
Daeryung	0396
Daewoo	0713 1743 1111
DAK	1993
Dantax	1626
D-box	1114 0723
Delta	1176 2443
Denver	2418 2738
DGTEC	1631 1718
Dick Smith Electronics	2813
Dicra	2738
Digenius	0299 0740
Digi	2026 1195 1197 1300
Digi Raum Electronics	1176
Digiality	1334 2813
DigiFusion	1645 1743 1929
Digihome	2034 1284 1935
Digiline	2273
DigiLogic	2034 2241 1993 2813
DigiMax	2273
DigiQuest	2278 2738 1473 1300 1631 2289
DigiSat	1232
Digital	2308 2273
Digital Vision	1929
Digital+	1046 0853
DigitAlb	1232
DigitalBox	2289 2540 1631 1100 1886
Digitel+	1659
Digittrade	1659
DigiTurk	2097
Dikom	2531
Dilog	1780 1957
DiPro	1473 2278
Distratel	1283
Distrisat	0200
Diunamai	2531
Di-Way	2289
DNA	1780 1957 1176 2144 1545 1323
DNT	0200 0396
Doro	1672
DRE	1176
Dream Multimedia	1237 1923 1652
DSE	2280 2418 2813
DStv	0879 2059 2060 1959 1960 1433
Dual	2034
Durabrand	1284 2241 2034
DVX	1993
Dyon	2738 2813
ECG	2738
Echolink	1366
Echostar	1200 0853 0396 0713 1323 1473 1409
Eco-Star	1413
Edision	1631 2306 2712
Einhell	0132 0713 0501
Elap	0713 1409 1611 1129 1567 1413
Elbe	2418
Electron	1956
Elisa	2455
Elless	0740
Elsat	0713
Elta	2738 0200 1659
Emtec	1659
Energy Sistem	1631 2289 2418
Engel	1720 1672 0713 1993 1251
esoSAT	2797
Essentials	3439
Essentiel b	2738
EuroLine	1251
Europa	0501 0200
Europhon	0299 0132 0713 1334
Europsat	1413 1611
Eurosat	1567 1886
Eurosky	0132 0299 0114 0501 0740
Eutelsat	0713
Eutra	0740 0299
Evesham	2034
Evolve	1993
F&U	2139
Fagor	1611

SAT

SAT

FaVal	1631
Fenner	0713
Ferguson	1291 1743 1929 1935 2034 1284
Fetch TV	2455
Fidelity	0501
Finepass	1780
Finlux	1626 2034 0573 1232 1284
FinnSat	0740
Flair Mate	0713
FMD	1251 1413 0114
FoneStar	1720
Foxtel	1356 1459 0879 1176
FPE	1993 2813
Free Wave Technology	1743
Freecom	0501 0173
Freesat	2376 2408 1692 3800 3204
Freesat+	2443
Fte Maximal	0713 1886 2289
Fuba	2750 0396 0173 0573 0299 1251
Fuji Onkyo	1631 2748 2728 2101
Galaxis	1111 1176 0853 0879
Galaxy	1956
General Satellite	1176
Geser	1631 2738
Get	1004
Gi	2799
GigaTV	2738
Globalteq	2145
Globo	1251 2273 1626 1429 1334 2026 0740
GlobSat	2748
Go	1780
GOD Digital	0200
GoGen	2738
Gold Box	0853
Gold Vision	1631
Golden Interstar	1283
GoldMaster	1334 1722
Goodmans	1284 2034 1291 3439 2376 2568 3346 3652 3800 1743 2296 3699
Gradiente	0887
Gran Prix	0740
Grandin	1626
Grocos	1409
Grundig	0173 0847 2367 2813 1291 2738 1284 2376 1672 2568 0879 3346 0853 0501 1780 2034
Haier	2418
Hailo	2289
Hallo	1626
Hama	1567
Handan	1780 1957
Hanseatic	1099 1100
Hänsel & Gretel	0132
Hauppauge	1672
HB	1736
HE@D	2183
Hills	1232
Hirschmann	0396 1886 1111 1113 2026 0173 0573 2308 0299 1232 0501 0740
Hitachi	2034 1284
HNE	1232 0132
Homecast	1680 1736
Houston	0396
Humax	1176 1232 2289 2408 1808 2736 3140 1427 1915 2144 1882 1788 1675 1743 2443
Huth	0132
Hyundai	2034 2738
i-Box	1652
i-CAN	2367
Icecrypt	2289 1631
ID Digital	1176
ID Sat	2145 2289 1334 1631
Illusion Sat	1631
Image	1993
Imagin	1195 1197
Imperial	1429 1334 1099 2289 1100 1197 1195 1351 0200 1672 1631
iNETBOX	1652
Ingelen	0396
Inno Hit	1626 2728
Intek	2204
International	0132
Inves	1993 1743
inVion	2418
iotronic	1413 0132
IP Vision	2455
IQ	2813
i-SET	1567
Isis	1284 2034
ITT	2418
ITT Nokia	0573 0723
Jaeger	1334 2797
Jameson	2813
Jepssen	2204
JVC	1284
Kabel Deutschland	1195 1197 1882 2443 1915 1672
KabelBW	1882 1915 1195 1197 1046 1176 1429
KabelNoord	2443
Kamm	0713
Kamosonic	2738
Kaon	1004 1300
KaTelco	1111
Kathrein	2569 1561 0707 1567 0658 1717 0249 0114 0173 0200 0713 1323
Kendo	1284
Kenwood	0853
Key West	0132
Kiton	0114
Kongque	1300
König	1631 2289 1567
Koscom	1956
KPN	1986 1545
Kreiling	0658 0249 0114 1626
Kreiselmeyer	0173
Krystel	1284
K-SAT	0713
Kyostar	0132
L&S Electronic	0132 1334
Labgear	2748
LaSAT	0132 0299 0740 0173
Lauson	2531
Lazer	2738
Legend	1718
Legend Digital	1718
Leiker	2728
Leiko	1626
Lemon	1334
Lenco	0713
Lenoxx	1611
Lenson	0501
Lexus	0200
LG	1414
Lifesat	0132 0299 0713
Line@TECH	2813
Linsar	1284
Listo	1626 2813
Liwest	1195 1197
Lodos	1284
Logik	1284 2441 2034 3204 3652
LogiSat	2797 2813 2026 2458
Lorenzen	0299 2026 0132
Lowry	1284
Luxor	1935 2034 0573 0501
M vision	2273
Macab	0853
Majestic	2738
Manata	0713 0132
Manhattan	2748 3204 1300
Maplin	2034
Marantz	0200
Marks & Spencer	2441
Marusys	2799
Mascom	2738 1680
Maspro	0713 0173
Matsui	1626 0173 1743 1929 1284 0200
Maximum	1334 2552 1986

Mediabox	0853
Mediacom	1206
MediaSat	0501 0853 2107
Mediaset	2750 2739 2278 2367 1427 2736 1473
Medion	1232 2797 0299 0713 0132 1626 1334 0740 2026
Medison	0713
Mega	0200
Megasat	2289 1631 1886 2813 0740 0299 2034 1284 2738
Metronic	2278 1284 1659 1935 0713 1631 2738 2418 1283 0132 1993 1986 1413 2269 1672
Metz	0173
MiCO	1993
Micro	2308 2813 0501 0713 2797
Micro electronic	0713 2308 2813 2458
Micro Technology	0713
Micromaxx	0299
Microstar	0299
Microtec	0713
Mitsai	2738
Morgan's	0132 0713 0200 1232 1409
Motorola	0856 1473
Multichoice	0879 2059 1959 1960 2060 1433
Murphy	2034
Mx Onda	1659
Myryad	0200
Mysat	0713 2738
MySky Italia	1693
MySky New Zealand	1356
NanoXX	2204 1631
NC+	2593
Neom	1993
Neosat	2273
Neotion	1334
Netgem	1322 2455
Neuf TV	1322
Neuhaus	0501 0713
Neuling	1232 0132 2458 2026
Neusat	0713
Nevir	1659 2728
New Line	2813 1993
Newton	0396
NexPRO	1631
NextWave	1956
Nikko	0713 0723 0200
Nilox	2278
Nokia	1114 1023 1223 0723 0853 0573
Noos	0853
Nordmende	1611
Nova	0879 1959 1960 2059 2060
NPG	2289 1631 2531
NTV Plus	1692
Numericable	0853 0099
OctalTV	1429
OKI	1567
Olin	2289
Omni	1993
Onn	1284 2034
Openbox	1662 1956
Opensat	1956
Opentel	1232
Optex	1720 1232 1993 1283 0114 0713 1611 1626 1413
Opticum	2273 2797
Optus	1356 0879 0853
Orbis	1334 1232
Orbitech	1099 1195 1197 1100 0200 0501 0114 1351
Orchid	2289
Orion Express	1986
Orton	2273
P&T Luxembourg	1322 2455
P/Sat	1232
Pace	1175 1356 1682 1693 1717 2097 2593 2657 0847 2059 1662 1323 2060 0887 0200 0853
Pacific	1284
Packard Bell	1111
Palcom	0299 1611 1409
Palladium	0501 0396
Palsat	0501
Panasat	0879 1959 1960
Panasonic	0847 1304
Panda	0173
Patriot	0132
peeKTON	1993 2418
Philips	0099 2097 2107 2593 1114 1499 0853 0133 0200 1672 1743 0173 1429 2561
Phoenix	2418 1956
Phonotrend	1200
Pino	1334
Pioneer	0853
Planet	0396
PMB	1611 0713
Polytron	0396
Preisner	0132 0396 1113 1366
Premiere	1114 1915 0723 1176 1195 1100 1882 1675 1788 0249 1111 0658 1717 2647 1499 1197
Premium	1736
Primacom	1111
Pro Basic	0853 2531
ProLine	1284 1659
Quadral	1323
Quelle	0299
Radiola	0200
Radix	0396 1113
RCA	1291
Regal	1251
RFT	0200
RiksTV	2367 1692 2429
RIO Media	1780
Roadstar	0713 0853
Rollmaster	1413
Ross	2540
Rover	0713
Rownsonic	1567
SAB	1251 1956 1300 1631
Saba	2205
Sagem	1114 1690 2107 2553 1692 2429 1004
Sagemcom	1692 2429
Saivod	2418
Salora	1232
Samsung	1662 1693 1458 1206 0853 1682 0253 1175
Sansui	1545 1251
Sanyo	1626
Sappa	2204
SAT	0501
Sat Control	1300
Sat Industrie	1611
Sat Partner	0501
Sat Team	0713
SAT+	1409
SatCatcher	1956
Satec	0713
Satlink	2273 1567
Satplus	1100
SatyCon	1631
Schaub Lorenz	2034 2418
Schneider	1251 1206
Schwaiger	2797 2533 1334 1631 2458 0740 1111 1429 1672 2308 0132 2813
Scott	2738
SCS	0299
Sedea Electronique	0132 1283 1626 0114
Seeltech	1993
Seemann	0396
SEG	1251 2235 1626 0114 1993 1659 1284 2034
Servimat	1611
ServiSat	1251 0713
Set-One	2728
SFR	2455 1322

SAT

Shark	1631
Sharp	2034 1935
Sherwood	1611 1409
Shinelco	2278 2738
Siemens	0173 1626 1657 1334 1429 2418 1672
Sigmatek	2139 2418 2813 2738
SignalMAX	1956
Silva	0299
Silva Schneider	0740
SilverCrest	2026 2101 2308 2458
Simz	2241
Skantin	0713
SKR	0713
SKT	0132
Sky Deutschland	1114 1915 0723 1197 1176 1195 1100 1882 1675 1788 1499 1111 0249 0658 1717 2647 0099 1351 2561 2443
Sky Italia	1693
Sky Media	1662 0856 0887 1114 1175 1693 1915 0847
Sky New Zealand	0856 0887 1356
Sky UK	1662 1175 0847
Sky XL	1251
Sky+ UK	1175 1662
Skylink	1986 1722 2443 1631 2289 2034 1545 1195 1197 1680 1957
Skymaster	1409 1611 0713 1200 1334 1567 2205 1545 2409 2728 2241
Skymax	0200 1413
Skypex	0299 0740
skyplus	2026 1232 1334 1175 0740
SkySat	0713 0501 0114
Skyvision	2797
Skyworth	1631 2289
SL	2026 0132 0740 1672
SM Electronic	0713 1200
Smart	0132 1631 0299 0396 1113 1232 0713 1413 2289 2285 0740
Sogo	2139
Sonera	1780 1957
Soniq	1567
Sony	0847 1558 0853
SR	0132
Star Sat	0132
Star View	2145
Starcom	0114
Starland	0713
Steinner	2738
Stream System	1300
Strong	1409 2235 0713 2278 1626 2418 0853 1284 1300 0879 1473 2748 2813 1993 2034 1806
STV	1986 2145 1736 1176
Sunny	1300
Sunray	2799
Sunsat	0713
Sunstar	0132
Sunstech	1993 2139 2738 2418 2813
Supratech	1413 2139
Systec	0132 1334
Sytech	2139 2418
TBoston	2418 1659 1251 2139
TBS	1284
Teac	1322 1957 2813
Tecatel	1200
Technika	2034 2441 1284 1672 1626 2455
TechniSat	1195 1197 1100 1099 0501 1351 1322 0200 0114 0396 2813
Technoit	2278
Technomate	1283
Technosat	1206
Technosonic	1672
Technotrend	1429 1672
Technowelt	0132
Techwood	0114 1284 1626 2034 1935 1251
tekComm	2738
TELE System	1611 1409 1251 0396 2739 2750 2813 1993 2738
Tele2	1195 1197
Telecom	0713
Teleka	0396 0501
Telestar	0501 1099 1100 0114 0200 1429 1251 1334 1351 1626 1672 1195 1197 2540
Teletech	0114
Televes	2101 0501 0132 1300 1334 1409
Telewire	1232
Telsey	2738
TelSKY	2540
Telstra	1356
Tesla	1626
Tevion	1334 1672 0713 1409 1567 2205
T-Home	1692 1004
Thomson	0847 1291 2107 1046 1175 0853 1662 1459 1935 0713
Tiny	1672
Tioko	0132
Titan	1886 2205
Tividi	1429 1736
TivùSat	2750
T-Mobile	1545 2443
TNT Pass	1567
TNT SAT	2235 1692 2748 2429 1986 1195 1197
Tokai	0200
Tonna	1720 1611 2458 0501 0713
Top Up TV	1935
Topfield	1986 1545 1783 1722 1206 1824
Toshiba	1284
TrekStor	2738 2813
Triasat	0501
Triax	0501 1722 1986 0200 0396 0713 0853 1251 0114 1291 0132 1099 1113 1626 1611 1413 2101 1886
Tricolor TV	1176 1915
TT-micro	1429
Turnsat	0713
TV Vlaanderen	0853
TVonics	2441
Twinner	0132 0713 1611
UEC	0879 1356
UfaNet	1986
Umax	1993
Unisat	0200 0132
United	1251 2418 1626 2278
Unitymedia	1429 1882 1176 1195 1197 1915 2443
Univers	1886
Universum	0173 0299 0114 1099 0740
UPC	1176
UPC Direct	2443
Van Hunen	0299
Vantage	1458 2297 2797 2204
Vaova	1993
Variosat	0173
VEA	2418
Vectra	1195 1197
Ventana	0200
Vestel	1284 1251 0114 1626
VH Sat	0299
Viasat	1323 0253 1023 1682 1195 2235 1197
Viola Digital	1672
Virgin Media	2441
Vision	1626 1886
VisionNet	1631
Visiosat	1718 1413 1631 0713 0114 1129
Vistron	0740 0299
Vitecom	1413 2531
VivaCom	2429
Volcasat	2418
Volia	1957 1780
Voo	0853

SAT

SAT

BUSH_4-DEV_RDN-1150415_URC-3541 Manual_gedrukt 15-04-15 10:58 Pagina 2

Vu+	2799
Walker	2034
Wavelength	1232 1413
Wetekom	0501
Wharfedale	1284 2034 0200 1935
Wightfibre	3140
Winix	2278
Wisi	0173 0396 0299 0501 0132 0740 1232 1986
Worldsat	1473 0114 1251
Woxter	2418 2139 2813
Xoro	2738 2813
Xsat	0713 1323
Xtreme	1300
Yakumo	1413
Yamada	1718 1993 2139
Youview	3140 2408 1176
Yukai	1659
ZapMaster	0740
Zehnder	1777 1720 1251 1334 1232 1413 0114 1631 2388 2235 1886 2034 0740 2289
Zenith	0856
Zeta Technology	0200
Ziggo	1657 1499 2443
Zinwell	1176 2280
Zircon	1631 2289
Zodiac	2531

CBL

@Home	1666 2015 0660
ADB	2343
Akado	2043
Altibox	2030
Amino	1615
Belgacom TV	2132
BT Vision	2294
Cablecom	1582
Caiway	2447 2015 0660 1666
Canal Digital	2030
Cisco	2563 2589 3265 2132 1582
ClubInternet	2132
Com Hem	0660 1666 2832 2447 2015
Cyfrowy Polsat	1666
Delta	0660 2015 1666 2447
Digi	0660
DNA	2832 1666 0660 2030
Echostar	2955
Elion	1615
freebox	1976 1482
Glashart Media	1615
GuestComm	2030
Huawei	2994
Humax	0660 1813 2043 2447 2889 1885 1983 2165 1981 2832 2620
Jambox	2030
Kabel Deutschland	1981 1983 2165 1666 2174 1577 2620
KabelBW	1813 2174 2889 1981 1983 1060
KabelNoord	2015
Kaon	2889
Kiss	2132
Kreatel	2030
Lattelecom	2030
Magio Sat	2132
Magnet	1615
Motorola	2030
MTS	1615
NTL	1060 1068
Ono	1068
Optus	1060
Orange	2407
Pace	1068 1577 2620 1060 2294
Philips	2174 1619 2294 1582
Premiere	2620 2174 1577 1813
Primacom	2889
PrimeTel	2030
PrimeTV	2030
Qwerty	1615
RIO Media	2030
Sagem	2407
Sagemcom	2407 0660
Samsung	2407 2015 2174 1060 1666 1987 2955 3265 2889 2610 2589
Scientific Atlanta	2132
Sky Deutschland	2620 1577 1813 2174 1619 1885 2447 0660 2832
Sky Media	2620
Sonera	1666 0660
Starman	0660
Stofa	2015
STV	0660
TalkTalk	2994
T-Com	2132
Technicolor	2994
Tele2	0660 2447
TeleColumbus	2889
Telewest	1068 1060 1987
Telia	2030
Telset	0660
TelstraClear	2343
T-Home	2132
Thomson	1582 1981 2174 2407 1983
Tivo	3265
TP	2407
Unitymedia	2610 2955 1813
UPC	0660 1582
UPC Cablecom	1582
Vector	2030
Viasat	2030
Viken Fibernett	2030
Virgin Media	1060 3265 1068 1987 2563
Vodafone	1615
Welho	2832
Youview	2994
Ziggo	2015 2589 0660 2447 1666

VIDAC

A.C.Ryan	2709
Antec	2037
Apple	2615
Argosy	2270
ASRock	1272
Asus	1272
ATMT	2270
Best Buy	2522
BSkyB	3061
Captiva	2270
chiliGREEN	2628
Dane-Elec	2628
Digitech	2260
DVICO	1921 2153
EGreat	2260
Elonex	1272
Eminent	2260
Emtec	2709
Fantec	2522 2709
Fujitsu Siemens	1272
Galaxy	2238
Hauppauge	1408
Hewlett Packard	1272
hFX	1272
iMON	2037
INOi	2270
Iomega	2270 2238
ISTAR	2260
LaCie	2238 2626
me2	2270
Memup	2270 2522
Microsoft	1272
Muvid	2522
Netgear	2036
Nilox	2522
Olidata	2270
Packard Bell	2238
Pinnacle Systems	1447

PopBox	2260
Popcorn Hour	2260
RaidSonic	2238
Ricavision	1272
Roku	3061
Sky UK	3061
SoundGraph	2037
Sumvision	2628
Thermaltake	2037
Trust	1272
TViX	2153
Via Technologies	1272
Western Digital	2558
Woxter	2628 2709
XBox	1272

DVD

3 Plus	0490
3D LAB	0539
4Kus	1158
Acoustic Solutions	0730 0713 2966 1530
AEG	0770 0790 1233 1923 0675 2173 1643
AFK	1152 1923
AGK	2139
Aim	0672 0790
Airis	0672 1005
Aiwa	0695 0869 0533 2020
Akai	0790 1115 0898 0884 0713 1233 2966
AKI	1005
Akira	2227
Akura	0898 0733 1493 1383
Alba	0713 2966 3765 0733 0695 0730 0539 0672 1530 0884 4081 3177
All-Tel	0790
Amitech	0770
Amstrad	0713 1115 1571 1493 0790 0770 2139 2172
AMW	0872
Ansonic	1351 0831 1493
Apex Digital	0672
Arcam	0732
Arena	1115
Aristona	0539 0646
ASCOMTEC	1923
Audio Authority	2555
Audiosonic	1923 1383
Audioworld	0790
Audix	1152 0713
Autovox	0713
AVideo	2173
AWA	0730 0872
Axion	0730
Basic Line	0713
Bauhn	3527
Baze	0898 0672
BBK	3527
Bellagio	0872 1004
Belson	1923 2139 2172 2227
Belsonic	1493
Berthen	1643
Best Buy	2139 2172
Binatone	1923
Biostek	1005
Black Diamond	0713 0884
Blu:sens	1233
Blue Sky	0713 0695 0672 0651 0790 0884
Bluetech	1516
BlueTinum	1493
Boghe	1004
Boman	0898 1005
Bose	2023
Brainwave	0770 1115
Brandt	0651 0551 0503 2966
Bush	0831 0713 0695 3765 0730 0884 1351 0733 1530 1383 2227 2139 3177 2966 4081 1957
CAT	0789
Celcus	2966
Celestial	0672
cello	2815
Centrex	0672 1004
Centrum	0713 0789 1005 1923 0675
CGV	0733 0770
Chili	1493
Cinea	0841
Cinetec	0713 0872
CJ Digital	1643 2173
Classic	0730
Clatronic	0672 0675 1233
Clayton	0713
CMX	1643
Coby	0730
Codex	1233
Conia	0672
Continental Edison	0872 0831
Crown	0770 0651
C-Tech	1152
Curtis	1493
Cybercom	0831
CyberHome	0816 1023
Cytron	0651 0831
Daenyx	0872
Daewoo	0770 0872 0213
Dansai	0770 1115
Dantax	0695 0713
Daytek	0872 1005
Dayton	0872
DCE	0831
Decca	0770
Denon	1634 0490 2258
Denver	0898 1923 1493 0672 1643
Diamond	0651 1152 0790 0770 1115
Dick Smith Electronics	0213
Dicra	2173
Digihome	0713 2966
DigiLogic	0713
Digital	2173
Digitor	1005 0651
Digitrex	0672 1004
DigiX	1394
DiK	0831
Dikom	2966
Dimarson	1233
Disney	0831
DK digital	0831 1643 2095
DMTECH	0790 2173
Dragon	0831
DSE	1152 0675 0213 2095
Dual	0831 0713 0651 0730 0790 1023 1530 0884 2227 1115 2966
Durabrand	0831 0675 0713 1530
D-Vision	1115
DVX	1152
e:max	1233 1643 1670 2173 0770
eBench	1152
Electrohome	0770
Elfunk	0884 0713
Elin	0770
Elta	0770 0790 1115 1233 1670 1643 2173
Emerson	0591 0869
Enox.	2815
Enzer	1005 0770
EuroLine	1115 1233 1351 0675 1643
F&U	2172 2139
Ferguson	0651 0898 0713 0884 3177 2966
Finlux	0741 0770 0591 0672 2966
Fintec	0713 1530
Firstline	0869 0651 1530
Funai	0695 0675 1957
Futronic	1005
Gericom	1004
Global Solutions	1152
Global Sphère	1152
GoldStar	0591 0741

Goodmans	0713 1004 1383 3765 0730 0651 0790 0884 0733 1923 1530 2966
GoWell	1643
GPX	0741
Gran Prix	0831 0898
Grandin	0672 0713 2173
Grundig	0775 0695 0651 0539 0790 0713 0670 1004 0551 2966
Grunkel	0770 1493 0831
H&B	0713 0841 1233
Haaz	1152
Hanseatic	0741 0790
Harman/Kardon	0702
HE	0730 1923 1493
Henß	0713
Hicon	0672
Hikona	1383
Hitachi	0664 0573 0713 1748 0884 2966 1957
Hiteker	0672 1923
Höher	0831 1004 2173 0713 1530 1643
Home Electronics	0730 0770
Home Tech Industries	1923
HYD	1233
Hyundai	1152 1530 2966 1493
ICP	1152
Inno Hit	0713 2966
Integra	2147
Irradio	0741 1115 1233 0869 0770
ISP	0695
ITT	1233
JBL	0702
JDB	0730
JGC	1530
JMB	0695 2966
JVC	0623 2966 1901 0539 0503 2365 0695 1957
Kansas Technologies	1233 1530
Kazuki	1493
Kendo	0713 0831 0672
Kennex	0770 0713 0898
Kenwood	0490 1906 2652
KeyPlug	0770 1643
Kiiro	0770
King Vision	1643 1493
Kiss	0841
Koss	0651
Küppersbusch	2966
KXD	1923
Lawson	1152
LC Power	1493
Leiker	0872
Lenco	0651 0770 0713 0831 1383
Lenoxx	1005 1923
Lexia	1152
LG	0741 1602 1906 2189 0869 0591
Lifetec	0651 0831
Limit	1152
Linetech	2966
Linsar	2966 0884 1957
LiteOn	1158 1416 1738 1644
LM	1643
Lodos	0713 0884
Loewe	0539 0741
LogicLab	1152
Logik	0713 0884 2227 3177
Lumatron	1115 0741 0713 0730 0898
Luxman	0573
Luxor	1004 2966 0713 0730 0884
Magnavox	0503 0675 0539 0713 0733 1354
Magnum	1382 1152
Manhattan	0713
Manta	1493
Marantz	0539 2414
Mark	0713 0695 0884
Marks & Spencer	2815
Marquant	0770
Matsui	0651 0713 0672 0695 0884 2966
Maxim	0713
MBO	0730
Mecotek	0770
Medion	2189 0831 0651 0630 1416 1644 0741 2966
MEI	0790
Memorex	0831
Memory	0730 1383
Metz	0571 0525 0713
Micromaxx	0695
Micromedia	0503 0539
Micromega	0539
Microsoft	1708 2083 0522
Microstar	0831
Minax	0713
Minoka	0770 1115
Mitsubishi	0713
Murphy	2815
Mustek	0730
Muvid	1643 2173
Mx Onda	0651 1383
Mystral	0831
NAD	0741
Naiko	0770 1004
NEC	0869 0591 0741 1602
Neom	1493 1643
Neon	2815
Nevir	0831 0770 0672
Nexius	0790
Nikkai	1923
Nikkei	0898
Nordmende	0831 1530 2966
Nortek	1643 2173
Nu-Tec	1493
OK.	2966
OKI	2966
One For All	2555
Onkyo	0627 1769 2147 0503
Oopla	1158
Optimus	0571 0525
Orava	1923 0884 0713
Orbit	0872
Orion	0695 1233 0898 0713
Oritron	0651
OTIC	1383
Pacific	0790 1152 0713 0831
Packard Bell	0831
Palladium	0695 0713
Palsonic	0672
Panasonic	0490 1834 1661 1579 1641 2518
Papouw	0533
PEAQ	3527
peeKTON	0898
Philips	0539 2056 2789 1340 0646 1354 1813 1506 1846 0675 0503 1158 2093 2334 2434 2526 2791
Pioneer	0571 1965 0631 1900 0525 1571 1768 2442
Play It	1643
Pointer	0770
Polaroid	2966
Portland	0770
Powerpoint	0872 1005
Prinz	0831
Prism	0831
Pro Vision	1923 1493 0730
ProAudio	1394
ProCaster	1004
ProLine	0651 0672 0790 1004 1738 2966
Proscan	0522
Proson	0713 1005
Prosonic	1923 2966 2302
Pye	0646 0539
Radionette	0741 0869 1906
Radiotone	0713
RCA	0522 0651
RE-BL	2555
REC	0490
Red Star	0770 0898 1923 1351 1394
Reoc	1152
Revoy	0841

Richmond	1233
Roadstar	0713 0730 0898
Rocksonic	0789
Ronin	0872
Rotel	0623
Rowa	1004 0525
Rownsonic	0789
Saba	0651 2173 1643 0551 2966
Sabaki	1152
Saivod	0831 0770
Sakyno	1152
Salora	0741 2966
Samsung	0199 0298 0573 1635 1932 0744 1075 1748 2107 2269 0490
Sansui	0695 1152 0770 1115
Sanyo	0670 0695 0213 0790 0713 2966
ScanMagic	0730
SCE	0789
Schaub Lorenz	0770 1152 1643 2173
Schneider	2966 0831 0539 0713 0651 0869 0790 0646
Schöntech	0713
Scientific Labs	1152
Scott	0651 0672 1233 1394 1383 2173 1923
Seeltech	1643
SEG	0713 1152 0884 0872 1530 2815
Shanghai	0672
Sharp	0630 0713 0695 2652 2966
Sherwood	0741 0213
Siemssen	1382
Sigmatek	2139 2172
Silva	0898 0831
Silva Schneider	0831 1906 0741
SilverCrest	1152 1643 2173
Singer	1152
Sinotec	0770 1115
Sinudyne	0733
Sistemas	0672
Skymaster	0730 1152
Skyworth	0898
Sliding	1115
Slim Art	0770
Slim Devices	0533
SM Electronic	0730 1152
Smart	0713
Sogo	2172 1493 2139
Sonashi	0831
Soniq	3177
Sontech	1383
Sonwa	1004
Sony	0533 2861 1516 1981 1536 1633 2020 1533 1903 0864 2555 1033 2132 2839
Sound Color	1233
Soundmaster	1152
Soundmax	1152
Soundwave	1530 2815
Spectra	0872
Standard	0651 1152 0831 0898
Star Clusters	1152
StarLogic	1005
Starmedia	1005
Strato	1382 1152
Strong	0713
Sunkai	0770
Sunstech	2139 0831 2172 2966
Superior	1643 2173
Supervision	0730 1152
Supratech	2172 2139
SVA	0672
Symphonic	0675
Synn	1152
Sytech	2139 0831
Tamashi	1394
Tandberg	0713
Targa	1158 1644 1906 0741 0869
Tatung	0770
TBoston	2172 2139
Tchibo	0741
TCM	0741
Teac	0741 0790 0571 1152 0591 1394 0675 3177 2227 1383
TEC	0898
Technical	2966
Technics	0490
Technika	0770 1115 2302 0831 3527 1530 1383 1152 3177
Technisson	0672
Technosonic	1005 1115
TechnoStar	1643 2173
Techwood	0713 1530 2966 0539
Tecnimagen	1233
Tedelex	1004 1152 0770 1923
TELE System	2173 2966
Telefunken	0790 0789 2966 1957 1923 1115 0770
Teletech	0713 0884 1152
Tensai	0651 0770
Tevion	0651 1382 1152 1004 0898 2227
Textorm	1493
Theta Digital	0571
Thomson	0551 0522 0831
Tokai	0898 1233
Tom-Tec	0789
Toshiba	0503 1510 1769 2966 0695
Tosumi	1005
TRANS-continents	0872 0831 1233
Transonic	0672 1394
Trevi	0831
Trio	0770
TVE	0713
UMC	2302
United	1383 0730 0790 0672 0695 1115 1152 1233 0713 0884 1351 0675
Universal Multimedia	1152
Universum	0741 0713 0591 0790 1530
Vecatech	1493
Venturer	1769 3177
Vestel	0713 1530
Voxson	0730 0831
Waitec	0730
Walker	2966
Waltham	1530
WB Electronics	2555
Welkin	0831
Wellington	0713
Weltstar	0713
Wharfedale	1152 0790 0770 1115 1383
Wilson	0831 1233
Windy Sam	0573
Woxter	2139 2172
XBox	0522 1708 2083
Xenon	1923
Xiron	1383 0713 0884
XLogic	0770 1152
XMS	0770
Yakumo	1004
Yamada	1004 0872 1493 1416 1158 2139
Yamaha	0539 0646 0490 1158 0497 1354
Yamakawa	0872
Yukai	0730
Zenith	0503 0591 0741

BUSH_4-DEV_RDN-1150415_URC-3541 Manual_gedrukt 15-04-15 10:58 Pagina 2

Bush warrants to the original purchaser that this product will be free from defects in materials and workmanship under normal and correct use for a period of one (1) year from the date of original purchase. This product will be replaced free of charge if it has been proven to be defective within the one (1) year warranty period. This warranty does not cover cartons, carrying cases, batteries, broken or marred cabinets or any other item used in connection with the product. Any further obligation than listed above is excluded. To obtain warranty service during the warranty period, please call us at the number mentioned on the Customer Service page. Please notice that we need your purchase receipt so that we may establish your eligibility for service.

If you have bought this product for purposes which are not related to your trade, business or profession, please remind that you may have legal rights under your national legislation governing the sale of consumer goods. This guarantee does not affect those rights.

CE

URC-3541
710418
RDN 1150415