
# **Emmett** - Pair of Upholstered Chairs

Assembly Instructions - Please keep for future reference

149/2772 149/2789



#### **Dimensions**

Width - 48cm

Depth - 62cm

Height - 87.3cm

### Important - Please read these instructions fully before starting assembly.

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800

IW-17-7521-112/ 132-0 Issue 1 - 29/06/12



## Safety and Care Advice

#### Important - Please read these instructions fully before starting assembly.

- Check you have all the components and tools listed on page 2.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft flat / firm surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



 We do not recommend the use of power drill/ drivers for inserting screws,

as this could damage the unit. Only use hand screwdrivers.


• Dispose of all packaging carefully and responsibly .

### Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

**Note:** if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

### Please check you have all the panels listed below




1 Back rest x 2 (44.2 x 55.5cm)



3 Left back leg x 2 (5.1 x 44.4cm)



Right back leg x 2 (5.1 x 44.4cm)



2 Seat pad x 2 (46 x 48cm)



5 Left front leg x 2 (4.1 x 44.4cm)




6 Right front leg x 2 (4.1 x 44.4cm)



## **Components** - Fittings

### Please check you have all the fittings listed below


**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



#### Tool required



Phillips screwdriver (medium & large)



## Step 1

## Attaching back legs and back rest

Fix back legs 3 and 4 to back rest 1 using 2 screws A as shown.

Use a screwdriver to turn fitting A clockwise to fix.

### Step 2

#### Attaching seat pad

**a:** Lift under cloth up and lay back as shown.


**b:** Insert lock washer **f** and flat washer **f** onto each bolt **f** as shown.

Insert bolts B with lock washers and flat washers through the pre-drilled holes of seat pad 2 and back rest 1 into back legs 3 and 4.

Tighten bolts **B** into the fittings inside back legs **3** and **4**.

Use allen key to turn fitting B clockwise to fix.

Continued on next page.



## Step 2 - continued

C: Fix back rest 4 to seat pad 4 using 2 bolts Cas shown.

Use allen key to turn fitting Clockwise to fix.

## Step 3


#### **Attaching front legs**

**a:** Place chair upside down onto a flat, stable, clean and soft surface as shown.

Position front legs 5 and 6 onto seat pad 2.

**Note:** Ensure that you put the front legs into the correct place as shown.

Continued on next page.



## Step 3 - continued


b: Insert threaded bolts

through the pre-drilled hole of metal corner brackets into front legs 5 and 6 as shown.

Tighten threaded bolts into the fittings inside front legs 5 and 6.

C: Insert flat washers , lock washers onto threaded bolts on then secure into position using hex nuts as shown.

Use spanner h to turn fitting Clockwise to fix.




## Step 4


### Attaching under cloth

Place under cloth back onto frame of seat pad by lining up velcro strips and pushing firmly to fix back in place.

Stand the chair upright.

Repeat complete process for second chair.





If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800