
IMPORTANT, RETAIN FOR FUTURE REFERENCE AND READ CAREFULLY. ASSEMBLY AND OPERATING INSTRUCTIONS FOR DINING TABLE

DESCRIPTION

ITEM NAME: EVELYN DINING TABLE
ITEM NO: 25191

15 mins		Floor Area 1.5 m x 1.5 m  Ceiling Heights 2.0 m
APPROXIMATE ASSEMBLY TIME	1 PERSON ASSEMBLY	REQUIRED ASSEMBLY SPACE

REQUIRED ASSEMBLY TOOLS	 Allen key



ASSEMBLED DINING TABLE

DESCRIPTION

ITEM NAME: EVELYN DINING TABLE

ITEM NO: 25191

HARDWARE PACK		
NO.	DESCRIPTION	QTY.
A	 JCBB SCREW (M8 x 60 mm)	8 PCS
B	 FLAT WASHER (M8.5 x 18 mm)	8 PCS
C	 SPRING WASHER (5 / 16" x 15 mm)	8 PCS
D	 ALLEN KEY (M5)	1 PC

Top Tips before you start!

1 .Please check that all parts are present before you start the assembly of your furniture, as once assembled the furniture is exempt from our home approval.

2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required.

3. For larger items, please ensure that you have sufficient space and people (as indicated on page 1) to assemble our product safely.

4. We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid unnecessary moving of the product.

5. For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage.

6. During assembly please take care not to over-tighten any fittings, as this may damage the product .

General for Table

-Please periodically check all fittings and re-tighten as necessary.

-Please do not sit or stand on this item.

-Please do not drag and pull your furniture.

-To clean your items, please use a soft cloth moistened in luke warm soapy and water. Then buff with a dry clean cloth.


MOUNTROSE


DESCRIPTION

ITEM NAME: EVELYN DINING TABLE

ITEM NO: 25191

* NOTE :
PLEASE ASSEMBLY ON SMOOTH SURFACE.





FIRG.1

1). PLEASE FACE DOWN THE TABLE TOP ON SMOOTH SURFACE, ATTACH THE TABLE LEG AT CORNER BLOCK AS SHOWN IN (FIRG.1), USE HARDWARE (A),(B),(C) AND TIGHT IT BY (D) , FOLLOW DO IT FOR EACH TABLE LEG AND TIGHTEN IT.

" NOTE :
PLEASE DO NOT USE ELECTRIC DRILL FOR FIXING "

MOUNTROSE

Thank you for purchasing your new Mountrose product.
If in the unlikely event you experience any problems with assembly. or require any spare screws/fixingsfor this product.

DO NOT RETURN THIS ITEM!!!!!

Please Telephone the Mountrose Customer Helpline

0161 406 5040

or email qc@mountrose.co.uk

THIS DOES NOT AFFECT YOUR STATUTORY RIGHTS

IMPORTANT, RETAIN FOR FUTURE REFERENCE AND READ CAREFULLY. ASSEMBLY AND OPERATING INSTRUCTIONS FOR DINING CHAIRS

DESCRIPTION

ITEM NAME: EVELYN DINING CHAIRS
ITEM NO: 25192

15 mins		Floor Area 1.5 m x 1.5 m  Ceiling Heights 2.0 m
APPROXIMATE ASSEMBLY TIME	1 PERSON ASSEMBLY	REQUIRED ASSEMBLY SPACE

REQUIRED ASSEMBLY TOOLS





ASSEMBLED DINING CHAIRS

MOUNTROSE

MOUNTROSE LIMITED, ALAN HOUSE, ASHTON ROAD, BREDBURY, STOCKPORT. SK6 2QN UNITED KINGDOM

MOUNTROSE

DESCRIPTION

ITEM NAME: EVELYN DINING CHAIRS

ITEM NO: 25192

HARDWARE PACK / 2 CHAIR

NO.	DESCRIPTION	QTY.
A	 JCBC SCREW M6 x 50 mm	12 PCS
B	SPRING WASHER M8 x 13.5 mm	12 PCS
C	 ALLEN KEY BALL	1 PC
D	 CSK SCREW M4 x 32 mm	14 PCS

Top Tips before you start!

1 .Please check that all parts are present before you start the assembly of your furniture, as once assembled the furniture is exempt from our home approval.

2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required.

3. For larger items, please ensure that you have sufficient space and people (as indicated on page 1) to assemble our product safely.

4. We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid unnecessary moving of the product.

5. For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage.

6. During assembly please take care not to over-tighten any fittings, as this may damage the product .

General for Chairs

-Please periodically check all fittings and re-tighten as necessary.

-Please do not sit or stand on this item.

-Please do not drag and pull your furniture.

-To clean your items, please use a soft cloth moistened in luke warm soapy and water. Then buff with a dry clean cloth.


MOUNTROSE

DESCRIPTION

ITEM NAME: EVELYN DINING CHAIRS

ITEM NO: 25192


STEP 1



1). PLEASE LAY DOWN THE BACK FRAME ON SMOOTH SURFACE, ATTACH THE SIDE RAIL AS SHOWN , USE HARDWARE , (B), (A), AND TIGHTEN BY ALLEN KEY BALL(C). DO IT WITH BOTH SIDE.

2). FOLLOW WITH ASSEMBLY THE STRETCHER RAIL, USE HARDWARE (D) AND USE PHILIP SCREW DRIVER TO TIGH IT.DO IT WITH BOTH SIDE.


STEP 2



3). FOLLOW ASSEMBLY AS SHOWN WITH LEG FRAME USING HARDWARE (B), (A), TIGHTEN IT WITH ALLEN KEY BALL(C).DO IT BOTH SIDE.

4). ALSO ASSEMBLY THE STRETCHER RAILTO LEG FRAME, USE HARDWARE (D) AND USE PHILIP SCREW DRIVER TO TIGH IT.DO IT WITH BOTH SIDE.

STEP 3



5). TURN UP SIDE DOWN THE CHAIR FOR ASSEMBLY SEAT, JUST FIX THE SCREW (D) AND (F) TIGHTEN IN BY PHILIP SCREWDRIVER AS SHOWN.

NOTE :
PLEASE DO NOT USE ELECTRIC DRILL TO FASTEN THE SCREW (EXCESSIVE PRESSURE WILL CAUSE BREAKAGE OF THE BACK LEG OR SIDE RAIL) . YOU CAN FASTEN MANUALLY WITH ALLEN KEY PROVIDED .

MOUNTROSE

Thank you for purchasing your new Mountrose product.
If in the unlikely event you experience any problems with assembly. or require any spare screws/fixingsfor this product.

DO NOT RETURN THIS ITEM!!!!!

Please Telephone the Mountrose Customer Helpline

0161 406 5040
or email qc@mountrose.co.uk

THIS DOES NOT AFFECT YOUR STATUTORY RIGHTS