

IMPORTANT, RETAIN FOR FUTURE REFERENCE AND READ CAREFULLY. ASSEMBLY AND OPERATING INSTRUCTIONS FOR DINING TABLE

DESCRIPTION

ITEM NAME: DINING TABLE
ITEM NO: 25201/ 25209

15 mins		Floor Area 1.5 m x 1.5 m  Ceiling Heights 2.0 m
APPROXIMATE ASSEMBLY TIME	2 PERSON ASSEMBLY	REQUIRED ASSEMBLY SPACE

REQUIRED ASSEMBLY TOOLS 



ASSEMBLED DINING TABLE

MOUNTROSE

DESCRIPTION

ITEM NAME: DINING TABLE

ITEM NO: 25201/ 25209

PART LIST		
A	TABLE TOP	1 PC
B	TABLE LEG	4PCS
HARDWARE LIST		
C	FLAT WASHER 	8 PCS
D	HEXAGON NUT 	8 PCS
E	HEXAGON WRENCH 	1 PC
F	SPRING WASHER 	8 PCS

Top Tips before you start!

1 .Please check that all parts are present before you start the assembly of your furniture, as once assembled the furniture is exempt from our home approval.

2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required.

3. For larger items, please ensure that you have sufficient space and people (as indicated on page 1) to assemble our product safely.

4. We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid unnecessary moving of the product.

5. During assembly please take care not to over-tighten any fittings, as this may damage the product .

General for Table

-Please periodically check all fittings and re-tighten as necessary.

-Please do not sit or stand on this item.

-Please do not drag and pull your furniture.

-To clean your items, please use a soft cloth moistened in luke warm soapy and water. Then buff with a dry clean cloth.


MOUNTROSE

DESCRIPTION

ITEM NAME: DINING TABLE

ITEM NO: 25201/ 25209

IMPORTANT NOTE : PLACE ALL WOODEN PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
FIX THE TABLE LEGS(B) TO THE CORNER BLOCK WITH SPRING WASHER(F), FLAT WASHER (C) AND HEX NUT (D). THEN TIGHTEN THE HEX NUT(D) BY USING THE SPANNER (E).



MOUNTROSE

Thank you for purchasing your new Mountrose product.
If in the unlikely event you experience any problems with assembly. or require any spare screws/fixingsfor this product.

DO NOT RETURN THIS ITEM!!!!!

Please Telephone the Mountrose Customer Helpline

0161 406 5040

or email qc@mountrose.co.uk

THIS DOES NOT AFFECT YOUR STATUTORY RIGHTS


IMPORTANT, RETAIN FOR FUTURE REFERENCE AND READ CAREFULLY. ASSEMBLY AND CARE INSTRUCTIONS FOR DINING CHAIRS

DESCRIPTION

ITEM NAME: DINING CHAIRS
ITEM NO: 25202 / 25210

15 mins per chair		Floor Area 1.5 m x 1.5 m  Ceiling Heights 2.0 m
APPROXIMATE ASSEMBLY TIME	1 PERSON ASSEMBLY	REQUIRED ASSEMBLY SPACE

REQUIRED ASSEMBLY TOOLS	



ASSEMBLED DINING CHAIR

MOUNTROSE


MOUNTROSE LIMITED, ALAN HOUSE, ASHTON ROAD, BREDBURY, STOCKPORT. SK6 2QN UNITED KINGDOM

MOUNTROSE

DESCRIPTION

ITEM NAME: DINING CHAIRS

ITEM NO: 25202 / 25210

HARDWARE LIST		
NO	DESCRIPTION	QTY
A	JCBC BOLT 	6 PCS
B	SPRING WASHER 	6 PCS
C	WOOD SCREW 	7 PCS
D	ALLEN KEY 	1 PC
E	WOOD DOWEL 	4 PCS

Top Tips before you start!

1 .Please check that all parts are present before you start the assembly of your furniture, as once assembled the furniture is exempt from our home approval.

2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required.

3. For larger items, please ensure that you have sufficient space and people (as indicated on page 1) to assemble our product safely.

4. We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid unnecessary moving of the product.

5. For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage.

6. During assembly please take care not to over-tighten any fittings, as this may damage the product .

.**General for Chairs**

-Please periodically check all fittings and re-tighten as necessary.

-Please do not stand on this item.

-Please do not drag and pull your furniture.

-To clean your items, please use a soft cloth moistened in luke warm soapy and water. Then buff with a dry clean cloth.


MOUNTROSE

DESCRIPTION


ITEM NAME: DINING CHAIRS

ITEM NO: 25202 / 25210

STEP 1



STEP 2




MOUNTROSE

DESCRIPTION

ITEM NAME: DINING CHAIRS

ITEM NO: 25202 / 25210

STEP 3



MOUNTROSE

Thank you for purchasing your new Mountrose product.
If in the unlikely event you experience any problems with assembly. or require any spare screws/fixingsfor this product.

DO NOT RETURN THIS ITEM!!!!!

Please Telephone the Mountrose Customer Helpline

0161 406 5040

or email qc@mountrose.co.uk

THIS DOES NOT AFFECT YOUR STATUTORY RIGHTS