
CARE AND MAINTENANCE
INSTRUCTIONS FOR DRAWER DRESSER


DESCRIPTION

ITEM NAME : 6 DRAWER DRESSER
ITEM NO : 13288




Note:

1. Remove the handles from the back of drawer as shown.



2. Fasten the Handles back to the front of the drawer.



MOUNTROSE

DESCRIPTION

ITEM NAME : 6 DRAWER DRESSER
ITEM NO : 13288

Care and Maintenance of your Furniture.

- Please periodically check all fittings and re-tighten as necessary.
- To clean your item, please use a damp cloth and wipe clean.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.
- Please do not drag and pull your furniture.

MOUNTROSE

Thank you for purchasing your new Mountrose product.
If in the unlikely event you experience any problems with assembly or require any spare screws/fixings for this product.

DO NOT RETURN THIS ITEM!!!!!

Please Telephone the Mountrose Customer Helpline

0161 406 5040
or email qc@mountrose.co.uk

THIS DOES NOT AFFECT YOUR STATUTORY RIGHTS