

## 1444139



- ⇒ Water Resistant
- ⇒ Daily Alarm
- $\Rightarrow$  Stopwatch
- ⇒ 7 Year Battery
  - ⇒ Microlight



Model variations may differ in appearance from the example above.

Stop Watch	1/100-sec accuracy.	Press button A until display shows stopwatch function (ST). Use following to meas-
	!	ure times with the Stopwatch.
		A signal confirms start/stop operation. (Working range) The stopwatch display is limited to 59 minutes 59.99 seconds, for longer times reset and start again.
		(a) Net time measurement  (b) (a) Time loss  (c) Time loss  (c) Start  (d) Net time measurement  (e) Time loss  (f) Re-start  (f) Reset
		(b) Split time measurement  Split Split Split release Stop Reset (c) 1st-2nd place times
		Start Split The first runner finishes. Stop Split release Record the time of the second time of the first runner. runner.
Alarm	Allows you to specify the hour, minutes, day and month of the alarm.	In Alarm Mode, Press B to set hours and minutes. Press A to advance the alarm setting by each hour. Press B to set minute digits, each Press of A advances the
		alarm setting by 1 minute. Press B again to exit setting screen once hour and mi-
		nute digits have been set. *If button C is pressed, the watch reverts to the regular
		timekeeping mode. (Quick digit advance) when button A is pressed for more than
		seconds, the digit advances quickly. When released, digit advance will stop.
Water Resistant	Suitable to resist light splashing.	Water Resistant classification DIN 8310 $/$ ISO 2281 is only resistant to minor splashing.
7 Year Battery	Battery power lasts up to approximately five- years without changing.	CASIO's advanced technology allows extended battery life for up to seven-years .  All timekeeping modes and functions of the watch can be used continuously for u to five-years without a battery change.