
Slim 3 Door Media Storage

Assembly Instructions - Please keep for future reference | 146/3646



Dimensions
Width - 60cm
Depth - 20cm
Height - 90cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**

Issue 1 - 24/09/13

Safety and Care Advice

Important–Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 1 and 2.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to lay out the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

Care and Maintenance

• Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.


•This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 0845 640 0800**


Please check you have all the panels listed below




1 Divider Panel X 3
27.5(w)cm x 20(d)cm




2 Shelf Panel X 1
57(w)cm x 20(d)cm




3 Shelf Panel X 1
57(w)cm x 20(d)cm




4 Door X 1
27(w)cm x 27(d)cm




5 Side Panel X 1
85.5(w)cm x 20(d)cm




6 Side Panel X 1
85.5(w)cm x 20(d)cm




7 Door X 2
27(w)cm x 27(d)cm




8 Base Panel X 1
60(w)cm x 20(d)cm



9 Top Panel X 1
60(w)cm x 20(d)cm



10 Back Panel X 1
88.4(w)cm x 29.8(d)cm













11 Back Panel X 1
88.4(w)cm x 29.8(d)cm

Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 0845 640 0800**

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


A  50mm Wooden dowel x 4	B  30mm Wooden dowel x 8	C  Magnetic catch x 3	D  Catch plate x 3
E  12mm Screw x12	F  Hinge Pins x 6	G  20 mm Screw x 4	H  45mm Screw x 8
I  35mm Male camlock x 4	J  female camlock x 4	K  Plastic Foot x 4	L  17mm Nail x 29
M  12mm Screw x1	N  35mm Screw x 1	O  30mm Wall Plug	P  130mm Wall Strap

Tools required


Phillips Screwdriver (medium & large)


Hammer (medium)


Ruler – Use this ruler to help correctly identify the screws



Assembly Instruction

Step 1

Push 4 x 50mm wooden dowel A through shelf panels 2 and 3. Connect divider panel 1 x 3 to wooden dowells as shown.




Step 2

Attach magnetic catch C x 2 in position shown using 4 x 12mm screws E

Assembly Instructions


Step 3

Fit catch plate D to door panel 4 and 7 x 2 using 6 x 12mm screws E



Step 4

Insert 8 x B 30mm Wooden dowel into shelf panels 2 and 3 as shown. Use a hammer to help with this.




Step 5

Using 2 x hinge pins F connect door panel 4 to shelf panels 2 and 3

Step 6


Connect panels 5 and 6 using 4 x 45mm screws H . Line up 4 x wooden dowels with holes.



Assembly Instructions


Step 7

Attach 4 x plastic foot (K) to base panel [8] using 4 x 20mm screw (G)



Step 8


Take 2 x hinge pins (F) and insert them into door panel [7] as shown. Connect door [7] by attaching base panel [8] using 4 x 45mm screws (H)



Step 9


Attach magnetic catch (C) to Top panel [9] using 2 x 12mm screw (E)

Insert 4 x Male camlocks (I) into top panel [9] using Phillips screwdriver.



Step 10

Take 2 x hinge pins (F) and insert them into door panel [7] as shown. Connect door [7] by attaching top panel [9] using 4 x Male camlocks from step 9. Fix together using 4 x Female camlocks (J).
Use Phillips screwdriver to tighten as shown.




Assembly Instructions

Step 11


Using a hammer, fix back panels 10 and 11 using 29 x Nails L as shown.

Attach 130mm Wall strap P using Screw 1 x 12mm screw M



Step 12

Fix unit to the wall using 30mm Wall plug O and 35mm screw N



Assembly Compete