
Rattan 4 Seater Set - Table

Assembly Instructions - Please keep for future reference

146/6904



Dimensions

Width - 80cm
Depth - 45cm
Height - 38cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**
Retailer: Argos
Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW

Issue 1 - 13/09/13

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- This product is manufactured from toughened safety glass. In the unlikely event that the glass fails it will break into a large number of small fragments that may be spread over a wide area. This is a feature of toughened glass, designed to remove the risk of injury from glass breaking into large shards.
- If the glass is chipped or broken, stop using the product and consult the manufacturer or supplier.
- Check you have all the components and tools listed on page 2.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the parts during assembly, this could cause damage.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Dispose of all packing carefully and responsibly.
- Do not sit or stand on this table.
- Do not place very hot or very cold items on the glass.
- ***Warning:*** The unit weighs approximately 7.6kgs.

Please lift with care.

Care and maintenance

- Wash glass with mild soap and water, rinse thoroughly, and dry glass completely.
- We recommend the use of furniture covers when not in use.
- Do not use the glass as chopping surface. Do not strike the glass with hard or pointed items.
- In order to prolong the life and your table, we recommend it be stored in a dry and protected area during off season periods.
- Do not use washing powders or any abrasive substances which may scratch the surface.







1

Components - Parts & Fittings

If you have damaged or missing components, call the **Customer Helpine: 0845 640 08 00**

Please check you have all the parts & fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


1  Table End x 2	2  Support bar x 1	3  Glass x 1
A  M6X15mm Screw x 6	B  Washer x 6	C  Screw Cap x 6


Tools Provided



E Hexkey x 1

Ruler - Use this ruler to help correctly identify the screws






Assembly Instructions


Step 1

Use screws Ⓐ and washers Ⓑ to fix the support bar 2 to the table ends 1.

Fix screw cap Ⓒ to screws Ⓐ


Important:
Do not fully tighten all screws until assembly is complete.





Step 2


Fit the glass 3 onto the two table ends 1 carefully.



Assembly Instructions

Step 3

Assembly is complete




If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**
Retailer: Argos
Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW

Rattan 4 Seater Set - Bench

Assembly Instructions - Please keep for future reference

146/6904



Dimensions

Width - 113cm
Depth - 71cm
Height - 76cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**
Retailer: Argos
Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW

Issue 1 - 13/09/13

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product during assembly, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the bench or your floor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers for inserting screws , as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

• Maximum safe seated weight: 200kgs.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

• Make sure each screw matches the corresponding figure to ensure correct assembly.

• From time to time check that there are no loose screws on this chair.

• Do not fully tighten all screws until assembly is complete.









• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Parts & Fittings

If you have damaged or missing components, call the **Customer Helpine: 0845 640 08 00**

Please check you have all the parts & fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


1  Armrest x 1	2  Armrest x 1	3  Backrest x 1
4  Seat x 1	5  Cushion x 1	A  M6X55mm Screw x 2
B  M6X35mm Screw x 6	C  M6X25mm Screw x 4	D  Washer x 12
E  Screw caps x 12		


Tools provided



F Hexkey x 1

Ruler - Use this ruler to help correctly identify the screws






Assembly Instructions

Step 1


Use long screws Ⓐ and Ⓑ and washers Ⓓ to fix the armrest 1 and 2 to the backrest 3 .



Important:
Do not fully tighten all screws until assembly is complete.

Step 2

Use screws Ⓑ and Ⓒ washers Ⓓ to fix the armrest 1 and 2 to the seat 4




Tighten all the screws and cover all the screws Ⓐ and Ⓑ and Ⓒ with cap Ⓔ.

Assembly Instructions


Step 3

Put the seat cushion 5 onto the chair.



Step 4

Assembly is complete




If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**
Retailer: Argos
Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW

Rattan 4 Seater set - Chair

Assembly Instructions - Please keep for future reference

146/6904



Dimensions

Width - 61cm
Depth - 71cm
Height - 76cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**
Retailer: Argos
Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW

Issue 1 - 13/09/13

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product during assembly, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the chair or your floor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers for inserting screws , as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

• Maximum safe seated weight: 200kgs.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

• Make sure each screw matches the corresponding figure to ensure correct assembly.

• From time to time check that there are no loose screws on this chair.

• Do not fully tighten all screws until assembly is complete.









• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Parts & Fittings

If you have damaged or missing components, call the **Customer Helpine: 0845 640 0800**

Please check you have all the parts & fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


1  Armrest x 1	**2**  Armrest x 1	**3**  Backrest x 1
4  Seat x 1	**5**  Cushion x 1	**A**  M6X55mm Screw x 2
B  M6X35mm Screw x 4	**C**  M6X25mm Screw x 4	**D**  Washer x 10
E  Screw caps x 10		


Tools provided



F Hexkey x 1

Ruler - Use this ruler to help correctly identify the screws





Assembly Instructions

Step 1


Use long screws Ⓐ and Ⓑ and washers Ⓓ to fix the armrest 1 and 2 to the backrest 3 .

Important:
Do not fully tighten all screws until assembly is complete.

Step 2

Use screws Ⓑ and Ⓒ washers Ⓓ to fix the armrest 1 and 2 to the seat 4


Tighten all the screws and cover all the screws Ⓐ and Ⓑ and Ⓒ with cap Ⓔ.



Assembly Instructions


Step 3

Put the seat cushion 5 onto the chair.



Step 4

Assembly is complete



If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**
Retailer: Argos
Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW