
OI WOW Eclipse Mirror Wall Cabinet

Assembly Instructions – Please keep for future reference | 147/7584



Dimensions

Width - 40cm
Depth - 15cm
Height - 50cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800

Issue 1 - 10/10/13

Safety and care advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the panels, this could cause damage.

• Assemble the unit as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• ***Note:*** Only apply the glue once you are sure of the assembly.

• The wall plugs supplied are suitable for solid walls only. It is important that the correct type of fixing is used for your wall, seek professional advice if in doubt.

• Parts of the assembly will be easier with 2 people.

• If using power tools, please follow the safety instructions supplied with the tools.



• We do not recommend the use of power drill/ drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.

• ***Warning:*** Before drilling, check the wall for hidden pipes and cables.

• Dispose of all packaging carefully and responsibly.

Glue safety - Take care when using glue, please follow the advice below

Skin contact: Remove contamination by washing with soap and water. This procedure should also be followed prior to eating and drinking.

Eye contact: Rinse immediately with clean water for 15 minutes and seek medical advice.

If swallowed: Seek medical advice immediately. If possible show product information or label to the medical advisor.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: if required the next page can be cut out and used as a reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the Customer Helpline:08456 400800


Please check you have all the panels listed below



1 Left side panel



2 Right side panel



3 Back panel




4 Top panel




5 Bottom panel



6 Adjustable shelf



7 Door panel










8 Corner piece x 4


Components - Fittings


Please check you have all the fittings listed below

Note:The quantities below are the correct amount to complete the assembly .In some cases more fittings may be supplied than are required.


A  Φ4 x 12mm Screw x 14	B  Locking Pin x 8	C  Locking Nut x 8
D  Hanger Bracket x 2	E  Φ3 x 12mm Screw x 10	F  Metal Support x 4
G  Straight hinge x 2	H  35mm Screw x 2	I  Wall plug(for solid walls only) x 2
J  Wooden Dowel x 16		

Tools required


Phillips screwdriver (medium & large)



Flatblade screwdriver (medium)

6mm Suitable drill bit (for use with wall plug)



Hammer Drill (Only for dril hole on the wall)


Small hammer


Ruler/tape measure


Eye protection (when using a hammer or glue)

Ruler –Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1

Assembling side panel and door panel

a:
Loosen straight hinge screw as shown to separate it into G1 & G2 .

b:
Use Φ4 x 12mm screws A to fix straight hinge G1 onto door panel 7 .


c:
Screw locking pins B into corner pieces 8 as shown.

d:
Insert wooden dowels J into left & right side panel 1 2 .


Attach corner pieces to left & right side panel and insert locking nuts C into side panel,tighten locking nuts to secure.

Use Φ4 x 12mm screw A to attach straight hinge G2 onto right side panel 2 .


a:




b:




c:







Tips: not make the hinge in wrong way

d:








Assembly Instructions

Step 2

Assembling the unit

Insert wooden dowels J into top panel 4 and bottom panel 5.

Carefully attach side panels 1 2 to top panel and bottom panel, insert locking nuts C into top and bottom panel,tighten locking nuts to secure.




Step 3

Assembling back panel

Use Φ3 x 12mm screw E to fix back panel 3 to the unit,please make sure the bracket hole on back panel match top panel 4 as shown.

Use Φ4 x 12mm screw A to fix hanger bracket D on top panel 4 .




Step 4

Assembling door panel

NOTE:It would be useful to ask someone to help you at this stage.

Attach door panel 7 to the unit by fixing G1 onto G2 as shown ,adjust the door left or right ,up or down ,in or out if needed .



Assembly Instructions

Step 5

Fixing to the wall

NOTE:It would be useful to ask someone to help you at this stage.

Warning!
Please make sure the unit is secured to the wall before use.


Please refer to next page the Guide for Wall Mounting & Fixings.

a:
Insert metal support Ⓕ into side panels,carefully put shelf [6] on it.


b:
Use screw Ⓗ and wall plug Ⓘ to fix the unit on the wall via wall bracket Ⓓ .

After above assembly, please double check and make sure all screws are tigthened before us.

a:



b:



NOTE:If you have damaged or missing components, call the Customer Helpline:08456 400800
Argos LTD,489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.

Important: **When drilling into walls always check that there are no hidden wires or pipes etc.**

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

1: General rule: ⚠ Always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.


4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 **"General Purpose" wall plug**




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 **"Plasterboard" wall plug**




For use when attaching light loads on to plasterboard partitions.

No.3 **"Cavity Fixing" wall plug**




For use with plasterboard partitions or hollow wooden doors.

No.4 **"Cavity Fixing-Heavy Duty" wall plug**




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 **"Hammer Fixing" wall plug**



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 **"Shield Anchor" wall plug Heavy loads**



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

⚠ Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.

SAFETY WARNING INFORMATION

Keep these instructions for future use:

WARNINGS

*Do not place very hot or very cold items against or in close proximity to glass surface unless an adequately thick insulating material is used to prevent such items from coming into contact with the glass.

*Do not strike the glass with hard or pointed items.

* Do not sit or stand upon horizontal glass surfaces.
*When cleaning glass panels or mirrors use a damp or leather with washing up liquid or soft soap if necessary do not use washing powders or any other substance containing abrasive since these substances scratch glass.
*It is essentail that this unit is fixed to a wall with the fixings provided.

BS7449 : 1991

Catalogue Number: 147/7584(D)

Manufacture date: Oct 22th, 2013

Retailer: **Argos**

Retailer address: **489-499 Avebury Boulevard**
Saxon Gate West
Central Milton Keynes
Bucks, MK9 2NW

This unit contains glass of a nominal thickness of 3 mm, which is not required to be classified to BS6206 Class C.

If a glass is chipped or broken replace with glass of the type described on this label. Consult the manufacturer, retailer, or agent with regard to obtaining a manufacturing specification and shape for replacement glass quoting the model number, and batch number or date of manufacture.