
Dining Chair

Assembly Instructions - Please keep for future reference 1524853/1597048



Dimensions - Chairs(x2)

Width - 42cm

Depth - 44.7cm

Height - 90cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 0845 640 0800

Issue 1 - 16/04/10

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product during assembly, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers ***for inserting screws,*** as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

Care and maintenance


• Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Panels


Please check you have all the panels listed below




1 Back x 2
(35.9 x 90cm)



2 Front frame x 2
(39.8 x 42.5cm)




3 Left & right side apron x 2
(32.6 x 6cm)



4 Left & right side rail x 2
(34.8 x 2.2cm)

5 Bottom middle rail x 2
(32.2 x 2.2cm)






6 Seat x 2
(42 x 41cm)

Components - Fittings


If you have damaged or missing components, call theCustomer Helpline: 0845 640 0800

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  M6x80mm Bolt x 8	B  Ø10x20mm nut x 8	C  16mm Nut x 8
D  Fly washer x 8	E  30mm screw x 12	F  40mm Screw x 8
G  80mm wrench x 1	H  30mm wood dowel x 28	

Tools required



Phillips screwdriver (medium)



Ruler/tape measure

Ruler - Use this ruler to help correctly identify the screws


0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170


Assembly Instructions

Step 1

Wood dowels

Insert wood dowels (H) into left &right side apron [3] left &right side rail [4] and bottom middle rail [5].






Assembly Instructions


Step 2

Fitting bolts

a: Insert nut B into back 1 screw bolts A into nut B.



b: Insert nut B into front frame 2 screw bolts A into nut B.




Assembly Instructions


Step 3

Attaching side apron

a: Attach left side apron 3 to back 1.




b: Insert bolt A into fly washer D Screw nut C to bolt A using hand .



Continued on next page.

Step 3 - continued


C: Attach right side apron [3] to the back [1]
Repeat step b on page 6.



Step 4

Attach side rail

Attach left & right side rails [4] to zhe bottom middle rail [5] .




Assembly Instructions

Step 5

Attach side rail


Attach left & right side rail [4] and bottom middle rail [5] to back [1] .



Step 6

Attach front frame

a: Attach front frame [2] to the aprons [3] and side rails [4] .




Assembly Instructions


Step 7

b: Insert bolts (A) into fly washers (D) to fix aprons to front frames.

Note:Tighten all the bolts.

b:






Step 8

Fitting screw

Fix side rails 4 and bottom middle rail 5 using screws (E).



Step 9


Fitting screws

Attach seat 6 to chair frame using screws F.

Repeat with remaining chair.

Tighten all the screws for chairs.

Assembly is complete.



If you need help or have damaged or missing parts, call the Customer Helpline: 0845 640 0800
Argos Ltd MK9 2NW