
Akari - Pair of Chairs

Assembly Instructions - Please keep for future reference

143/9357

144/8520

SCHREIBER



Dimensions

Width - 45.2cm

Depth - 55.75cm

Height - 88cm

Important - Please read these instructions fully before starting assembly.

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**

Safety and Care Advice

Important - Please read these instructions fully before starting assembly.

• Check you have all the components and tools listed on page 2.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft flat / firm surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/ drivers ***for inserting screws,*** as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

• Maximum user weight: 110kg.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.


• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800**


Please check you have all the panels listed below



1 Back leg frame x 2
(45 x 88cm)



2 Front leg frame x 2
(44 x 44cm)



3 Seat pad x 2
(45.2 x 44.2cm)



4 Left apron x 2
(40.1 x 6.4cm)






5 Right apron x 2
(40.1 x 6.4cm)


Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A 	B 	C 
48.5mm Steel dowel x 8	Grub screw x 8	Seat bracket x 4
D 	E 	F 
15mm Hex head bolt x 4	M4 Allen key x 1	M5 Allen key x 1

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1

Fitting dowels

a: Screw 2 steel dowels (A) into the inset fittings that are located on back leg frame [1] as shown.

Note: Ensure the direction of the holes on fittings are facing correctly as per diagram. **Do not over tighten.**




Step 2

Fitting dowels

a: Screw 2 steel dowels (A) into the inset fittings that are located on front leg frame [2] as shown.

Note: Ensure the direction of the holes on fittings are facing correctly as per diagram. **Do not over tighten.**



Assembly Instructions

Step 3

Attaching aprons


Position aprons 4 and 5 onto back leg frame 1 as shown.

Note: Ensure steel dowels and wooden dowels are aligned correctly with mating holes to avoid damage.

Ensure end of aprons are flush with back leg frame 1.

Insert 2 grub screws B into aprons 4 and 5 as shown.

Use allen key F to turn grub screws B clockwise to fix.



Step 4

Attaching front leg frame


Position front leg frame 2 onto aprons 4 and 5 as shown.

Note: Ensure steel dowels and wooden dowels are aligned correctly with mating holes to avoid damage.

Ensure end of aprons are flush with front leg frame 2.

Insert 2 grub screws B into aprons 4 and 5 as shown.

Use allen key F to turn grub screws B clockwise to fix.



Assembly Instructions

Step 5


Placing seat pad.

a: Place seat pad 3 on a flat, stable, clean and soft surface as shown.


b: Lower the constructed chair frame onto seat pad 3 as shown.

Note: Ensure wooden locator block is inside front leg frame 2 as shown.

a:



b:



Assembly Instructions

Step 6

Fixing seat pad.

a: Insert 2 seat brackets C into the slots on aprons 4 and 5 as shown.


Note: Align holes on seat brackets C with holes on seat pad 3.

b: Insert 2 bolts D into the holes of seat brackets C and the holes of mating seat pad 3 as shown.

Use allen key E to turn bolts D clockwise to fix.

Repeat complete process for second chair.


Assembly is complete.



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**

WILTSHIRE OAK 150 TABLE

Assembly Instructions - Please keep for future reference | 145/4806



Dimensions

Width - 160cm
Depth - 90cm
Height - 75cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**

Issue 1 - 10/28/2013

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Pls do not stand or put weight on the product during assembly, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers **for inserting screws,** as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.


• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 0845 640 0800**

Please check you have all the fittings listed below




1 Top Panel x 1



2 Leg x 4



3 Center Stretcher x 1



4 Side Stretcher x 2

Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  Spring Washer x 14 (M8)	**B**  Large Flat Washer x 8 (M8, Ø20mm)	**C**  Wrench x 1 (M8)
D  Bolt x 14 (M8 x 70mm)	**E**  Metal Pad x 6 (28 x 14mm)	**F**  Nut x 14 (M8)
G  Wood dowel x 6 (Ø8 x 40mm)	**H**  Small Flat Washer x 6 (M8, Ø16mm)	

Tools required

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1

Attaching the side stretchers

Screw bolts (D) into legs [2] as shown. Insert wood dowels (G) into legs [2] as shown.

Attach the side stretcher [4] between the two legs [2] as shown.



Step 2


Installing the side stretchers

Install the side stretcher [4] into leg [2] , with the metal pad (E) , flat washer (H) , spring washer (A) and nut (F) as shown using wrench (C) .

Attaching the center stretcher

Screw bolts (D) into side stretcher [4]. Insert wood dowel (G) into side stretcher [4] as shown.

Attaching center stretcher [3] between the side stretchers [4] .




Assembly Instructions

Step 3

Installing the center stretcher

Install center stretcher 3 into side stretchers 4 with metal pad E, flat washer H, spring washer A and nut F as shown, using wrench C.




Step 4

Installing the legs

Attach legs 2 downwards onto the top panel 1 as shown.

Assemble legs 2 with bolt D, flat washer B, spring washer A and nut F as shown using wrench C.

Assembly is completed.



If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**
Argos Ltd MK9 2NW