WESTBEACH RAIDER 2.0 STUNT SCOOTER

Assembly & User Instructions - Please keep for future reference | 214/7631

WESTBEACH



Important – Please read these instructions fully before assembly or using

These instructions contain important information which will help you get the best from your equipment and ensure safe and correct assembly, use and maintenance.

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 6000 464**

Contents

Safety Information	**3**
Components	**4**
Key Features	**5**
Assembly Instructions	**6**
Instructions for Use	**7**



Safety Information

WESTBEACH

Important – Please read fully before assembly or using

To reduce the risk of serious injury, read the entire manual before you assemble the Westbeach scooter
In particular, note the following safety precautions:

⚠ Warning

Warning! not suitable for children under 8 years of age due to small parts - choking hazard.

- Adult assembly required.
- This product is for children aged 8 years +.
- Maximum total weight 100 kg.
- Always wear a helmet, wrist, knee and elbow pads when riding your scooter and keep the helmet chinstrap securely buckled.
- Always wear closed shoes when riding your scooter.
- Ride on smooth, paved surfaces away from motor vehicles and other road users.
- Avoid sharp bumps, drainage grates, and sudden surface changes, that might cause the scooter to suddenly stop.
- Avoid streets and surfaces with water, sand, gravel, dirt, leaves and other debris. wet weather impairs traction, braking and visibility.
- Do not ride at night.
- Brake will get hot from continuous use, do not touch after braking.
- Avoid excessive speed associated with downhill rides.
- Watch out for pedestrians.
- Check and secure all fasteners before every ride.
- The scooter is designed for one rider at a time.
- Do not use the scooter if it has any damage.
- Replace worn or broken parts immediately.
- Read the information supplied by the manufacturer.
- Do not ride scooter with one hand. Both hands should be on both handles at all times.
- Adult supervision is required during the initial assembly and maintenance procedures.
- Injury may occur if the precautions above are not observed and followed.
- Please check the limitation of use according to regulations of road safety.
- Important! The self-locking bolts and other self-locking parts may lose their efficiency.

Care

- Keep the product in a dry place. if the scooter gets wet, dry metal parts to prevent rusting.
- Clean with damp cloth. do not use solvents or bleaches for cleaning.
- This scooter is equipped with precision bearings which were filled with lubricant at high pressure during manufacturing. For this reason, the wheels can only run easily and quickly when there is a load on the scooter. The bearings are maintenance free.
  The wheels should be replaced when they get worn.
- For your own safety, please use original spare parts only. Do not make any structural changes.
- No modification other than to the manufacturer's instruction shall be made.
- Please rotate the bearings and wheels to check if they are rolling smoothly.
- Clean regularly paying attention to the moving parts, clearing them of grit and dirt so they move freely.
- Ensure parts specifications are correct with the dealers if some parts need to be replaced.
- Ensure the front fork, wheels and handlebar are fixed tightly. You can use a wrench to tighten the locking nut. Use firm pressure but don’t over tighten.


Trick / Stunt Riding and Warranty

If you ride your scooter in a manner that places large forces and stresses on the product, the scooter will not be covered under warranty.
The scooter is designed to meet and exceed applicable safety standards, however the forces exerted through extreme riding will cause premature wear to all parts.


Components

Please check you have all the parts listed below

1. HANDLE BAR X 1




2. SCOOTER BODY X 1



3. CLAMP X 1



4. STUNT PEG X 2




5. BOLT SET X 4




6. ALLEN KEY X 2



7. STUNT PEG BOLT SET X 2





If you have damaged or missing components, call the
Customer Helpline: 0845 6000 464


Assembly Instructions


Assembly

A) Place the clamp over the vertical tube of the handle bar, then insert the handle bar onto the fork stem.

B) Push the handlebar with clamp onto the fork stem until it’s up against the headset.

C) Tighten the bolt set one by one from bottom to top. Repeat the process until all bolts are securely tightened.






Instructions for Use


WESTBEACH

- Grip the handlebars with your hands, place one foot on the deck (board) and the other foot on the ground.
- Pay attention to your surroundings and make sure that your riding area is clear.
- Kick backwards with your foot beside the scooter to give you motion.
- Repeat this kicking action in order to stay in motion.
- To stop or slow down, place your kicking foot on the brake pedal above the rear wheel or put your kicking foot on the ground.
- Do not over-steer as this could cause you to fall off the scooter.




Install Stunt Peg

HOW TO INSTALL
FRONT STUNT PEG AND STUNT PEG AXLE



HOW TO INSTALL
REAR STUNT PEG AND STUNT PEG AXLE



Guarantee

Product Guarantee

This product is guaranteed against manufacturing defects for a period of



Year

This product is guaranteed for twelve months from the date of original purchase. Any defect that arises due to faulty materials or workmanship will either be replaced, refunded or repaired free of charge where possible during this period by the dealer from whom you purchased the unit.

The guarantee is subject to the following provisions:

- The guarantee does not cover accidental damage, misuse, cabinet parts, knobs or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in this manual.
- It must be used solely for domestic purpose.
- The guarantee will be rendered in invalided if the product is re-sold or has been damaged by inexpert repairs.
- Specifications are subject to change without notice.
- The manufacture disclaims any liability for the incidental or consequential damages.
- The guarantee is in addition to, and does not diminish your statutory or legal rights.
- In the event of a problem with the products with in the guarantee period call the **Customer Helpline: 08456 000 464.**

Guarantor: Argos Ltd
489-499 Avebury Boulevard
Central Milton Keynes
MK9 2NW