
Baby Amelie-Dressing table with stool

Assembly Instructions - **Please keep for future reference** 226/1380



Dimensions

Width - 100 cm
Depth - 50 cm
Height - 117 cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400 800**

Issue 1 - 06/05/14

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

· Check you have all the components and tools listed on pages 2 and 3.

· Remove all fittings from the plastic bags and separate them into their groups.

· Keep children and animals away from the work area, small parts could choke if swallowed.


· Make sure you have enough space to layout the parts before starting.

· Do not stand or put weight on the product, this could cause damage.

· This product has been produced from natural timber; you may notice some variation in the grain and colour of different component parts which is normal for furniture produced using natural wood and is not the result of any manufacturing fault.

· Assemble the item as close to its final position (in the same room) as possible.

· Assemble on a soft level surface to avoid damaging the unit or your floor.



We do not recommend the use of power drill/drivers ***for inserting screws***, as this could damage the unit. Only use hand screwdrivers.

· Parts of the assembly will be easier with 2 people.

· Dispose of all packaging carefully and responsibly.

Care and maintenance

· Use an appropriate furniture polish for natural wood furniture and a dry cloth to clean the product.

· Avoid placing the furniture in direct sunlight as this will cause the timber to prematurely age.


· From time to time check that there are no loose screws on this unit.

· This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: **if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.**

Components - Panels


Please check you have all the panels listed below




1 Top panel x 1 (100x50 cm)




2 Top front rail x 1 (87x6.8 cm)




3 Top back rail x 1 (87x6.8 cm)




4 Side rail x 2 (38.4x6.8 cm)




5 Dressing foot x 4 (61x4 cm)




6 Stool foot x 4 (41x4 cm)




7 Small top panel x 1 (67.5x31 cm)




8 Left side panel x 1 (29x10.9 cm)



9 Right side panel x 1 (29x10.9 cm)




10 Middle panel x 1 (27.5x9.4 cm)



11 Front rail x 1 (60.5x5 cm)




12 Back rail x 1 (60.5x5 cm)




13 Mirror frame x 1 (39x46 cm)




14 Top frame x 1 (50.5x4 cm)




15 Support rail x 2 (32.8x3 cm)



16 Drawer front x 2 (29.1x9 cm)




17 Drawer left side x 2 (25x5.5 cm)




18 Drawer right side x 2 (25x5.5 cm)




19 Drawer back x 2 (24x5 cm)



20 Drawer bottom x 2 (25.4x25 cm)




21 Back panel x 1 (62.3x11.8 cm)



22 Seat panel x 1 (38x33 cm)



23 Stool front rail x 2 (27x6.8 cm)



24 Stool side rail x 2 (22x6.8 cm)



25 Corner x 8 (10.2x6 cm)















Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 08456 400 800**

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  30 mm Wooden dowel x 36	**B**  30 mm Screw x 73	**C**  12 mm Screw x 13
D  12 mm Screw x 8	**E**  Right runner x 2	**F**  Left runner x 2
G  Metal dowel x 10	**H**  Locking nut x 10	**I**  Nail x 12
J  Knob x 2	**K**  20 mm Bolt x 2	**L**  60 mm Bolt x 16
M  Wall strap x 1	**N**  Washer x 1	**O**  Allen key x 1

Tools required




Phillips screwdriver (medium & large)



Ruler/tape measure




Small hammer



Eye protection (when using a hammer or glue)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


Step 1

Fitting Wooden Dowels:
Insert dowels (A) into holes in the indicated parts.

Fitting metal dowel
Screw metal dowel (G) into small top panel 7 and fronts drawer 16.

Note: Insert metal dowels as far as shown.


Do not over tighten.



Step 2

Fix runners (E) and (F) into the pre-drilled holes on left side 8, right side 9 and middle panel 10 using screws (C) as shown.


Make sure runners are positioned as shown.



Step 3

Attach corner 25 to top rail 2 and 3 using screws (B).

Make sure corner 25 in flush to the edge of the rail as shown.




Assembly Instructions

Step 4

Attach side rails 4 through corner 25 using screws B.

Atach top frame 14 to pre drilled holes in mirror frame 13 using screws B.


Make sure corners 25 are is flush to edge of the rail as shown.



Step 5

Insert dowels A into holes in the indicated parts.


Fix the support frames rail 15 to mirror frame 13 using screws B.



Assembly Instructions


Step 6

Attach side rails 4 and top rails 2 and 3 to top panel 1 using screws B.



Step 7

Fix dressing feet 5 to corners 25 using bolt L and allen key O, through the pre-drilled holes, as shown.



Assembly Instructions


Step 8


Carefully lay down the top on a clean and soft surface to avoid damaging the product.

Insert the left side panel 8 and middle panel 10 to the top panel 7.

Insert 4 locking nuts (H) into left side panel 8 and middle panel 10 where shown.


Use a screwdriver to turn locking nuts (H) clockwise to lock.
Do not over tighten.





Step 9

Attach front rail 11 and back rail 12 to side panel 8 and middle panel 10 using screws (B).




Step 10


a) Insert right side panel 9 to the top panel 7 and rails 11 and 12 as shown.
Insert 2 locking nuts (H) into right side panel 9, where shown.

Use a screwdriver to turn locking nuts (H) clockwise to lock.

Do not over tighten.

b) Attach front rail 11 and back rail 12 to side panel 9 using screws (B).






Assembly Instructions

Step 11


Carefully turn the cabinet upright.
Fix back panels **21** within rebates using nails ❶.

Important: Cabinet **MUST** be 'square' when back is attached.



Step 12

Insert dowels Ⓐ in to holes a top panel **1**.
Place the cabinet on the table through the dowels as shown.



Assembly Instructions

Step 13

Drawer assembly

A) Attach drawer sides 18 and 17 to the drawer front 16. Insert 2 locking nuts H into left and right side drawer 17 and 18, where shown.

Use a screwdriver to turn locking nuts H clockwise to lock.

Do not over tighten.


B) Slide drawer bottom 20 in to slots on drawer sides 17 and 18.

Make sure finished side face inside the drawer.

C) Attach drawer back 19 to drawer sides 17 and 18 using screws B.


D) Fix knob J using bolts K.

E) Fix runner E and F using screws D as shown.



Step 14

Fix the supports frame 15 in the pre drilled holes in top panel 1 and 7 using screw B.




Assembly Instructions

Step 15

Insert drawers


Hook the wheels of the runner on the back of the drawers over the wheels of the runners on the left and right sides, then hold the drawers level and slide backwards into position.



Step 16

Adjusting drawers

Loosen the screws in the runners, adjust the drawers to suit and once drawers are aligned retighten and insert 1 screw Ⓒ into fifth hole of the runners Ⓔ and Ⓕ.




Assembly Instructions

Step 17

Adjusting drawers

To move drawers left or right: loosen the screws in the runners, adjust the drawers to suit and once drawers are aligned retighten.



Step 18

Fixing wall strap


Fix strap Ⓜ to top of furniture using washer Ⓝ and screw Ⓒ. With help, move furniture into position.

Lift with care

Mark fixing hole on wall and remove furniture. Drill hole and insert wall plug (not supplied).

Warning:
Before drilling check wall hidden pipes and cables.


Note: wall plugs not supplied. The type of fixing must be used for your wall, seek professional advice if in doubt.



Assembly Instructions


Step 19

a) Attach corner 25 to top rails 23 using screws B.



Step 20


Attach side rails 24 through corner 25 using screws B.



Make sure corners are in flush to the edge of the rail as shown.

Step 21


Insert dowels A into holes in the indicated parts.



Assembly Instructions


Step 22

Attach side rails 23 and top rails 24 to seat panel 22 using screws B.



Step 23

Fix stool feet 6 to corners 25 using bolt L, an allen key O, through the pre-drilled holes, as shown.



Assembly is complete.

A Guide to -**Wall Mounting & Fixings**

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fxings is the responsibility of the installer.

Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualifed tradesperson if you are unsure.

Hints:

1: General rule: Always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.


4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well ftted and are a tight ft in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 **"General Pourpose" wall plug**




Generally aerated blocks should not be used to support heavy loads, use a specialist ftting in this case. For light loads, general purpose wall plugs can be used.

No.2 **"Plasterboard" wall plug**




For use when attaching light loads on to plasterboard partitions.

No.3 **"Cavity Fixing" wall plug**




For use with plasterboard partitions or hollow wooden doors.

No.4 **"Cavity Fixing-Heavy Duty" wall plug**




For use when ftting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 **"Hammer Fixing" wall plug**



For use with walls stuck with plasterboard. The hammer fxing allows it to be fxed to the wall rather than the plasterboard. Always check the fxing is secure to the retaining wall.

No.6 **"Shield Anchor" wall plug Heavy loads**



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

Care & Maintenance

Safety: Always check the ftting and location to ensure your safety in and around the home.

Fitting: From time to time check the ftting to ensure the wall plugs or screws do not become loose.