


Knightsbridge Oak Mini Sideboard

Assembly Instructions - Please keep for future reference

230/3107



Dimensions

Width - 80cm
Depth - 34cm
Height - 80cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.


- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on this product during assembly, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor.

- Parts of the assembly will be easier with 2 people.



- We do not recommend the use of power drill/drivers **for inserting screws**,

as this could damage the unit. Only use hand screwdrivers.

- Dispose of all packaging carefully and responsibly.

- As wall materials vary, screws for fixing to wall are not included. Please purchase a suitable screw system from your local specialised dealer.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.


- From time to time check that there are no loose screws on this unit.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Panels

If you have damaged or missing components,
call the **Customer Helpline: 0845 640 0800**

Please check you have all the panels listed below






1 Mini Sideboard (80x34x80 cm)




Components - Fittings

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<div><div>A</div><div></div><div>Wall strap x 1</div></div>	<div><div>B</div><div></div><div>Ø12x1mm Washer x 1</div></div>	<div><div>C</div><div></div><div>Ø3.5x15 mm Screw x 1</div></div>
--	--	--

Tools required




Ruler/tape
measure



Philips screwdriver
(medium & large)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1

Fixing to wall.


It is recommended that the unit is fixed to a wall.

Mark fixing hole on wall.


Fasten wall strap **A** to the wall using a suitable wall screw/plug system.



Warning:
Before drilling, check wall for hidden pipes and cables.



Note: The correct type of wall screws must be used for your wall. Please seek professional advice if in doubt.





Step 2

Fixing to unit.

With the help of another person move the unit into position.

Place the wall strap on the top of the unit.

Fasten the wall strap to the unit with screw **C** and washer **B**.



If you need help or have damaged or missing parts, call the Customer Helpline: 0845 640 0800