
Bergen SHELF PACK 120 x 200 x 53cm

Assembly Instructions Please keep for future reference

237/5805





Dimensions

Width - 57.7cm Depth - 48.8cm Height - 1.8cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, please visit: **www.argos-support.co.uk** or email: **Help@ClickSpares.co.uk** (quoting your original order number) Alternatively, call the Spares Helpline on: **0370 112 1928** For any other queries please contact the Customer Helpline on: **0345 640 2020**

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• During assembly do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.

• To reduce the likelihood of damaging your product please ensure that your

power drill is set on a low torque setting.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners. • From time to time check that there are no loose screws on this unit.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts • Regularly check and ensure that all bolts and fittings are tightend properly.


Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels For damaged or missing parts, please visit: www.argos-support.co.uk or email: Help@ClickSpares.co.uk




Assembly Instructions

Step 1




Assembly Instructions



Assembly Instructions

Step 3

inserting shelves a: Push shelf supports **G** in hole as shown.



b: Position shelves 2 onto shelf supports **C** and fix by screwing eight chipboardscrews **D** through shelf supports **C** into shelves 2.