
Wiltshire - 2 Door Wardrobe

Assembly Instructions - Please keep for future reference

2387305
2466714
2473628



Dimensions

Width - 89cm
Depth - 52cm
Height- 184.5cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 03456 400 800

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (- in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints


• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten bolts.

• Regularly check and ensure that all bolts and fittings are tightened properly.

Components - Panels

If you have damaged or missing commponents, call the Customer Helpline: 03456 400 800


Please check you have all the panels listed below




1 **Right side panel x 1 (49 x 182.2cm)**




2 **Left side panel x 1 (49 x 182.2cm)**



3 **Top panel x 1 (89 x 52cm)**



4 **Bottom panel x 1 (75 x 48.6cm)**



6 **Back panel x 2 (38.5 x 174.1cm)**

7 **Right hinge frame x 1 (5.3 x 182.2cm)**

8 **Left hinge frame x 1 (5.3 x 182.2cm)**




9 **Bottom plinth x 1 (74.9 x 2cm)**


15 **Handle x 2 (10.5 x 1.9cm)**



16 **Large horizontal partition shelf x 1 (75 x 48.4cm)**



23 **Right door x 1 (37 x 170.6cm)**









25 **Left door x 1 (37 x 170.6cm)**


Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  Feet x 4	**B**  8/30mm Wooden dowel x 30	**D**  Nail x 50
E  Screw x 27	**G**  Large locking nut x 27	**O**  Underlay x 2
S  30mm Screw x 4	**U**  Hanger rail support x 2	**V**  Hinge plates x 6
W  Door hinge x 6	**X**  Wall strap x 1	**Y**  13mm Screw x 1
Z  Hanger rail x 1	**Z2**  14mm Screw x 2	**Z3**  Door stop x 1


Tools required



Phillips screwdriver
(medium & large)



Hammer




Flatblade screwdriver
(medium)



Ruler/tape
measure

Ruler - Use this ruler to help correctly identify the screws



The screws length is measured from the head to the point (30mm screw shown)


Assembly Instructions

Step 1

a: Preparation for the attaching of horizontal partition shelf and bottom panel

Insert screws E into the drilled holes of the left and right side panels 1 and 2, top panel 3 and fix them.


b: Attaching feet
Position plastic feet A to the left and right side panels 1 and 2 from below and fix them using the hammer.



Step 2

Insert wooden dowels B into the bottom panel 4 and partition shelf 16 and place on left and right side panels 1, 2.


Align correctly and insert large locking nuts G and turn them clockwise to lock.



Assembly Instructions


Step 3

Frame assembly
Insert screws E in to the frames 7 , 8 , 9 .



Step 4

Insert wooden dowels B as shown, align correctly and connect the frames 7, 8 and 9 as shown on the picture.




Assembly Instructions

Step 5

Attaching the frame


Insert wooden dowels B into the edge of the left and right side panels 1 , 2 .
Align correctly and insert large locking nuts G into left and right side panels 1 , 2 and bottom panel 4 , place the frame and turn locking nuts clockwise to lock.



Step 6

Attaching top panel

Insert wooden dowels B into the top edges as shown, align correctly and insert large locking nuts G into left and right side panels 1 and 2 , place the top panel 3 and turn locking nuts clockwise to lock.




Step 7

Attaching back panels

With help, carrefully lay wardrobe down

Position back panel 6 in position on the back of wardrobe. Position nails D 5 mm in from side edge of the back panel 6 with distance 100 mm between each other. Fix them using the hammer.



Note: **You must ensure the wardrobe is square before attaching the back panels.**

Assembly Instructions

Step 8

a: Attaching hanger rail


With help, carefully stand wardrobe upright.

Warning:
The wardrobe is heavy.
Lift with care.

Insert hanger rail supports U and place the hanger rail Z.

b: Fitting door stop


Position door stop Z3 onto the the bottom panel 4 , fix using screws Z2.



Step 9

Fitting hinges to doors


Position 3 door hinges W into left and right doors 23 , 25 , fix using supplied screws.



Step 10

Attaching handles to doors

Attach handles 15 to doors 23 , 25 using screws S.




Assembly Instructions

Step 11

Fitting hinges to side panels

Position 3 hinge plates (V) into left and right side panels [1], [2]. Small arrow on the hinge plate must point outwards. Fix using supplied screws.





Step 12

Hanging doors

With help, slot door hinges (W) onto hinge plates (V) and click into position.

Repeat for left door.






Step 13

Hinge adjustment

To move doors up or down, in or out, left or right: loosen screws as shown and move doors up or down, in or out, left or right as required.

Retighten screws.



Assembly Instructions

Step 14

Fixing to wall

It is recomended that the chest is fixed to a wall.

Mark fixing hole onto wall. Drill a hole and insert a suitable wall plug. Fix wall strap X using a screw suitable for your wall.


Warning:
Before drilling, check wall for hidden pipes and cables.


With help, move wardrobe into position.

Warning:
The wardrobe is heavy. Lift with care.

Fix wall strap X to top of wardrobe using screw Y and underlay O.

Assembly is complete.





Note: Wall fixings are not supplied with this unit.

The correct type of fixing must be used for your wall, seek professional advice if in doubt.