

G-SHOCK




AE-1300WH-8AV

Specifications

- ⇒ 100M WR
- ⇒ Daily Alarm
- ⇒ Stopwatch
- ⇒ World Time
- ⇒ LED Light
- ⇒ 10- Year Battery



Model variations may differ in appearance from the example above.

World Time	Displays the current time in major cities and specific areas. Current time in 48 cities (31 time zones)	Press button C to enter World Time mode, your current world time city code should appear on the digital display for two seconds. Press D to get the next city code in order. 						
Stop Watch	Elapsed time	Press button D until display shows stopwatch function (STW) Start and stop the stop watch using button. Measure times: To measure times with the stopwatch Elapsed Time 						
Daily Alarms	To Enter Alarm mode Press C — Hold down Button A until hour digits start to flash on the display (hours digits flash because the are selected, this operation automatically turn on the alarm). Press C to change the selection in the following sequence;  When a setting is flashing, use Button D and B to change as described below; <table border="1" data-bbox="316 1496 976 1585"> <thead> <tr> <th>Screen</th> <th>To do this:</th> <th>Do this:</th> </tr> </thead> <tbody> <tr> <td>12:00</td> <td>Change the hour and minutes</td> <td>Use D (+) and B (-). • With the 12-hour format, set the time correctly as a.m. or p.m. (P indicator).</td> </tr> </tbody> </table> After you set the alarm time, Press A to return to the Alarm model		Screen	To do this:	Do this:	12:00	Change the hour and minutes	Use D (+) and B (-). • With the 12-hour format, set the time correctly as a.m. or p.m. (P indicator).
Screen	To do this:	Do this:						
12:00	Change the hour and minutes	Use D (+) and B (-). • With the 12-hour format, set the time correctly as a.m. or p.m. (P indicator).						
Water Resistant	Suitable for bathing, swimming, and showering. not for diving.							
LED Light	Includes an After-Glow feature that keeps the illuminator turned on for a few seconds after the light button released.	In any mode (except when setting screen is on the display) Press B to illuminate display						
10 Year Battery	Battery power lasts up to approximately ten-years without changing.	CASIO's advanced technology allows extended battery life for up to ten-years . All timekeeping modes and functions of the watch can be used continuously for up to seven-years without a battery change.						