
avignon 1 drawer bedside chest

Assembly Instructions - Please keep for future reference

254/9710

257/8925



Dimensions

Width - 56cm
Depth - 47cm
Height - 46.9cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts,call the
Customer Helpline: Argos = 0345 6400 800

Issue 1 - 06/06/14

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torgue setting.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts


• Regularly check and ensure that all bolts and fittings are tightened properly.

Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: Argos = 0345 6400 800**


Please check you have all the panels listed below



1 Top ×1 (56 × 47cm)




2 Side panel, Left ×1
(39.3 × 25.3cm)




3 Side panel, Right×1
(39.3 × 25.3cm)



4 Back leg, left ×1 (45.1 × 4.5cm)




5 Front leg, left ×1 (45.1 × 4.5cm)




6 Back leg, Right ×1 (45.1 × 4.5cm)




7 Front leg, Right ×1 (45.1 × 4.5cm)



8 Cross bar, front x1 (43 × 2.4cm)




9 Cross bar, back x1 (43 × 5.7cm)




10 Cross bar, front ×1 (43 × 4.5cm)




11 Back panel ×1 (44.1 × 21.2cm)



12 Drawer frontal ×1 (42.6 × 18.5cm)




13 Drawer side, right ×1 (35 × 16cm)



14 Drawer side, left ×1
(35 × 16cm)



15 Drawer back×1 (38.1 × 15.7cm)















16 Drawer bottom ×1 (39.2 × 34.9cm)


Components - Fittings


Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  Large locking pin × 22	**B** Large locking nut × 22 	**C**  Wooden dowel × 16
D  Φ3.5 × 15mm Screw for Runner × 14	**E**  Ø3.5×25mm Screw × 4	**F**  Ø3.5×30mm Screw × 2
G  350mm Runner outside left × 1	**H**  350mm Runner outside right × 1	**I**  350mm Runner inside left × 1
J  350mm Runner inside right × 1	**K**  Small locking pin × 4	**L**  Small locking nut × 4
M  Handle × 1	**N**  Screw for handle × 1	**O**  Ø3.0×15mm Support for Back panel × 4
P  Ø3.0×20mm Screw × 4	**Q**  Rubber bumper × 2	


Tools required


Phillips screwdriver (medium & large)


Rubber mallet


Flatblade screwdriver (medium)


Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1


Screw Large locking pins A into the Top 1 ,and legs 4 5 6 7 .






Step 2

Insert the Wooden dowels C to the Cross bar 9 and 10, the Side panel 2 and 3 .







Assembly Instructions

Step 3

Attach the two leg [6] and [7] to the Side panel [3], fix them using Locking nut (B) and screwdriver.


Repeat above steps with the other Side panel [2] .





Step 4

Attach the Runner (G) to the Side panel [2], and Runner (H) to the side panel [3], fix them using Screw (D).




Assembly Instructions

Step 5

Screw 4 Locking pins (K) to the Drawer front [12].


Fix the Cross bar [8] to the Top [1] using Screw (F) .


Attach the Rubber bumper (Q) to the Drawer front [12].



Step 6


Attach the Side frames to the Cross bars [9] and [10] fix them using Screw (B) and screwdriver.






Step 7


Slip the Back panel [11] to the groove in the back legs [4] and [6] .



Step 8

Cover the Top [1] to the frame, fix it using Locking nut (B) and screwdriver.






Assembly Instructions

Step 9

Attach Drawer side 13 and 14 to the Drawer front 12 . Fix them by Locking nuts L and screwdriver.


Slip the Drawer bottom 16 into the groove in the Drawer side 13 and 14, cover the Drawer back 15, fix it by Screw E.



Step 10

Fix the Runner I and J to the Drawer side 13 14 using Screw D.


Fix the Handle M to the drawer front 12 using Screw N .



Assembly Instructions


Step 11

Fix the Support O to the back panel 11 using Screw P .



Step 12

Slip the drawer to the chest.



Assembly is complete.

If you need help or have damaged or missing parts,call the
Customer Helpline: Argos = 0345 6400 800