
Emperor Rectangular Dining Table + 4 Folding Chairs


Assembly Instructions - Please keep for future reference **2662680**

2685849

2705444

DINING TABLE x 1





FOLDING CHAIR x 4

TABLE	
Dimensions	
Width - 139cm	
Depth - 87cm	
Height - 75cm	

CHAIR	
Dimensions	
Width - 46,8cm	
Depth - 48,6cm	
Height - 70,6cm	

IMPORTANT - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline:
Argos = 0345 6400800

Issue 1 - 28/08/14

Safety and Care Advice

Important - Please read these inctructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3 .
- Remove all fittings from the plastic bags and separate them into their groups .
- Keep children and animals awey from the work area, small parts could choke if swallowed .
- Make sure you have enough space to layout the parts befor starting .
- Do not stand on the product , this could cause damage .
- Assemble the item as close to its final position (in the same room) as possibe .
- Assemble on a soft level surface to avoid damaging the unit or your floor .
- Parts of the assembly will be easier with 2 people.



- We do not recommend the use of power drill/drivers ***for inserting screws***, as this could damage the unit. Only use hand screwdrivers.
- Assemble on a soft level surface to avoid damaging the unit or your floor .

Care and maintenance

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners

From time to time check that there are no loose screws on this unit


This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note : if required the next page can be cut out and used as reference throughout the assembly . Keep this page with these instructions for future reference .


Components - Panels

If you have damaged or missing components, call the Customer Helpline: Argos = 0345 6400800

Please check you have all the panels listed below



1 Flap x2



2 Top x1



3 Back Panel x 1



4 Drawer Front x 1



5 Door x 1



6 Drawer Side Left x1




7 Drawer Side Right x1



8 Drawer Back x1




9 Drawer Bottom x1




10 Wooden runner x2



11 Wooden runner x9



12 Wooden frame element x 2





13 Wooden flap support x 2

Components - Fittings

Please check you have all the fittings listed below

Note : The quantities below are correct amount to complete the assembly . In some cases more fittings may be supplied then are required .

A  Large cam x 2	**B**  Magnetic plate x 1	**C**  Locking pin x 2
D  18 mm Screw x 72	**E**  Magnetic Catch x 1	**F**  50 mm Screw x 18
G  Hinge x 6	**H**  60 mm Screw x 10	**I**  36 mm Dowel x 20
J  Hinge x 4	**K**  Castor x 2	**L**  Hex Key x 1
N  35 mm Screw x14	**O**  handles x 2	

Tools required


Philips screwdriver
(medium & large)


Flatblade screwdriver
(medium)


Suitable drill bit
(for use with wall plug)


Small
hammer


Roler/tape
measure


Eye protection
(when using a
hammer or glue)

Ruler - use this ruler to help correctly identify the screws




Assembly Instructions


Step 1

Fix Fittings to the Table Flaps

Fix hinges Ⓙ to table flaps [1] using screw Ⓓ

Fix wooden runners [10] to table flaps [1] using screw Ⓝ






Step 2

Assemble Carcass

Insert dowels Ⓘ into the wooden runners [11]

Fix wooden runners [11] with the frames [12] using hex key Ⓛ and screw Ⓕ




Assembly Instructions

Step 3

Fix Magnetic Catch to the Carcass

Fix magnetic catch E to the carcass 12 using screw D





Step 4


Assemble Table Top and Carcass

Assemble table top 2 and carcass 12 using screw H

Fix castors to the Carcass

Attach the mounting plates with castors K to the underside of the carcass using screw D






Assembly Instructions

Step 5

Fix Hinges to Flap Supports

Fix hinge G to the flap support 13 using screw D






Step 6

Fix Flap Supports to Carcass

Attach flap supports 13 to the carcass 12 using screw D




Assembly Instructions

Step 7

Mounting the locking pins to the drawer front

Screw the locking pins Ⓒ into the holes indicated on the drawer front [4]

Note:
Insert locking pins Ⓒ as far as shown. Do not over tighten.



Step 8


Assembling the drawer front to the drawer sides

Lower the drawer front [4] onto the side [6] and [7]

Place the cams Ⓐ into the holes indicated, arrows pointing towards the side / locking pins

To tighten cams: Turn to the right using a screwdriver

Slide the drawer bottom [9] into the grooves of the drawer frame




Assembly Instructions

Step 9

Drawer assembly

Fix the drawer back [8] to the drawer sides [6] and [7] using screw Ⓝ




Step 10

Fix Fitting to the Door

Attach magnetic plate Ⓑ using screw Ⓓ

Fix hinge Ⓖ to the door [5] using screw Ⓓ






Assembly Instructions

Step 11

Fix Door to the Carcass

Fix door [5] to the carcass using screw Ⓓ

Fix back panel [3] to the carcass using screw Ⓗ




Step 12

Fit Drawer to the Carcass

Slide the drawer onto the wooden runners

Use screw Ⓝ to secure the drawer




Assembly Instructions

Step 13

Secure Table Flap to Table Top


Secure the table flap [1] to the table top [2] by fixing hinge Ⓙ with screw Ⓓ




Step 14

Fix the handles

Attach the handles Ⓞ using screw Ⓝ





Assembly Instructions


Step 15

How to unfold /fold the table flaps

a: Lift up the table flap 1 and hold it with your hand for a while.

b: Slide the flap support 13 underneath it towards the center of the table flap 1 until it touches the wooden runner

c: Repeat the same process with the other table flap and flap support.




To fold the table simply reverse the process.

1. Hold the table flap 1 with your hand, then slide the flap support towards the door and the drawer front

2. Close the table flap

3. Repeat the process with the other flap and support



Care and Maintenance Advice

Important - Please read these inctructions fully

IMPORTANT MAINTENANCE AND CLEANING INFORMATION DO NOT REMOVE
(CARING FOR YOUR PRODUCT)

Outlined below are general care instructions that will prolong the look and life by preventing wear and damage

PLEASE NOTE THAT THE MANUFACTURER IS NOT LIABLE FOR ANY DEFECTS CAUSED BY MISUSE AND NON COMPIANCE WITH THESE INSTRUCTIONS

PU – PVC etc.

General Care Advice

- Dust regularly with a clean dry cloth.
- Wipe up any liquid spills immediately with a damp cloth and then dry the surface with a clean dry duster.
- Repeat this procedure for periodic cleaning.
- Solid spills (Butter, Food & Mud) – Carefully remove the excess quantity of the spill before dabbing to clean stains
- The use of furniture polish or spray is not necessary or recommended

What Not to Do – Do Not Soak

- Never rub or scrub with a wet cloth to remove spills or stains as this could remove colour.
- Do not use washing up liquid, detergents, or bleach to remove stains.

Cleaning:

We recommend Professional Cleaning only for this product, to prevent excessive build-up of dirt and soiling.

Sunlight and Heat

- Direct sunlight or heat can cause fabrics to deteriorate or fade – Place your furniture out of the way of prolonged direct light
- Reduce exposure by moving items around or changing position so that the same piece of area is not always exposed.
- Avoid placing furniture too close to fires or radiators

Beware of Sharp objects

- Sharp objects such as buckle and jewellery can easily snag on the fabric and produce tears and marks in the fabric

If you need help or have damaged or missing parts, call the Customer Helpline:
Argos = 0345 6400800