
Henley TV Unit



614 / 3136 614 / 3143



Dimensions

Width - 90cm Depth - 40cm

Height - 45cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800

A Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• Keep these instructions for future use.

• Check you have all the components and tools listed on pages 2 and 3.

•Do not stand or put excessive weight on the product, this could cause damage.

• Parts of the assembly will be easier with 2 people.

• Dispose of all packaging carefully and responsibly.

• Do not use this item if any components are missing or damaged.

• During assembly children should be kept away from the product due to possible risk of injury.

• Remove all fittings from the plastic bags and separate them into their groups.

• To ensure an easier assembly, we strongly advise that all fittings are only finger tightened during initial assembly. Only upon completion of the assembly should all fixing points be fully tightened.



• We do not recommend the use of power drill/drivers for inserting screws,

as this could damage the unit. Only use hand screwdrivers.

Care and maintenance


• Clean using a damp cloth or a proprietary domestic furniture polish. Do not use abrasive cleaners.

• This product should not be discarded with household waste. Take to your local authority waste disposal only. • From time to time check that there are no loose screws on this unit.

Components - Parts

If you have damaged or missing components, call the **Customer Helpline: 08456 400800**

Please check you have all the parts listed below



Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

۵	6	Θ
	0111110	
Metal dowel x 20	Wood dowel x 10	Locking nut x 20
0	9	6
		Ô
25mm Screw x 14	19mm Screw x 2	Drawer handle x 2

Tools required



Phillips screwdriver (medium & large)

 Ruler/tape measure

Ruler - Use this ruler to help correctly identify the screws

 $0 \quad 5 \quad 10 \quad 15 \quad 20 \quad 25 \quad 30 \quad 35 \quad 40 \quad 45 \quad 50 \quad 55 \quad 60 \quad 65 \quad 70 \quad 75 \quad 80 \quad 85 \quad 90 \quad 95 \quad 100 \quad 105 \quad 110 \quad 115 \quad 120 \quad 125 \quad 130 \quad 135 \quad 140 \quad 145 \quad 150 \quad 155 \quad 160 \quad 165 \quad 170 \quad 100 \quad 10$

Step 1


Preparing panels

Place left and right side panels 1 and 2 and top panel 3 and shelf 12 flat on the floor with the fixing holes facing up.

Screw metal dowels (A) into panels (1), (2), (3) and (12) as shown.

Note: Insert metal dowels as far as shown. Do not overtighten.

Insert wood dowels into right side panel 1 and top 3 as shown.



Step 2


Attaching back panel

Locate back panel 4 onto shelf 12.

Note: Ensure the fixing holes are all facing in as shown.

Insert locking nuts 🕒 into the holes in back panel 4 as shown.

Using a screwdriver, turn locking nuts **O** clockwise to secure.



Step 3

Attaching right side panel


Lay right side panel 1 flat on the floor.


With help, carefully locate the shelf assembly onto the side panel.

Note: Ensure back panel **4** is located at the back of right side panel **1**.

Insert locking nuts **()** into the holes in back panel **(4)** and shelf **(12)** as shown.

Using a screwdriver, turn locking nuts **O** clockwise to secure.





C

C

Step 6

Attaching left side panel

Insert wood dowels **B** into the ends of lower stretcher **6** and shelf **12** as shown.

With help, carefully align left side panel 2 and locate into position.

Insert locking nuts () into back panel (4), shelf (12) and stretchers (5) and (6).

Turn locking nuts clockwise to secure.

Step 7

Attaching top panel


Place top **3** upside down onto a clean flat surface.


With help, turn the unit body upside down and locate it onto top 3.

Insert locking nuts () into the holes in side panels 1 and 2.

Turn locking nuts clockwise to secure.

Finally secure top 3 using screws **()** through stretchers **(5)**.






Step 8


Assembling drawer


a: Assemble drawer side panels 10 and 11 and drawer back 8 together using screws

Note: Ensure the grooves in all 3 panels are aligned at the bottom.




b: Slide drawer base **9** into the grooves as shown.





Attach drawer handles using screws **B**.



C:

b:

Step 9

Locating drawer

Carefully stand the unit upright.



a: Fully extend all drawer runners out as shown.

a: pull out the side panel drawer runners for proper insertion of the drawers. b: O Ю Line up the drawer runners on the drawers on both sides so that they enter evenly into the extended receiving runners as shown. Gently push in the drawer until the drawer is secure and slides in and out smoothly.

b: Carefully locate the runners on the drawers, into the runners on the main unit.

Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800** Justwise Group LTD., 6 The Shires, Shire Hill Industrial Estate, Saffron Walden Essex. CB11 3AP