
Rattan 4 Seater Set - Coffee Table

Assembly Instructions - Please keep for future reference

3459311

2935609



Dimensions

Width - 110cm
Depth - 53cm
Height - 38cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 03456 400 800

Issue 1 - 26/09/13

Safety and Care Advice

Important Please read these instructions fully before starting assembly

- This product is manufactured from toughened safety glass. In the unlikely event that the glass fails it will break in to a large number of small fragments that may be spread over a wide area. This is a feature of toughened glass, designed to remove the risk of injure from glass breaking into large shards.
- If the glass is chipped or broken, stop using the product and consult the manufacture or supplier.
- Check you have all the components and tools listed on page 2.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the parts during assembly, this could cause damage.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Dispose of all packing carefully and responsibly.
- Do not sit or stand on this table.
- Do not place very hot or very cold items on the glass.
- ***Warning:*** The unit weights approximately 14.2kgs.

Please lift with care.


Care and maintenance

- Wash glass with mild soap and water, rinse thoroughly, and dry glass completely.
- When moving the table, remove the umbrella. Do not drag.
- We recommend the use of furniture covers when not in use.
- Do not use the glass as chopping surface. Do not strike the glass with hard or pointed items.
- In order to prolong the life and beauty of your table, we recommend it be stored in a dry and protected area during off season periods.
- Do not use washing powders or any abrasive substances which may scratch the surface.


Components - Parts

If you have damaged or missing components, call the Customer Helpline: 03456 400 800


Please check you have all the parts listed below




1 Right Side board x 1



2 Left Side board x 1



3 Base board x 1




4 Glass x 1

Components - Parts

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  20mm Screw x 8	B  Metal washer x 8	C  Allen key x 1

Tools required



Allen key x 1

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1

Assembly frame


Use 20mm screw A
and metal washer B
to fix the base board 3
to the side board 1 2.



Important:
Do not fully tighten all screws until assembly is complete.

Step 2

Fit the glass 4
onto the two side
boards 1 2 carefully.



Tighten all the screws.

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**
Argos Limited
489-499 Avebury Boulevard Saxon Gate West Central Milton Keynes Bucks,MK9 2NW