

SETUP GUIDE

Interface



- 1 Power ON/OFF/STANDBY
- 2 Headphone 3.5mm jack
- 3 Micro USB/Charger
- 4 Volume +
- 5 Volume -
- 6 Micro SD card Slot

IMPORTANT INFORMATION - PLEASE READ BEFORE SETTING UP YOUR KURIO

- The tablet must be set up by an adult to ensure an appropriate level of protection for all users of the device.
- To turn off your Kurio tablet correctly, press the Power button until the pop up message appears on screen, and then select ""Power off"". Avoid switching off the device by pressing and holding the Power button until the unit stops.
- Do not fully discharge the battery (keep at 5% or more). Recharge it to full power regularly to preserve the battery.
- Password Reset: Tech Support may not be able to retrieve your Parental Area password, so please don't forget to note it in a safe place. In case of a lost password, the tablet may have to be factory reset and all personal data will be lost.
- Please connect your Kurio tablet to Wi-Fi frequently to receive and enjoy the latest upgrades. Updates are pushed to your tablet wirelessly.
- If you encounter any issue with your device, please do not return it to the store. Please review our FAQs & troubleshooting info or contact our tech support team for help at www.kurioworld.com/support/


Find more tips and information at WWW.KURIOWORLD.COM

Customer Service Hotline: UK - 0344 880 4700 / 0115 8464256 • EIRE - 016869397

Installation

Kurio Parental Account Setup

- **Language selection:** Select your language to continue. You will still be able to change the language later in the Android settings.
- **Wi-Fi connection:** Select a Wi-Fi hotspot and connect to Wi-Fi (not mandatory but highly recommended).
- **Date & Time settings:** Set the correct date & Time (if not connected to Wi-Fi). If connected to Wi-Fi the date and time will automatically set.
- **Select usage mode:**
 - Normal Mode: Select this mode to use your tablet normally and continue the setup.
 - Demo Mode: This Mode is only for in store display use. DO NOT select **This Mode unless you are setting up a retail display.**
- **Restore preloads content:** That screen will be displayed only after a factory reset: it will allow you to download and install all original applications. Skip this screen if you don't want to restore the preloads.
- **Parental account creation:** Enter your name, email address and check the Terms of Use.
- **Security password:** To protect your parental account, you must set up a password (Either Pin code, password or visual pattern). Select your option and continue.




Create a Kurio User Profile

- **Create 1st child profile**
You can create the first child's profile now or choose to create it later. Make your choice and continue.
- **Child profile information**
 - Name: Enter the child's name
 - Birthdate: Enter your child's birthdate (this information will be used to automatically adjust security level)
 - Gender: Select either boy and girl.



Profile Type

Select a predefined profile on the left, or create your own custom settings. Each pre-defined profile defines the main options for your child's account: the authorised applications, the Web access filtering and the Time Management options.




Kurio Parental Area Overview

Parental Area Main Menu

The Kurio Parental widget is pre-installed on the main screen of the parental profile.

This widget will give you quick access to the main settings and features of the Kurio system:

- **Parental Account:** In this section, you will be able to change the main settings of your parental account (email address, name, password, pin code...).
- **Child's Profiles:** This button will give you access to the child's profile management. You'll be able to create new profile, delete or manage an existing one.
- **Apps & Preloads Management:** In this area, you will be able to install new available apps, update the existing ones, categorise each application or restore your preloads.
- **Store:** This button gives you quick access to the installed stores of your device (Kurio store & Google Play Store).
- **Customer Service:** You'll find in this screen all the information you will need, if you encounter any issue with your device (contact support, find your serial number, see the FAQ, report a bug...).
- **Settings:** This is a quick access to the main Android settings (date and time, application management, language...).
- **Exit the parental area:** use this button to switch profile.




Profile Main Menu

In the Profile main Menu, you can see the current settings of your child.


To modify a profile, use the following settings:

- **Child profile information:** change your child's name, birthday, configure theme or avatar.
- **App Management:** to allow or block each installed application for this profile.
- **Internet Access Modes:** to configure the Internet filtering system, use weblist or block Internet access.
- **Time Management:** to set time usage for weekdays and weekends, configure PlayTime and session time.
- **Profile Settings:** to review and change the profile's general settings.




Internet Access Modes

- **Kurio Filtering Presets:** Our advanced filtering system allows users to browse the Internet safely by blocking websites that may contain inappropriate content.
- **Custom Filters:** customise your own filters to select authorised categories or websites.
- **No Internet Access:** No Internet access is allowed from the profile. Apps can still access online content if an Internet connection is active.
- **Full Internet Access:** Removes any and all restrictions to web browsing. Not recommended for a child user profile.
- **Safe List Only:** Restricts Internet browsing only to websites that appear on the Safe List of this profile. All other sites will be blocked.



Profile Settings


- **Allow USB Connection:** This will turn on the USB port when connecting to a PC or from a USB host, such as an external hard drive.
- **Activate Online Ad filtering:** Kurio will try to filter ads inside websites and apps. Some ads may remain visible.
- **Reset Child Password:** if your child added a password to protect his profile, you can reset it using this option.
- **Auto-authorize Applications after install:** Applications downloaded from Parental Area will automatically appear in the child's profile (not recommended).
- **Lock Interface:** Turn this setting on to lock your child's interface, preventing him/her to move icons or delete them.



Time Management

On the right side of the main screen, you can see the current Time controls settings for this profile.

Select a Kurio preset or choose to customise the settings yourself. You can also import the settings from another profile.



TIME SLOTS MANAGEMENT

Activate the Time Slots settings by switching "on" the button at the top of the screen.

- **Day by day setting:** Swipe your finger on the tablet to set the desired time slots. You can choose several slots and set different ones for each day of the week.
- **Apply the same settings to the entire week:** Click on the box at the top of the screen to make the Time slot settings the same every day.



PLAY TIME MANAGEMENT

Activate this control to set the maximum play time for your child throughout the day.


- **Daily Play Time:** Maximum duration of use per day.
- **Session Time:** Maximum duration of consecutive use.
- **Rest Time:** Minimum break time between each session.

At the bottom, you can exclude some categories to those settings: for example, you can exclude the Educational category so that all apps in that category will be accessible all the time.

App Management

From the master list of apps shown, tick the box next to the app to use it in the profile. All unticked apps will not appear on this profile's interface.

It is also possible to import the settings from another profile or to use the default original selection.




Kurio User Interface

- **Avatar:** Press your avatar to access child's menu.
- **Categories:** Categories: use the categories to find your apps.
- **Favourites:** Drag and drop your favourite's apps in the Favourite's tab.
- **Store:** Access directly to the Kurio Store.



Child's menu



- **Change my avatar:** Press here to select a new avatar or to take a picture.
- **Change my theme:** Apply another theme to your interface.
- **Change my wallpaper:** Select a picture from the gallery to change your wallpaper.
- **Help:** Press here if you need help.
- **Kurio Store:** Access the Kurio Store to download new applications.
- **Log out:** Press here to exit your profile.



Kurio TAB

Tech Support & Warranty Information

- If you have any questions setting up or using your tablet, please visit www.kurioworld.com to find out more about Kurio, read our related FAQs, and for any technical support. All of our products have a one Year Warranty. In the unlikely event you experience any problems with your Kurio, please visit www.kurioworld.com/support/ to contact Kurio Customer Service. If the service representative is unable to solve the issue, he or she will provide instructions regarding how to have your Kurio serviced if it is under warranty.
- Please note that this tablet is warranted only to the original purchaser for a period of one year from the original purchase date, under normal use and service, against defective workmanship and materials. If the product is damaged due to accident, improper or unreasonable use or maintenance, such as a broken screen, fall, water damage, etc., this damage is not covered by the warranty. Please contact Kurio Customer Service for repair & replacement options, especially for a broken screen or other spare parts.
- Please visit www.kurioworld.com for the full details of Kurio's one Year Warranty.

Copyrights

2014 © A&R Entertainment. All rights reserved. Abalone® Published by AMA, developed by sppa4apps, Produced by Cazap © Copyright Michel Lalel-Laurent Lévi – 1987-2011, all rights reserved. Abalone® is licensed by Abalone Sarl. The Abalone® trademark is registered by Abalone Sarl. Panic Flight - © 2011 Advanced Mobile Applications. All rights reserved © 2014 Kidsbookmaker © 2014 Applift © 2012 bbigg Applications Inc. Strawberry Shortcake Bake Shop © Budge Studios Inc. 2014. Strawberry Shortcake™ Strawberry Shortcake is a trademark of Those Characters From Cleveland, Inc. and American Greetings, Inc. used under license by Budge Studios Inc. Winx Club Rocks The World © Budge Studios Inc. 2014. Winx Club™ Winx club is a trademark of Rainbow srl. Used under licence by Budge Studios Inc. CronLab® is a CronLab Limited registered trademark. Copyright © 2013 Farlex, Inc. Android, Google Play and other marks are trademarks of Google Inc. The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License. ©Greenlife Apps. Copyright © Intel Corporation. All Rights Reserved. Copyright © Karisma Kidz 2014. All Rights Reserved. Copyright © 2013 KD Productions™. All rights reserved. KD GROUP™, KD™, KD INTERACTIVE™, KURIO™, KD PRODUCTIONS™, the KD™ logo, the names, the graphics, the musics and brands mentioned on this product are registered trademarks of KD GROUP™, © Breakfirst © Nathan 2013 © 2009-2014 KidsEmail © 2013 Sybo and Kiloo. All rights reserved. Copyright © 2013 Kingsoft Software. All rights reserved. Copyright © 2011 Kuuasema Ltd. All right reserved. © Little Worlds Studio - Mana Crusher registered trademark. All right reserved. © Magma Mobile. All right reserved. © 2013 Miss Humblebee, LLC © 2013 mixtvision digital GmbH & Co.KG. Copyright © 2010-2013 Out Fit 7. Copyright © 2014 PinpinTeam. © Play7 Ltd. 2014. Copyright © 2012-2014. Genera Mobile. © 2013 Pyrosphere. MicroSDHC Logo is a trademark of SD-3C, LLC.. 2013 Socialin, Inc. PicsArt is a trademark of Socialin, Inc. © 2008-2014 Spotify Ltd. Copyright © 2013 Toon Goggles , Inc. ZeptoLab, Cut the Rope 2 and Pudding Monsters are the trademarks or registered trademarks of ZeptoLab UK Limited. © 2010-2014. All rights reserved. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by CIDE Interactive is under license. Other trademarks and trade names are those of their respective owners.



Warning! Permanent hearing loss may occur if earphones or headphones are used at high volume for prolonged periods of time.

For more information about Kurio, please go to www.kurioworld.com or contact:



Imported by:
InspirationWorks (UK) Ltd,
part of KD Group
First Floor - The Annexe
Salisbury Hall - St Albans AL2 1BU
UK



C14100GB_KDGB_AW_UM_04_140729

Tips and Recommendations

- While using some applications that use a lot of the device's processing capacity, the device may become warm. If this occurs, take a short break from using the device to let it cool down.
- Keep the Tablet clean by wiping it with a slightly damp cloth.
- If you encounter any charging issues, such as not fully charging or shutting off when it has a charge above 5%, you may need to reset the battery level indicator. Plug the Tablet into the power adapter, and then press and hold the POWER button until the tablet turns off. Continue to hold down the POWER button until the battery icon shows up again. Once it appears, release the POWER button and press it again to start the unit normally.
- The Kurio bumper protects your tablet in most cases, but is only intended to make the product more resistant to damage due to falls, bumps or other impact damages. Like any other electronic device, Kurio is fragile and despite the presence of the protective bumper, can break or be damaged from forces like dropping, banging, or being hit by other items. Please handle with care. Broken screens and touch panels are not covered by the warranty. Bumpers can only protect but cannot prevent all damage.
- Due to Android 4.4's system management, it is not possible to move applications to an external SD card. Instead we advise you to store all media files, such as Videos, photo's and music, on an external SD card to keep free memory on the device's internal storage for applications and games.

	WARNING RISK OF ELECTRIC SHOCK DO NOT OPEN		 <p>The lightning flash with arrow head within a triangle is intended to tell the user that parts inside the product constitute a risk of electric shock to people.</p>
WARNING: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER OR BACK. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.			 <p>The exclamation point within a triangle is intended to tell the user that important operating and servicing instructions are in the papers with the appliance.</p>
CAUTION: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE. DO NOT PLACE ANY OBJECTS FILLED WITH LIQUIDS, SUCH AS VASES, ON THIS APPARATUS.			

- Do not damage or deform the power supply USB cable. If it is damaged or deformed, it may cause electric shock or malfunction when used. When removing from wall outlet, be sure to remove by holding the plug attachment and not by pulling the cable.
- The power adapter & cable should be plugged in near the unit, so it is easily accessible and does not strain the cable.

Warning

- All packing materials such as internal bags, plastic collars, plastic films, screen protector film, and carton inserts are not part of this product and should be removed before handing the device over to a child. Please keep the box and this guide for further reference.
- Do not try to disassemble the unit.
- To charge Kurio, only use the power adapter supplied with Kurio tablet.
- Avoid using the tablet while charging: this may alter the battery charging process and the battery life of the device.
- Keep the unit out of direct sunlight and away from any direct heat source.
- Do not expose the unit to moisture or water.
- To prevent hearing damage, never use earphones at excessive volume levels. Listening to loud sounds for an extended period may cause temporary or permanent hearing loss.
- Never use Kurio while operating a motor vehicle or bicycle.
- If you feel discomfort in your hands or any pain using Kurio, please stop immediately.
- In case of long period of use, take frequent breaks.
- If any internal parts come out of the Kurio, do not try to remove it. Turn the Tablet off immediately and contact the Kurio help line. Please Keep the Tablet away from children.
- Never force a connector into a port a Kurio. If a connector and a port do not join with reasonable force, make sure that the connector matches the port and that you have positioned the connector correctly in relation to the port.
- To clean up the screen, simply use a soft damp cloth. Do not use alcohol, solvent, aerosol spray or abrasive cleaners to clean your Kurio.
- The silicone bumper is designed to protect from light use and drops, but is not guaranteed to protect this delicate piece of electronics from severe drops, abuse, misuse, etc.
- The product and the adapter should be periodically examined for conditions that may result in the risk of fire, electric shock, or injury to people and that, in an event of such conditions, the adapter should not be used until properly repaired.

Exposure to Radio Frequency Energy

- **Caution:** changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- **NOTE:** This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Consult the dealer you purchased your TV from, or an experienced radio/TV technician for help.

Restricted Use of Electronic Devices

"The use of electronic/electric devices may interfere with safe operation of some aircraft and can be restricted with some airline companies. Please check with your airline company before travelling. If needed Kurio has an Airplane Mode. Please go into the Settings of the Android Interface to switch the tablet into Airplane Mode. By selecting this all wireless connections will be turned off."

Declaration of Conformity

KD Interactive
Viladecans Business Park,
Edificio Brasil, C/ Catalunya,
83-85 Pl.1 B1,
08840 VILADECANS – BARCELONA,
SPAIN

Product: Kurio Tab
Model: C14100

"We declare that the product above complies with the basic requirements and the other relevant provisions required by R&TTE Directive (1999/5/CE), the Low Voltage Directive (2006/95/EC), EMC Directive (2004/108/EC), Eco conception-Energy related products (ErP) Directive (209/125/EC) and is in conformity with the following standards: EN 301 489-1 V1.9.2 :2011, EN 301 489-7 V1.3.1 :2006, EN 301 489-17 V2.1.1: 2009, EN 301 489-24 V1.2.1:2002-11, EN 62311: 2008, EN 55024: 2010, EN 55022: 2010, EN 61000-3-3: 2008, EN 62209-1+2: 2006, EN 50566: 2013, EN 50360: 2001+A1: 2012, EN 300328 v1.7.1: 2006, EN 60950: 2006+A11: 2009+A1: 2010+A12: 2011, IEC 62209-2:2010, 1275/2008, 278/2009".

The undersigned does hereby declare that the product complies with the above Directives.
Eric Wolff
General Manager



Issue date: June, 23th 2014

Recycling



Waste electrical products and batteries should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority for recycling advice.

CAUTION – ELECTRICALLY OPERATED PRODUCT – As with all electric products, precautions should be observed during handling and use to prevent electric shock. Adult supervision is recommended. Please retain this manual for further reference.

Privacy Policy

We need you to provide us with your email address when activating your Kurio tablet. Please ensure you keep your email address up to date via the Parental Area to be informed of important updates and information.

Your email address will never be shared with any third parties and you can unsubscribe at any time by clicking on the link provided at the bottom of every Kurio email. To read our Privacy Policy at any time, please go to www.kurioworld.com.