
Bamboo Clothes Rail (Half size)

Assembly Instructions - Please keep for future reference | 322/8645



Dimensions

Width - 45cm
Depth - 45cm
Height - 148.5cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**

Issue 1 - 11/ 12 /2014

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Pls do not stand or put weight on the product during assembly, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers **for inserting screws,** as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.


• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 0845 640 0800**


Please check you have all the parts listed below




1 Top Leg x 4




2 Bottom Leg x 4




3 Rail x 1




4 Small Shelf x 1




5 Large shelf x 1



6 Peg x 4



7 Small Support x 2





8 Large Support x 2


Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


A  Wooden dowel x 8	**B**  Bolt **x 8** (M6 x 20mm)	**C**  Bolt x 2 (M6 x 30mm)
D  Bolt x 2 (M6 x 50mm)	**E**  Rivet nut x 12	**F**  Screw x 12 (M4.8 x 40mm)
G  Screw x 10 (M4.5 x 50mm)	**H**  Allen Key x 1	

Tools required



Phillips screwdriver (medium)

Ruler - Use this reler to help correctly identify the screws




Assembly Instructions

Step 1

Building the legs

Insert rivet nuts E and bolts B into leg 1 and 2. Use Allen key H and Phillips screwdriver to lock bolts and rivet nuts together.

Repeat with the remaining three legs.



Step 2


Assembling the leg frames

Insert a wooden dowel A into each end of small support 7 and large support 8.

Fit support 7 and 8 to leg 2 with screws G and fasten with Allen key H.

Insert bolts C and D into leg 1 as shown. Insert rivet nuts into the other leg. Use Allen key H and a Phillips screwdriver to lock the bolts and rivet nuts together.

Repeat with the other leg frame.



Assembly Instructions

Step 3

Assemble the rail and shelf to side stretchers


Attach rail 3 , small shelf 4 and large shelf 5 to one leg frame with bolts G and F as shown.

Note:
The side of the shelf with mark 'Down' is the bottom side.

Attach the other leg frame to the assembly with bolts G and F .

Fasten the bolts F and G using Allen key H .


Carefully turn clothes rail up.



Step 4


Assemble pegs 6 to the legs with bolts F and fasten using Allen key H .

Assembly is complete.



Assembly Instructions

Note :
Due to the inherent nature of this design, please do not exceed the maximum load shown here.



If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**
Argos Ltd MK9 2NW