
Radium Corner Unit

Assembly Instructions - please keep for future reference | 322/9754



Dimensions

Width - 35.5cm
Depth - 22.3cm
Height - 100cm

Important– Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 6400800**

Issue 1 - 10/10/14

⚠ Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Glue safety - Take care when using glue, please follow the advice below

Skin contact: Remove contamination by washing with soap and water. This procedure should also be followed prior to eating and drinking.

Eye contact: Rinse immediately with clean water for 15 minutes and seek medical advice.

If swallowed: Seek medical advice immediately.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightend properly.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 0845 6400800**


Please check you have all the panels listed below




1 Top x1
(35.2cm x 22.3cm)




2 Left side x1
(12.9cm x 98.1cm)




3 Right side x1
(12.9cm x 98.1cm)




4 Bottom x1
(18.7cm x 27.6cm)




5 Left back x1
(12.6cm x 98.1cm)




6 Right back x1
(12.6cm x 98.1cm)




7 Front bar x1
(8cm x 27.6cm)



8 Adjustable shelf x3
(17.3cm x 27.4cm)



9 Door x1
(27cm x 89.5cm)




10 Middle back x1
(15.4cm x 90.9cm)

Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 0845 6400800**


Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly.In some cases more fittings may be supplied than are required.

A  30mm wooden dowel x 16	B  Male camlock x 9	C  Female camlock x 9	D  Glue x 1
E  Handle x 1	F  22mm Handle screw x 2	G  Catch Plate x 1	H  16mm Screw x 2
I  Hinge x 2	J  14mm Screw x 8	K  50mm Screw x 4	L  Hex Key x 1
M  Shelf support x12	N  25mm Sticker x 2	O  Wall Plug x 1	P  Wall strap x 1
Q  Washer x2	R  32mm Screw x 2		

Tools required



Phillips screwdriver (medium & large)



Drill


Small hammer

7mm Suitable drill bit (for use with wall plug)


Ruler - Use this ruler to help correctly identify the screws




The screws length is measured from the head to the point (30mm screw shown).

Components - Fittings


Ruler - Use this ruler to help correctly identify the screws



Using Camlocks

Step 1


Connect the male camlock as directed in the assembly instructions using a screwdriver.



Step 2


Insert the female camlock as shown in the instructions.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.



Step 3

Push the male camlock into the entry hole.




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.




Assembly Instructions

Step 1

Fitting Male camlock

1.Insert 9 x male camlocks B into top 1 ,left side 2 right side 3 & front bar 7




Assembly Instructions

Step 2

Fitting dowels

1.Glue and insert 16 x wooden dowels (A) into left side [2], right side [3], left back [5], right back [6], bottom [4] & front bar [7]



Assembly Instructions


Step 3

Attaching panels

1.Attach bottom [4] to front bar [7] .

2.Insert 1 x female camlock (C) to bottom [4] .

Use a screwdriver to turn the female camlock clockwise to lock. Please refer to the "Using Camlocks" section at the front of this instruction for further assistance.




Step 4

1.Attach bottom [4] and front bar [7] to left side [2]

2.Insert 2 x female camlock (C) to front bar [7] & bottom [4]

Use a screwdriver to turn the female camlock clockwise to lock. Please refer to the "Using Camlocks" section at the front of this instruction for further assistance.

Note: Please do not attempt to assemble the unit in an upright position.




Step 5

1.Attach bottom [4] to front bar [7]

2.Insert 2 x female camlock (C) to front bar [7] & bottom [4]


Use a screwdriver to turn the female camlock clockwise to lock. Please refer to the "Using Camlocks" section at the front of this instruction for further assistance.



Assembly Instructions


Step 6

1.Attach left back [5] & right back [6] to bottom [4] with 4 x screws (K) with Hex Key (L) supplied, to tighten.



Step 7

1.Slide middle back [10] along grooves in panel [5] and [6] as shown in diagram




Assembly Instructions

Step 8

1.Attach top [1] to left back [5], right back [6], left side [2] & right side [3].

2. Insert 4 x female camlocks (C) to back [5], right back [6], left side [2] & right side [3]


Use a screwdriver to turn the female camlock clockwise to lock. Please refer to the "Using Camlocks" section at the front of this instruction for further assistance.



Step 9

1.Insert 12x shelf supports (M) into the holes inside the unit in the desired position


2.Place 3xadjustable shelve [8] on the shelf supports.



Assembly Instructions

Step 10


1.Attach 2 x hinges (I) to the door [9] with 4 x screws (J) as shown.



Step 11

1. Attach door [9] to the unit with 4 x screw (J) as shown.

Note: You have the choice to hang the door from the left or the right.




Hinge adjustment:

a: To move the doors up or down, loosen screws shown and move doors to suit

b: To move the doors in or out, loosen screws shown and move doors to suit.

Retighten screws


c: To move the doors left or right, adjust screws shown.



Assembly Instructions


Step 12

1.Attach 1 x Catch Plate G to the bottom of top 1 with 2 x screw H .



Step 13


1. Attach 1 x Handle E with screw F as shown



Assembly Instructions


Step 14

1.Attach 1 x Catch Plate G to the bottom of top 1 with 2 x screw H
2.Attach 1 x handle E with 2 x screw F as shown.



Step 15


1.Use 2 x stickers N to cover camlock hole on left side 2 and right side 3



Assembly Instructions

Step 16

1.Using screw (R) & washer (Q) secure the 1 x nylon strap (P) to the back of top [1]



Step 17

Two people are needed here. It is recommended that the unit is fixed to a wall.

1.Move the unit into desired position.

Warning:
The unit is heavy.
Lift with care.


2. Mark the wall with a suitable scribe the position of the fixing hole.

Warning:
Before driling,check wall for hidden pipes and cables.

3. Drill 7mm hole and insert wall plug (O).

4.Secure the other end of the strap (P) to the wall with washer (Q) & screw (R)


Note: To hide the strap behind the unit ,drill the hole lower than the top of unit.



Assembly Instructions

Step 18

1.Assembly is complete.




If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 6400800**

A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs(rawl plugs) are supplied with your product, e.g.:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using the incorrect fixings is the responsibility of the installer.

Important: when drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for **supporting your unit.Consult a qualified tradesperson if you** are unsure.

Hints:

1: General rule: always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.


4: Take extra care when drilling high walls,ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the folllowing types of wall plug if your walls are made of brick, breeze block, concrete,stone or wood.

No.1"General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads,use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.3"Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.5"Hammer Fixing" wall plug




For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.2" Plasterboard" wall plug




For use when attaching light loads onto plasterboard partitions.

No.4" Cavity Fixing - Heavy Duty" wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.4" Shield Anchor" wall plug - heavy loads



For use with heavier loads such as TV and HiFi speakers and satelite dishes etc.

Care & Maintenance

Safety: always check the fitting and location to ensure your safety in and around the home.

Fitting: from time to time check the fitting: to ensure the wall plugs or screws do not become loose.

If you need help or have damaged or missing parts, call the Customer Helpline: 0845 6400800