

Hygena Charlie Chair

Assembly Instructions - Please keep for future reference

323/2349

339/6852

hygena



Dimensions

Width - 48cm

Depth - 54cm

Height - 83cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 6400800



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- During assembly do not stand

or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.
- Do not stand on the chair.
- Do not use this chair as step ladder.



• We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- Unit weight: 4.54kgs.
- Maximum safe weight of user: 110kgs.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightend properly.


Components - Parts

If you have damaged or missing components, call the
Customer Helpline: Argos = 0345 6400800

Please check you have all the parts listed below



1 Backrest
(48 x 54.5 x 43.5cm)







2 Leg Frame
(42.5 x 43 x 39.5cm)

Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A  M6 x 25mm Bolt x 4</p>	<p>B  Washer x 4</p>	<p>C  Spring washer x 4</p>	<p>D  Allen key x 1</p>
--	--	---	---

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


Step 1

Attaching leg frame

Place the seat **1** upside down on a raised, flat and protected surface.

Position the leg frame **2** on the seat as shown.

Secure using bolts **A** and washers **B** / spring washer **C** then tighten bolts using allen key **D**.



Carefully turn over the chair.

Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 6400800