
Foley Bookcase

Assembly Instructions - Please keep for future reference | 333/7976



Dimensions

Width - 63cm
Depth - 30 cm
Height - 137 cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline:** 0345 6400 800

Issue 1-26-11-14

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

Check you have all the components and tools listed on pages 2 and 3.
Remove all fittings from the plastic bags and separate them into their groups.
Keep children and animals away from the work area, small parts could choke if swallowed.
Make sure you have enough space to layout the parts before starting.

Assemble the item as close to its final position (in the same room) as possible.

Assemble on a soft level surface to avoid damaging the unit or your floor.

Assembly requires 2 people.

Do not fully tighten bolts until the whole bed is assembled.
Do not overtihgten the nuts to avoid causing damage to the threads.



We do not recommend the use of power drill/drivers ***for inserting screws,*** as this could damage the unit.
Only use hand screwdrivers and Allen keys.

Dispose of all packaging carefully and responsibly.

Solid wood / Real wood veneers

This product has been finished using natrual materials. As a living material, you may notice some variation in the grain and colour shade between the different components.

Unlike a synthetic or man-made material which has a uniform finish, a feature of natural wood is its variation in grain and colour. We wish to reassure you that this is quite normal and is not the result of any manufacturing fault.

Where sheets of wood are joined together, a line may be detected. Again, this is normal and is not an imperfection.

The natural finish should be cared for by the periodic application of a good quality 'was' based domestic furniture polish (Not silicone!!). Occasional / small spills should be removed immediately using a damp cloth.

Do not allow hot articles to come into contact with the surface, as damage will occur!

Care and maintenance

Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.


From time to time check that there are no loose screws on this unit.

This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Components - Parts

If you have damaged or missing components.
call the **Customer Helpline**: 0345 6400 800

Please check you have all the parts listed below



1 Side panel (left) x 1
(128x30x1.5cm)




2 Side panel (right) x 1
(128x30x1.5cm)




3 Back panel (grey) x 2
(60.8x35.3x0.3cm)




4 Back panel (white)x 2
(60.8x35.3x0.3cm)




5 Upper shelf x1
(60x24.5x1.5cm)



6 Middle shelf x1
(60x26x1.5cm)



7 Lower shelf x 1
(60x27.5x1.5cm)



8 Base panel x 1
(60x29.5x1.5cm)



9 Leg x 4
(3.8x3.8x15cm)






10 Top panel x 1
(60x22.5x1.5cm)

Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 0345 6400 800**

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


A  Metal dowel x 20	**B**  Locking nut x 20	**C**  Wooden dowel x 4
D  6 x 50mm Allen screw x 8	**E**  Spring washer x 8	**F**  Plain washer x 8
G  Wall strap x 2	**H**  12mm Wood screw x 2	**J**  Allen key x 1

Tools required

 Ruler/tape measure

 Phillips screwdriver (Not supplied)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1


Preparing panels

Place side panels 1 and 2 flat onto the floor with the fixing holes facing up.

Screw metal dowels A into each panel as shown.

Screw metal dowels as far as shown.

Do not overtighten.




Step 2

Assembling shelves

Carefully locate base panel 8 ,shelves 5 , 6 and 7 and top panel 10 onto right side panel 2 in the locations shown.

Note: Ensure all grooves are correctly located at the back.

Secure all panels using locking nuts B .




Step 3

Assembling back panels

Carefully slide back panels 3 and 4 into the grooves as shown.


Note: All back panels are the same size so can be moved to suit your required colour combination.



Step 4

Assembling side panel

Carefully locate left side panel 1 into position and secure using locking nuts B.




Assembly Instructions

Step 5

Attaching feet

Assemble feet [9] to base panel [8] using fixing **D**, **E** and **F**.



Assembly Instructions

Step 6

It is recommended that the unit is fixed to the wall to ensure stability.

Assemble wall straps G to the back edge of top panel 10 using screws H .

With help, move the unit to the desired location.


Mark the fixing hole locations on the wall and remove the unit.

Drill the wall and fit suitable plugs for your wall type.

Note: Wall plugs are not supplied.

Warning: Before drilling. Check the wall for hidden pipes or cables.Re-position the unit and secure the wall straps to the wall.

Note: Screws are not supplied.



Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline: 0345 6400 800**
Home Retail Group. 489-499 Avebury Boulevard. Saxon Gate West. Central Milton Keynes. MK9 2NW