340/6199[D]





3 Litre
Bellows Foot Pump

Item No.: HT-122

Usage:
1. Release loop to enable bellows to expand.
2. To inflate - Press wide end of hose firmly into outlet valve shaped ⊙
3. To deflate - Press wide end of hose firmly into outlet valve shaped ⊕
4. Select adapter that fits aperture of item to be inflated / deflated and connect to end of hose
5. Place bellows on level surface and pump steadily, without undue force.

Notice: Keep the pump out of hard products and fire.

Recycle
CARD - CARD
widely recycled

MADE IN CHINA

Argos MK9 2NW

152.2X215.35mm