

REVOLUTION® 5 Pro FAQ:

- **Can I play on PS5, PS4 and PC with the Revolution 5 Pro® controller?**

Yes, the Revolution 5 Pro is compatible with PS5, PS4 and PC. The controller is made to be fully compatible when used on the correct platform. Use the switch on the back of the controller to change between the different platforms settings.



- **Is the controller compatible on Steam?**

Yes the controller is compatible on Steam but not with Mac.

Make sure to set your controller's platform switch on PC mode.

- **Does the Revolution® 5 Pro have adaptative triggers?**


The Revolution 5 Pro does not have adaptative triggers . Instead, we chose to focus on durability with hall effect magnetic sensors on our triggers that will make your triggers withstand the test of time.

- **Does the Revolution® 5 Pro have haptic feedback?**

The Revolution 5 Pro does not have haptic feedback. It instead includes Vibration as on PS4 and PC. Those vibration only work on PC games and PS4 games.

- **How long can I play per charge?**

You can play for 10h or more depending on the power settings. Increase battery life by activating the battery saving mode on the Revolution 5 Pro app home screen.



- **Can I buy spare parts separately and where can I buy them?**

In the future you will find spare parts for easy repairs available through the MyNacon portal on Nacongaming.com.

- **Where can I download the software for the REVOLUTION® 5 PRO controller?**

You will be able to download the PC app for the Revolution® 5 Pro on the nacongaming.com product page in the Support and Downloads section.

A Mac application will also be available before the end of the year.

- **Can the REVOLUTION® 5 PRO Controller support a macro function?**

Macros are not supported in E-Sports, as the REVOLUTION 5 PRO controller follows the rules of E-Sports, this feature is not supported.

- **My REVOLUTION® 5 PRO controller is not recognized by my console.**

If you are using the controller in Wired mode, ensure that the cable is well fixed to your controller and connected to your PS5™ or PS4™ console. To use the controller on the PS5™ or PS4™ console, you need to press the PS button to turn it on and make sure that the mode button is on the right platform.

If you are using the controller in Wireless mode, ensure that the USB receiver is well connected to your PS5™ or PS4™ console and that the USB dongle and the



controller are paired together and that you are on the right platform on the mode button.

When the controller is paired to its USB dongle, the led of the USB dongle will be fixed and player LED on the controller will also be fixed.

Also, make sure that the battery is charged.

When switching from Wireless mode to Wired mode you will see the on-screen message: "Controller was disconnected". Press the "PS" button to re-connect.

- **Can I turn on or wake up my PS5™ or PS4™ console, with my REVOLUTION® 5 PRO controller?**

The communication, to open the PS5™ or PS4™ console, is only Sony dual sense controllers. This feature is not supported by our controller.

- **How can remap buttons on my Revolution 5 Pro controller ?**

Classic & Advanced modes

Classic mode: your controller will act as a classic DualSense® wireless controller, DUALSHOCK®4 wireless controller, or PC controller.

You can access the following customization options "on the fly" without the need for any App:

- Mapping of the 4 rear shortcut buttons.
- Trigger travel data range, via the trigger stopper position.
- Audio control, via the touch pad.

Advanced mode: Access by using the Revolution 5 Pro App. This mode is the most complete customization tool available to you with more than 60 variation of settings.

Download the App at <https://nacongaming.com/revolution-5-pro> and follow the tutorial.

Your controller is pre-loaded with 4 profiles so you can experience the range of features.

1. Profile 1: Racing - Sports - adapted for racing and sports games
2. Profile 2: FPS – adapted with a reactive curve on your Left joystick for quick movement and a progressive curve on the Right joystick for precision aiming.
3. Profile 3: Arcade - Fighting – adapted with an instant curve on the Left and Right joysticks for a quicker reaction time.
4. Profile 4: Infiltration – adapted with an ultra-reactive curve on the Left joystick for quick movement and a delayed one on the Right joystick for precision actions.



Using the App, you can create and share your profiles with your friends and the gaming community.

Mapping the rear shortcuts

• IN CLASSIC MODE

1. Press and hold the Multi-function button for 3 seconds. The light ring around the Right joystick will start to flash;
2. Now, press the rear shortcut button that you want to program. The Profile LED, which is linked to the selected rear shortcut, will light up (see image below);
3. Then, press the button that you want to associate with the shortcut. The profile LED will flash 3 times to indicate that the mapping was applied to the selected shortcut;
4. Repeat these steps for each shortcut or if you want to change an existing setting;
5. The profile LED will flash 3 times to indicate that the mapping was applied to the selected shortcut;
6. Repeat these steps for each shortcut or if you want to change an existing setting.
7. Apply a short press on the Multi-function button to leave this mode and save your settings. The light ring will stop flashing.

• **How do I pair a device using Bluetooth on my Revolution 5 Pro?**

To pair the controller to Bluetooth® true wireless earbuds or headset, follow these steps:

1. Put the controller and true wireless earbuds/headset next to each other.
2. Put the Bluetooth® true wireless earbuds/headset in to pairing mode.
3. Press and hold the Bluetooth® button on the controller for 6 seconds
4. The controller will go in to pairing mode and light ring around the Right joystick will flash alternatively in blue and white.
5. When the controller is paired, the halo ring will stop flashing.

Future connections of the same true wireless earbuds/headset will pair automatically. Make sure that the Bluetooth® is turned on, on the controller, by pressing and holding the Bluetooth button for 3 seconds.

NOTE: *The controller cannot connect to the console via Bluetooth.*

• **My REVOLUTION® 5 PRO controller is not recognized by my game on PC.**

Ensure that your controller is in the PC mode. It is important to check that the mode switch (on the underside of the controller) is in the 3rd position (PC).
– The REVOLUTION® 5 PRO Controller is compatible with all PC games that are X-Input compatible. This is the standard protocol for using a controller.



Do not activate both options at the same time.

- **When playing a versus fighting game I cannot achieve some movements with the Directional pad on Advanced Mode.**

In that case, Connect your REVOLUTION®5 PRO Controller on a PC or MAC and use the companion app to check that the directional pad is not set at 4 directions on your desired profiles. If it's the case, select the 8 directions, save your profile and send it into your REVOLUTION®5 PRO Controller and try again.