
Collectors Cabinet

Assembly Instructions - Please keep for future reference | 355/3932 D



Dimensions

Width - 75cm
Depth - 10cm
Height - 75cm

Warning: 2 persons assemble recommended.

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**

Issue 1 - 15/09/14

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.



• We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

Glass safety – Take care when handling glass, please follow the advice below

• If a glass component is chipped or broken replace with glass of the type described on this instructions. Consult the manufacturer, retailer or agent with regard to obtaining a manufacturing specification and shape for replacement glass quoting the model number, and batch or date of manufacture.

• Do not place very hot or cold items against or in close proximity to the glass surfaces unless adequately thick insulating material is used to prevent such items coming into contact with the glass.

• Do not strike the glass with hard or pointed items.

• When cleaning glass panels or mirrors use a damp cloth or leather with washing up liquid or soft soap if necessary.

• Do not use washing powders or any other substances containing abrasives since these substances scratch glass.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Panels


Please check you have all the panels listed below




1 Top panel
(750 x 97mm)



2 Side panel x 2
(720 x 97mm)



5 Glass door x 2
(725 x 410mm)



3 Bottom panel
(750 x 97mm)



4 Glass shelf x 5
(709 x 78mm)







6 Rear panel (folded)
(745 x 745mm)

Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 08456 400800**

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


A  42mm Screw x 12	**B**  25mm Screw x 16	**C**  Cover pad x 8
D  Wall plug (for solid walls only) x 4	**E**  Metal plate x 4	**F**  Shelf holder x 20
G  Nail x 14		

Tools required



Phillips screwdriver
(medium & small)

7mm Suitable drill bit
(for use with wall plug)




Drill



Small hammer




Ruler/tape measure



Eye protection (when using a hammer)

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1

Position Panels 1 2 and 3 as illustrated, half-tighten with Screws A.


Measure the distance cross corners as shown, make sure the dimention X is equal to dimention Y, then tighten up all screws.



Step 2

Unfolder Rear panel 6 and locate on the edges of Panels 1 2 and 3 as shown.

Gentally hammer the Nails G on to the pre-drilled holes as shown.




Assembly Instructions

Step 3

Locate Metal plates **E** to the pre-drilled holes as shown, secure with Screws **B**, make sure the metal plate do not stand over the edges.

Turn the unit upright.



Step 4

Decide upon the position to be fixed.


Using a spirit level make sure the unit is level. Mark fixing hole on wall and remove unit.


Drill 7mm hole and insert wall plug **D**.

Warning: Before drilling, check wall for hidden pipes and cables.

Reposition the unit, push Screw **A** through the central hole in Metal Plate **E** and then secure into the Wall plug **D** as shown.

2 people needed for this step.





Wall

Door stopper on bottom panel.


Note: Wall plugs supplied are for solid walls only.

The correct type of fixing must be used for your wall, seek professional advice if in doubt.

Assembly Instructions

Step 5


Insert the shelf holders Ⓕ into the holes in Side panels 2 at desired height.



Step 6

Push one glass shelf 4 into the top level shelf holders, secure the screw underneath the shelf holder as shown.

Repeat this step to locate and fix other glass shelves one by one from top to bottom for easy assembly.




Assembly Instructions

Step 7

Position one glass door [7] with handle hole on the right side as shown.


Insert the top edge of glass door in the INNER groove in top panel, holding the door and insert the bottom edge into the INNER groove in bottom panel.



Step 8

Position the other glass door [7] with handle hole on the left side as shown.

Insert the top edge of glass door in the OUTER groove in top panel, holding the door and insert the bottom edge into the OUTER groove in bottom panel.



Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**
Home Retail Group plc. Avebury, 489-499 Avebury Boulevard. Milton Keynes. MK9 2NW

A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.

Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

1: General rule: Always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.


4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 **"General Purpose" wall plug**




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 **"Plasterboard" wall plug**




For use when attaching light loads on to plasterboard partitions.

No.3 **"Cavity Fixing" wall plug**




For use with plasterboard partitions or hollow wooden doors.

No.4 **"Cavity Fixing-Heavy Duty" wall plug**




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 **"Hammer Fixing" wall plug**



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 **"Shield Anchor" wall plug Heavy loads**



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.