
Foley Storage Unit

Assembly Instructions - Please keep for future reference | 362/7741



Dimensions

Width - 120cm
Depth - 40 cm
Height - 114 cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline:** 0345 6400 800

Issue 1- 10-12-14

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

Check you have all the components and tools listed on pages 2 and 3.
Remove all fittings from the plastic bags and separate them into their groups.
Keep children and animals away from the work area, small parts could choke if swallowed.
Make sure you have enough space to layout the parts before starting.

Assemble the item as close to its final position (in the same room) as possible.

Assemble on a soft level surface to avoid damaging the unit or your floor.

Assembly requires 2 people.

Do not fully tighten bolts until the whole bed is assembled.
Do not overtihgten the nuts to avoid causing damage to the threads.



We do not recommend the use of power drill/drivers ***for inserting screws,*** as this could damage the unit.
Only use hand screwdrivers and Allen keys.

Dispose of all packaging carefully and responsibly.

Solid wood / Real wood veneers

This product has been finished using natrual materials. As a living material, you may notice some variation in the grain and colour shade between the different components.

Unlike a synthetic or man-made material which has a uniform finish, a feature of natural wood is its variation in grain and colour. We wish to reassure you that this is quite normal and is not the result of any manufacturing fault.

Where sheets of wood are joined together, a line may be detected. Again, this is normal and is not an imperfection.

The natural finish should be cared for by the periodic application of a good quality 'was' based domestic furniture polish (Not silicone!!). Occasional / small spills should be removed immediately using a damp cloth.

Do not allow hot articles to come into contact with the surface, as damage will occur!

Care and maintenance

Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.


From time to time check that there are no loose screws on this unit.

This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Components - Parts

If you have damaged or missing components.
call the **Customer Helpline**: 0345 6400 800


Please check you have all the parts listed below




1 Base panel x1
(120x40x7.5cm)




2 Lower shelf x1
(120x40x1.5cm)




3 Upper shelf x1
(120x40x1.5cm)




4 Top panel x1
(120x40x1.5cm)




5 Divider x3
(31x40x1.5cm)




6 Divider x2
(holes for door stop)
(31x40x1.5cm)




7 Divider x2
(holes for door hinges)
(31x40x1.5cm)




8 Divider x1
(31x40x1.5cm)



9 Divider x1
(holes for door stop)
(31x40x1.5cm)



10 Divider x1
(holes for door hinges)
(31x40x1.5cm)



11 Small door (white) x1
(29.6x30.6x1.5cm)



12 Large door x1
(39.6x30.6x1.5cm)


Components - Parts

If you have damaged or missing components.
call the **Customer Helpline**: 0345 6400 800

Please check you have all the parts listed below



13 Large back panel x1
(52.3x31.8x0.3cm)




14 Small back panel x2
(wood finish)
(31.8x30.8x0.3cm)




15 Medium back panel x1
(40.8x31.8x0.3cm)



16 Feet x4
(3.8x3.8x15cm)



17 Small back panel x1
(painted)
(31.8x30.8x0.3cm)







18 Small door (grey) x1
(29.6x30.6x1.5cm)

Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 0345 6400 800**

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  Metal dowel x 40	**B**  Locking nut x 40	**C**  Wooden dowel x 40
D  Ø4 x 14mm Wood screw x 36	**E**  Door hinge x 6	**F**  Plastic bracket x 20
G  Ø3 x 14mm screw x 20	**H**  M6 x 50mm Allen screw x 8	**J**  Spring washer x 8
K  Plain washer x 8	**L**  Door stop x 3	**M**  25mm screw x 6
N  12mm screw x 2	**P**  Wall strap x 2	**Q**  Allen key x 1

Tools required




Ruler/tape measure



Phillips screwdriver (Not supplied)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


Step 1

Preparing panels

a: Carefully place base panel [1] upside down onto the floor.

Assemble legs [16] to base panel [1] using H fixings J and K.

a:



b:


b: Turn-over base panel [1] flat onto the floor with the fixing holes facing up.

Place top panel [4] flat on the floor with the fixing holes facing up.

Screw metal dowels A into each panel as shown.

Note: Screw metal dowels as far as shown. Do not overtighten.

Insert wood dowels C into panels [1] and [4] as shown.



Assembly Instructions


Step 2

Preparing shelves

Place lower shelf [2] and upper shelf [3] flat onto the floor.

Fit metal dowels (A) to both side of shelves [2] and [3] as shown. (C)


Fit wooden dowels [2] to one side of shelves and [3] .



Step 3

Preparing dividers

Fit door stops (L) to dividers [6] and [9] using screws (M) .



Assembly Instructions

Step 4

Attaching dividers


a: Locate dividers 5 , 6 and 7 onto base panel 1 in the locations shown.


Insert locking nuts B into the holes in the dividers as shown.


Turn locking nuts B clockwise to secure.


Fit wood dowels C into the holes in the top edges of each divider.

b: Carefully slide back panels 14 and 17 into the grooves in the dividers as shown.









Step 5

Fitting lower shelf

Locate lower shelf 2 into position and secure using locking nuts B .

Assembly Instructions

Step 6

Attaching dividers


a: Repeat step 5 to assemble dividers [5], [9] and [10] onto lower shelf [2].

Secure using locking nuts (B).


Fit wood dowels (C) into the top edges of the dividers.

b: Slide back panels [13] and [14] into position as shown.

a:




b:



Step 7

Fitting upper shelf

Assemble upper shelf [3] using locking nuts (B) as shown.



Assembly Instructions

Step 8

Assembling dividers


a: Assemble dividers [6], [7] and [8] onto upper shelf [3].

Secure using locking nuts (B).


b: Slide back panel [15] into position as shown.

c: Fit top panel [4] and secure using locking nuts (B).


a:



b:




c:




Step 9

Preparing doors

a: Assemble hinges Ⓔ to doors [11], [12] and [18] using screws Ⓓ.



b: Assemble doors [11], [12] and [18] to dividers [7] and [9] using screws Ⓓ.



Assembly Instructions


Step 11


Hinge adjustment

a: To move doors up or down, loosen screws Ⓓ as shown and move doors to suit.

Once doors are aligned, insert 2 more screws Ⓓ into the hinge plates and fully tighten all screws.

a:







b: To move doors in or out, loosen screw shown and move doors to suit.

Re-tighten screws.

b:







c: To move doors left or right, lossen screw shown and move doors to suit.

Re-tighten screws.

c:






Assembly Instructions

Step 12

Securing assembly

Fit plastic brackets (F) around the edge of back panel 13 , 14 , 15 and 17 using screws (G).



Step 13

It is recommended that the unit is fixed to the wall to ensure stability.

Assemble wall straps (P) to the back edge of top panel 4 using screws (N).

With help, move the unit to the desired location.

Mark the fixing hole locations on the wall and remove the unit.


Drill the wall and fit suitable plugs for your wall type.

Note: Wall plugs are not supplied.

Warning: Before drilling. Check the wall for hidden pipes or cables.Re-position the unit and secure the wall straps to the wall.

Note: Screws are not supplied.

Assembly is complete.



If you need help or have damaged or missing parts, call the **Customer Helpline: 0345 6400 800**
Home Retail Group. 489-499 Avebury Boulevard. Saxon Gate West. Central Milton Keynes. MK9 2NW