

1 Contents

- a) Backboard
- b) Inflation Pump
- c) Tubes x 2
- d) Tube with slot in bottom
- e) Tube with hole in top
- f) Hoop and net
- g) Hoop Connector Clip
- h) Hoop Bracket
- i) Tube Connectors
- j) Backboard Connector
- k) Basketball
- l) Base
- m) Lid

2 Use sand or water as ballast

Ensure slot in bottom pole lines up with notch in base

If sand is to be used as ballast, ensure that the first tube (d) is inserted before putting the sand in the base.

3 Push lid firmly onto base and fasten with clips at each corner

4 Push on 1st connector

5 Insert 2nd tube

Ensure groove in bottom of second tube lines up with slot in top of first tube each time a tube is inserted.

6 Repeat steps 4 and 5 until all four tubes are inserted.

PLEASE NOTE:
To adjust height, remove one of the poles.

7 Attach net to hoop

Loop net over hooks on inside of hoop as shown.

8 Push hoop into hoop bracket

Push the hoop firmly into the slots at the front of the hoop bracket.

9 Push backboard connector into hoop bracket

Push narrow end of backboard connector through hoop bracket ensuring that the groove in the connector runs parallel to the lines on the back of the bracket.

10 Unfold backboard and secure

PLEASE NOTE: To release clip for packing away depress end and push back through slot

Push the clip through the top of the reverse side of the board as shown.

11 Push backboard onto backboard connector as shown below

Slide slot in backboard over notch in top of backboard connector and push firmly until secure.

12 Push connector into top tube

Push firmly into the top tube ensuring that the holes line up at the back of the tube and push clip through hole to secure as shown.

13 Use pump provided with needle attachment to inflate ball

Do not over inflate. Wet needle before inserting.

14 Ready to play

Packing away

Push down firmly on the top of the hoop as shown to remove the hoop from the bracket and pack everything in base. Net can be left on the hoop when stored.

HELPLINE

If you are experiencing problems with this product, please call our Helpline on:
+44(0)1525 722716
Mon-Thurs 9am - 3.30pm
and
Fri 9am - 2.30pm
or
email: info@mookie.co.uk
www.mookie.co.uk

All rights in and to this product including its configuration and colour combination, the slogans "The Way to Play", "Just Play It" and "Its Alive" which are either registered trade marks in the United Kingdom and/or other countries, are owned by, and used under licence from, European Sports Merchandising B.V., Bovenkerkerweg 49, 1185 XA Amstelveen, The Netherlands.

© 2003 All rights reserved.

This product is covered by:

1. E.P.O. Patent Application No. 00912229.2
2. U.S. Patent No. 6328665
3. P.C.T. Patent Application No. PCT/ZA00/00011
4. U.K. Patent Application No. 0001566.9
5. Swingball is a registered Trademark No. 1097469
6. Corresponding Patents in other countries also apply.

PLEASE NOTE: This product will last longer if not exposed to direct sunlight for long periods of time. Store in a frost free environment. Empty water to avoid it going stagnant.