

1 Unpack base

a) Lid
b) Base & clips

c) TriLattice Checkerbats® x 2
d) TriLattice Checkerbats® holder
e) Swingball® TURBO HEAD™ and TURBO SLEEVE™
f) Poles x 2
g) Bottom pole x 1
h) E-clip
i) Ball and tether
j) Cord adjuster
k) Connectors x 3

2 Insert bottom pole and fill base with sand or water

Fill base with sand or water. For more robust play, please add extra ballast such as sand, bricks or stones for extra stability.
Please ensure that the bottom pole is inserted before sand if used.
PLEASE NOTE: Bottom pole has a stopper in the end.
Insert E clip through hole in the pole before fitting lid.

3 Fasten clips securely as shown

1
2
3

4 Add second pole

Push connector onto second pole
Push second pole onto bottom pole

5 Add third pole

Push connector onto third pole
Push third pole onto second pole

* Bat holder may be added at this stage if required.

6 Add Swingball® TURBO HEAD™

Push connector onto Swingball® TURBO HEAD™
Push Swingball® TURBO HEAD™ onto third pole

7 Place loop over Swingball® TURBO SLEEVE™

TURBO SLEEVE™
TURBO HEAD™

8 Ready to play