
Colourmatch Gemini Bar Stool

Assembly Instructions - Please keep for future reference

392/4839
414/8793
414/6489
391/9655



Dimensions

Width - 52cm
Depth - 43cm
Height - 99.5cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 640 0800

Issue 1 - 09/04/15

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Parts of the assembly will be easier with 2 people.

• During assembly do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Do not stand on the stool.

• Do not use this stool as a step ladder.



• To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

• Unit weight: 4.25 kgs.

• Maximum safe weight of user: 110kgs.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints


• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.

• Regularly check and ensure that all bolts and fittings are tightend properly.


Components - Parts

If you have damaged or missing components, call the **Customer Helpline: Argos = 0345 640 0800**


Please check you have all the parts listed below




1 Seat
(52 x 42 x 29cm)



2 Stretcher
(Ø2.2 x 38.2 x 38.2cm)



3 Upper leg
(72 x 52.5 x 3cm)






4 Lower leg
(72 x 51 x 3cm)


Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  M6 x 35mm Bolt x 8	**B**  M6 x 25mm Bolt x 1	**C**  Nut x 1
D  Curved washer x 4	**E**  Allen key x 1	**F**  Spanner x 1

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions


Step 1

Attaching legs

Position the upper leg 3 and lower leg 4 as shown. Align holes and fix using bolt B & nut C.

Important:
Tighten bolt and nut using allen key E and spanner F but do not fully tighten at this stage.







Step 2

Attaching stretcher

Position the stretcher 2 between the legs as shown. Align holes and fix using bolts A.

Important:
Tighten bolts using allen key E but do not fully tighten at this stage.





Assembly Instructions

Step 3


Aligning the legs

Place the leg frame on a flat surface.

Fully tighten bolt **B** and nut **C** assembled in step 1 first using allen key **E** and spanner **F**.

Carefully make adjustments to the leg frame to ensure the legs are flat even on the floor.

Then fully tighten bolts **A** on stretcher [2] using allen key **E**.



Step 4

Attaching seat


Place the seat [1] face down on a flat protected and raised surface.


Position the leg frame on the seat as shown. Align the holes and fix using bolts **A** and curved washers **D**. Tighten the bolts using allen key **E**.


Important:
Do not over tighten bolt **A**.

Carefully turn over the bar stool.

Assembly is complete.







If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 640 0800