
2 Tier Shoe Rack

Assembly Instructions - Please keep for future reference

408/5791



Dimensions

Width - 75cm
Depth - 28cm
Height - 33cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 640 0800

Issue 1 - 19/03/15

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• During assembly do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.


• Regularly check and ensure that all bolts and fittings are tightend properly.

Components - Parts


If you have damaged or missing components,call the **Customer Helpline: Argos = 0345 640 0800**

Please check you have all the panels listed below

1 Side support x 2 (33cm)



2 Net x 2 (72cm)



Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A End cap x 4 	**B**  Screw 32mm x 8	**C**  Allen key x 1


Assembly Instructions

Step 1

a: Insert the End cap Ⓐ into the end of the Side support 1 .

Repeat a: for the other Side support 1 .

a:



b: Fix the Net 2 with Side support 1 using Screw Ⓑ, tighten with Allen key Ⓒ as shown in fig.1 and fig.2.

b:




fig.1






fig.2





Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 640 0800