# AVR Bentwood Chair

**Assembly Instructions** - Please keep for future reference | 411/1634



## Dimensions

Width - 48cm
Depth - 53cm
Height - 81cm

**Important** - Please read these instructions carefully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**

Issue 1 . 23/3/2015

# Safety and Care Advice

## **Important -** Please read these instructions carefully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small part could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• During assembly do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.

• Unit weight: 3.9 kgs.



• To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

• Maximum safe weight of user: 110 kgs.

• Do not stand on the chair.

• Do not use the chair as a step ladder.

## Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

## Handy Hints


• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.

• Regularly check and ensure that all bolts and fittings are tightend properly.


# Components - Parts

If you have damaged or missing components, call the **Customer Helpline: 03456 400800**


## Please check if you have all the parts listed below



1 Seat (42 x 40 x 1.2cm)



2 LegA (64 x 40.5 x 1.9cm)








3 LegB (64 x 40.5 x 1.9cm)


# Components - Fittings


## Please check you have all the fittings listed below

***Note:*** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

| | | |
|---|---|---|
| A  M6x32mm Bolts x 4 | B  M6x40mm Bolt x 1 | C  M6 Flat washer x 2 |
| D  M6 Spring washers x 5 | E  23x28x32mm Nut plastics x 4 | F  M6 Allen key x 1 |
| G  M6 Nut x 1 | H  M6 Spanner x 1 | |

**Ruler-** Use this ruler to help correctly identify the screws




The screws length is measured from the head to the point (30mm screw shown).

# Assembly Instructions

## Step 1

**Attach the legs**


Upside down the seat [1] on a protected table.
Attach the shorter end of bolt (B) with flat washer (C) into the center hole of seat [1].
Slide the nut plastics (E) onto legs [2] & [3] as shown in the figure.
Attached legs [2] & [3] to the seat [1] using bolts (A) with spring washers (D), and then tighten with allen key (F)




## Step 2

**Fix the centre bolt**

Fix the bolt (B) with a flat washer (C) and a spring washer (D) and a nut (G) to the seat, tighten with a spanner (H).




**Assembly is complete**

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**