Red lines are for Die Cut and folding reference...
do NOT Print Red Lines.

Front page

Acctim Smart Connector®

LED ALARM CLOCK

Thank you for your purchase of this quality clock. Please read these instructions carefully and store in a safe place for future reference.


Acctim Smart Connector® is an innovative new technology which allows you to use or upcycle your Smartphone charger to reduce landfill. Simply plug the supplied USB lead into the clock and the other end into your phone/smart device charger. You can now use your clock to charge/power your smart device.

FEATURES:
Jumbo LED display
Soft touch painted case
Alarm with push case for snooze
USB powered - Just connect to a phone/smart device charger
160cm USB lead supplied
Second USB port to charge Smartphone/tablet/e-reader etc.
Battery back-up requires 1 X AA battery (not included)

IMPORTANT NOTE: The charger used to power this clock must be suitable and of the correct output voltage (volts) and current (amps) to charge the smart device.

GETTING STARTED
Plug the USB lead supplied into one of the USB ports at the back of the clock and connect it to your phone/smart device charger, now plug the charger into a standard household outlet.

CHARGING YOUR PHONE/SMART DEVICE
Note: You can use either USB port 'USB.1 or USB.2' at the back of the clock to charge or power your device.
Plug the smart devices 'USB data cable lead' into the port that you want to charge from and connect it to your phone/smart device. Your clock now becomes a hub and can be used to charge most Smartphones, tablets, e-readers, MP3, bluetooth speakers etc.



SETTING THE TIME
Slide the AL.SET.T.SET.LOCK switch to the T.SET position.
Press the HR (hour) button or MIN (minute) button to set the desired time. Note - The PM indicator will appear for PM time.
Slide the switch to the LOCK position.

SETTING THE ALARM
Slide the AL.SET.T.SET.LOCK switch to the AL.SET position. Press the HR (hour) button or MIN (minute) button to set the desired alarm time.
Note - The PM indicator will appear for PM time.
Slide the switch to the LOCK position.

Back page

TO TURN ON/OFF THE ALARM
To turn on/off the alarm slide the AL.ON/OFF switch to the AL.ON position, the alarm bell icon will appear. When the alarm sounds, slide the AL.ON/OFF switch to the AL.OFF position.

USING THE SNOOZE FEATURE
When the alarm sounds, push the top of the clock down to activate the Snooze feature. The alarm will stop and sound again after 8 to 9 minutes. The alarm bell icon will flash. To stop the snooze function, slide the AL.OFF/ON switch to the AL.OFF position.

OPTIONAL BATTERY BACK UP
This clock has an optional battery back up feature, designed to retain the time and alarm settings in the event of a power failure. To use the battery back up, insert one "AA" battery (1.5 Volt) into the battery compartment at the back of the clock. If the power fails, the battery back up will automatically continue running the clock and maintain the time and alarm settings - Note: The alarm will not sound and the time display will not function under battery power.

SAFETY
This electric clock may represent a hazard for young children. Keep this clock out of reach of small children to avoid risk of shock or possible choking hazard from small parts or batteries.

CHANGING THE BATTERIES
It is recommended that you replace the battery annually. Only use 1XAA (1.5V) Alkaline battery in this clock. Insert the battery observing the polarity markings inside the compartment. Do not mix old and new batteries, different types or brands. Remove the battery if the clock is stored or not in use. Remove exhausted batteries from the product.
Warning: Do not recharge non-rechargeable batteries.
Please dispose of used batteries in a responsible manner. For more information please contact your local authority.

MAINTENANCE
A soft paper towel may be used to clean the clock. Do not use corrosive cleaners or chemical solutions on the clock. Keep the clock clean and dry to avoid any problems.

YOUR GUARANTEE
Your clock is guaranteed for 12 months from the date of purchase against any faults arising from defective materials or manufacture. Damage caused through careless handling, misuse or in transit is expressly excluded. Should this clock fail within 12 months please return it in the first instance to your retailer.

If you have any queries, problems or do not understand any part of these instructions please contact:

Customer Help Line Locall 0845 1207208 or (01908) 449208
Mon - Fri 9.00am - 4.30pm
email for service: service@acctim.com or visit www.acctim.com

ENVIRONMENTAL PROTECTION
Disposal of electrical and electronic equipment



Do not dispose of this product with household waste. For the proper treatment, recovery and recycling please take this product to the appropriate collection point. If you are unsure of where this is contact your local authority.
Improper disposal may be harmful to the environment.

V.1