
Foley End Table

Assembly Instructions - Please keep for future reference | 418/2883



Dimensions

Width - 40 cm
Depth - 35 cm
Height - 58 cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline:** 0345 6400 800

Issue 1-15-05-15

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

Check you have all the components and tools listed on pages 2 and 3.
Remove all fittings from the plastic bags and separate them into their groups.
Keep children and animals away from the work area, small parts could choke if swallowed.
Make sure you have enough space to layout the parts before starting.

Assemble the item as close to its final position (in the same room) as possible.

Assemble on a soft level surface to avoid damaging the unit or your floor.

Assembly requires 2 people.

Do not stand or put excessive weight on the product,this could cause damage.



We do not recommend the use of power drill/drivers ***for inserting screws,*** as this could damage the unit. Only use hand screwdrivers and Allen keys.

Dispose of all packaging carefully and responsibly.

Solid wood / Real wood veneers

This product has been finished using natrual materials. As a living material, you may notice some variation in the grain and colour shade between the different components.

Unlike a synthetic or man-made material which has a uniform finish, a feature of natural wood is its variation in grain and colour. We wish to reassure you that this is quite normal and is not the result of any manufacturing fault.

Where sheets of wood are joined together, a line may be detected. Again, this is normal and is not an imperfection.

The natural finish should be cared for by the periodic application of a good quality 'was' based domestic furniture polish (Not silicone!!). Occasional / small spills should be removed immediately using a damp cloth.

Do not allow hot articles to come into contact with the surface, as damage will occur!

Care and maintenance

Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.


From time to time check that there are no loose screws on this unit.

This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Components - Parts

If you have damaged or missing components. call the **Customer Helpline**: 0345 6400 800


Please check you have all the parts listed below




1 Top panel x 1
(40x35x1.5cm)




2 Base panel (right) x 1
(40x35x7.5cm)




3 Side panel (left) x 1
(21x35x1.5cm)




4 Side panel (right) x 1
(21x35x1.5cm)




5 Drawer front x 2
(36.4x10x1.5cm)




6 Drawer side panel (left) x 2
(30x10x1.2cm)



7 Drawer side panel (right) x 2
(30x10x1.2cm)




8 Drawer back x 2
(34x10x1.2cm)



9 Drawer base x 2
(34.8x29.8x0.3cm)



10 Back panel x 1
(37.8x21.8x0.3cm)









11 Leg x 4
(34x3.8x3.8cm)

Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 0345 6400 800**


Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


A  Metal dowel x 16	**B**  Large locking nut x 8	**C**  Small locking nut x 8
D  Wooden dowel x 8	**E**  6 x 50mm Allen screw x 8	**F**  Spring washer x 8
G  Plain washer x 8	**H**  4x30mm Wood screw x 8	**J**  Drawer runner x 4
K  3x12mm wood screw x 8	**L**  Drawer stop x 4	**M**  Allen key x 1

Tools required

 Ruler/tape measure

 Phillips screwdriver (Not supplied)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1

Preparing panels

a: Place top panel 1 and base panel 2 onto the floor with the fixing holes facing up.


Screw metal dowels A into each panel as shown.

b: Place side panels 3 and 4 onto the floor with the fixing holes facing up.

Fit drawer runners J to side panels 3 4 using wood screws K.

Note: Screw metal dowels as far as shown.

Do not overtighten



Step 2

Assembling top


Insert wood dowels D into the top edges of side panels 3 and 4 .

Carefully locate top panel 1 into position.

Note: Ensure the grooves in the top and side panels are aligned together.

Fit large locking nuts B into the holes in side panels 3 and 4 .


Turn locking nuts clockwise to secure.



Step 3

Assembling back panel

Carefully slide back panel 10 into the grooves in side panels 3 and 4.



Step 4


Assembling base


Insert wood dowels D into the holes in the bottom of side panels 3 and 4.

Carefully locate base panels 2 into position.

Fit large locking nuts B into the holes in side panels 3 and 4.

Turn locking nuts clockwise to secure.






Assembly Instructions

Step 5

Assembling legs

Assemble legs [11] to base panel [2] using fixings E, F and G.



Step 6

Assembling drawers

a: Assemble left and right drawer side panels [6] and [7] together with back panel [8] using screws H.

b: Slide drawer base [9] into the grooves as shown.

c: Place drawer front [5] flat on the floor.


Screw metal dowels A into each drawer front as shown.

d: Locate drawer front [5] onto the drawer body.

Locate small locking nuts C into the holes in side panels [6] and [7].

Turning locking nuts C clockwise to secure.

Repeat for both drawers.



Assembly Instructions


Step 7


Fitting drawers

Carefully stand the table upright .

Slide drawers onto the runners and push the drawer half way in only. Do not push fully into the body.

With the drawer in the half way position, push drawer stops L into the holes in the drawers side panels as shown.





Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline: 0345 6400 800**
Home Retail Group. 489-499 Avebury Boulevard. Saxon Gate West. Central Milton Keynes. MK9 2NW