For: Xbox One™ I Mobile



PREMIUM XBOX ONE[™] GAMING HEADSET

USER GUIDE





#1 IN GAMING AUDIO





Congratulations on your purchase of the Turtle Beach Ear Force XO SEVEN headset from Turtle Beach. You'll enjoy powerful gaming audio and chat on the Xbox One as well as for mobile gaming. Turtle Beach brings over 35 years of expertise to transforming your listening experience. Welcome to Turtle Beach!




Table of Contents

P4_
P5
P6_
P7_
P9_
P10
P11
P12
P13
P16

Package Contents

USB Micro Cable

For our Knowledgebase and Technical Support please visit **turtlebeach.com/support**




The Ear Force® XO SEVEN is the ultimate audio companion for the Xbox One[™], built with tournament grade durability and superior quality audio components. Experience everything Xbox One[™] has to offer with stunning high performance sound and chat audio - get the most from your games, music, TV and movies.

FEATURES

Be immersed. Headphones are tuned to provide the highest quality audio from the Xbox One [™] Audio Adapter.
Be unique. Customize the XO SEVEN with swappable speaker plates available in dozens of designs from turtlebeach.com/speakerplates.
 Be social. Chat in game or with friends on Skype [™] and Xbox LIVE® using the high- quality, noise-cancelling mic.
Be in control. Adjust game and chat volume for the perfect audio mix.
Be mobile. Remove the mic and swap in the mobile cable to use the XO SEVEN with all your mobile devices.
Be quiet. Memory foam cushions create a noise-isolating barrier to outside distractions.
Be entertained. Headsets aren't just great for games. Enjoy your favorite movies and TV shows with superior quality sound. Then crank up your tunes from music services like Xbox Music [™] or Skype [™] with friends!

Parts and Controls

Xbox One Audio Adapter



Setup and Connections: Xbox One Consoles

The Ear Force XO SEVEN headset is supplied with a convenient Xbox One Audio Adapter that plugs directly into the Xbox One controller (not supplied with the headset). The adapter places game volume, chat volume and mic mute controls right where your thumbs can operate them.

Updating the Xbox One controller firmware



To use the adapter with an Xbox One controller, you first need to update the controller firmware. Perform the following steps.

- 1. Make sure your console is on and you're signed in and connected to Xbox Live.
- Note: It's important to connect to Xbox Live because your console will need the latest system update, which contains the newest controller software. If you've connected recently, your Xbox One is probably already up to date, but you should connect anyway just to be sure. If your console needs an update, you'll be prompted to install one.
- 2. Open the battery compartment on the back of the controller and remove the batteries.
- 3. Plug the Xbox One Audio Adapter into the bottom of your controller.
- 4. Plug in your XO SEVEN (a headset is required to be plugged in so the adapter will turn on).
- 5. Plug the big end of the included USB cable into the port on the side of the console.
- 6. Plug the small end of the USB cable into the top of the controller.
- 7. Instructions to install the update should automatically be displayed. Follow the instructions, and don't disconnect the USB cable while the update is in progress.
- 8. When the update is complete, unplug the USB cable and put the batteries back into your controller.
- 9. Press the Xbox button on the Wireless Controller to turn it on. Your controller is now up-to-date, and you're ready to use your Xbox One Audio Adapter.

Note: You only need to update your controller one time, but if you plan to use the Xbox One Audio Adapter with other Xbox One Controllers, you'll need to do this process for each controller, always make sure that all connections are firmly inserted.

Setup and Connections: Xbox One Consoles

Connecting to the Xbox One controller


1. Insert the microphone boom into the jack on the left earcup of the headset. Use the keyed plug to line up the Mic Boom in the correct orientation.

2. Insert the Xbox One Audio Adapter into the Xbox One Controller.

3. Connect the Headset Breakaway Cable to the 6-pin connector hanging from the XO SEVEN Headset

4. Insert the cable from your Headset Breakaway Cable into the headset jack of the Xbox One Audio Adapter.


NOTE: For reliable sound, confirm that all connections are firmly inserted.




Go to Table of Contents

Setup and Connections: Mobile Sources

1. Remove the microphone boom if currently connected. Disconnect the Headset Breakaway cable and connect the Mobile Adapter cable. This cable includes an In-line Microphone.



2. Insert the cable from your Mobile Adapter Cable into the headphone jack of your mobile device.



Specifications

- Speaker diameter: 50 mm
- Speaker frequency response: 20 Hz 20 kHz
 Condenser microphone frequency response: 100 Hz 10 kHz
- Earcup style: Around-ear
- Sound pressure level: 120 dB @ 1 kHz
- Total harmonic distortion: <1%
- Headphone cable: 3 feet (0.91 m) with stereo 3.5 mm plug
- Weight: 10.6 oz. (301 g)
- Xbox One audio/mic connection: Xbox One Audio Adapter



No sound/low sound

Possible cause	Solution
Volume control turned down	Press the Volume Up button on the Xbox One Audio Adapter If necessary, press the Game button of the Chat/Game Mix.
Loose connector	Confirm that each plug is inserted firmly and fully.

Microphone not working

Possible cause	Solution
Microphone muted	Press the Mic Mute button on the Xbox One Audio Adapter.
Mic boom loose	Confirm that the mic boom is fully inserted into the jack on the left earcup.

No chat volume/low chat volume

Possible cause	Solution
Chat volume control turned down	Press the Chat Button on the Chat/Game Mix of the Xbox One Audio Adapter.
Loose connector	Confirm that each plug is inserted firmly and fully.

If your issue is not resolved by these steps, please visit turtlebeach.com/support

To avoid potential damage to the device, always disconnect all cables before transporting it.

WARNING: Permanent hearing damage can occur if a headset is used at high volumes for extended periods of time, so it is important to keep the volume at a safe level. Over time, your ears adapt to loud volume levels, so a level that may not cause initial discomfort can still damage your hearing. If you experience ringing in your ears after listening with the headset, it means the volume is set too loud. The louder the volume is set, the less time i takes to affect your hearing. So, please take care to listen at moderate levels.

- Before placing a headset on your ears, turn the volume down completely, then slowly increase it to a comfortable level.
- Turn down the volume if you can't hear people speaking near you.
- Avoid turning up the volume to block out noisy surroundings.

Regulatory Compliance Statements for the XO SEVEN Models

Federal Communications Commission (FCC) Compliance Notices

Class B Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15, Subpart B of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canadian ICES Statements

Canadian Department of Communications Radio Interference Regulations

This digital apparatus does not exceed the Class B limits for radio-noise emissions from a digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications. This Class B digital apparatus complies with Canadian ICES-003.

Règlement sur le brouillage radioélectrique du ministère des Communications

Cet appareil numérique respecte les limites de bruits radioélectriques visant les appareils numériques de classe B prescrites dans le Règlement sur le brouillage radioélectrique du ministère des Communications du Canada. Cet appareil numérique de la Classe B est conforme à la norme NMB-003 du Canada.

European Union and European Fair Trade Association (EFTA) Regulatory Compliance

This equipment may be operated in the countries that comprise the member countries of the European Union and the European Fair Trade Association. These countries, listed below, are referred to as The European Community throughout this document:

AUSTRIA, BELGIUM, BULGARIA, CYPRUS, CZECH REPUBLIC, DENMARK, ESTONIA, FINLAND, FRANCE, GERMANY, GREECE, HUNGARY, IRELAND, ITALY, LATVIA, LITHUANIA, LUXEMBOURG, MALTA, NETHERLANDS, POLAND, PORTUGAL, ROMA-NIA, SLOVAKIA, SLOVENIA, SPAIN, SWEDEN, UNITED KINGDOM, ICELAND, LICHTENSTEIN, NORWAY, SWITZERLAND

Declaration of Conformity

Marking by this symbol:

indicates compliance with the Essential Requirements of the EMC Directive of the European Union (2004/108/EC). This equipment meets the following conformance standards:

Safety:	EN 60950-1: 2006 + A11: 2009 + A1: 2010 + A12: 2011 (T-Mark License)
	Also Licensed for Standards:
	IEC 60950-1: 2005 (2nd Edition) + Am 1: 2009 (CB Scheme Report/Certificate),
	UL 60950-1: 2007 R12.11 (NRTL License),
	CAN/CSA-C22.2 No. 60950-1-07 + A1: 2011 (SCC License)
	EN 50332-1: 2000, EN 50332-2: 2003
	Additional licenses issued for specific countries available on request

Emissions: EN 55022: 2010, CISPR: 2008

Immunity: EN 55024: 2010, EN 55024: 2010, EN61000-4-2: (2008-12), EN61000-4-3: (2010-04), EN61000-4-4: (2011-03), EN 61000-4-6: (2005), EN 61000-4-8: (2009-09) These products are licensed, as required, for additional country specific standards for the International Marketplace. Additional issued licenses available upon request. The products are licensed, as required, for additional country specific standards for the International Marketplace. Additional issued licenses available upon request.

Environmental: Low Voltage Directive 2006/95/EC, RoHS 2011/65/EU,

REACH 2006/1907/EC, WEEE 2012/19/EU, Packaging 94/62/EC

Warning!

This is a Class B product. In a domestic environment, this product may cause radio interference, in which case, the user may be required to take appropriate measures.

Achtung!

Dieses ist ein Gerät der Funkstörgrenzwertklasse B. In Wohnbereichen können bei Betrieb dieses Gerätes Rundfunkstörungen auftreten, in welchen Fällen der Benutzer für entsprechende Gegenmaßnahmen verantwortlich ist.

Attention!

Ceci est un produit de Classe B. Dans un environnement domestique, ce produit risque de créer des interférences radioélectriques, il appartiendra alors à l'utilisateur de prendre les mesures spécifiques appropriées.



This symbol on the product or its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste for recycling, please contact your local authority, or where you purchased your product.

Japan Compliance Statement

この装置は、クラスB情報技術装置です。この装置は、家庭環境で使用 することを目的としていますが、この装置がラジオやテレビジョン受信機に 近接して使用されると、受信障害を引き起こすことがあります。 取扱説明書に従って正しい取扱いをして下さい。 VCCI-B

This is a Class B product based on the standard of the VCCI Council. If this is used near a radio or television receiver in a domestic environment, it may cause radio interference. Install and use the equipment according to the instruction manual.

Korean Compliance Statement

B급 기기 (가정용 방송통신기자재) 이 기기는 가정용(B급) 전자파적합기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다.

Class B

(Broadcasting Communication Equipment for Home Use)

As an electromagnetic wave equipment for home use (Class B), this equipment is intended to use mainly for home use and may be used in all regions.

LIMITED ONE YEAR WARRANTY FOR TURTLE BEACH PRODUCTS:

Voyetra Turtle Beach, Inc. ("VTB") warrants to the original end-user purchaser ("Purchaser") that the retail Turtle Beach hardware product herein ("Product") will be free of defects in materials and workmanship for a period of one year from the date of purchase by the Purchaser ("Warranty Period"). Any Extended Warranty or Service Plans purchased through a Retail store are not honored by VTB. The Warranty refers to the repair/replacement of a defective product during this period and not a refund.

This limited warranty is extended only to the original Purchaser of a new product, which was not sold "AS IS". It is not transferable or assignable to any subsequent purchaser. This limited warranty is applicable only in the country or territory where the Product was purchased from an authorized VTB retailer and does not apply to a Product that has been purchased as used or refurbished or was included as part of a non-VTB product.

WARRANTY SERVICE:

In the USA and CANADA Warranty Service is provided by our Turtle Beach USA offices and in all other Countries it is provided by our local International Distributors when available. Refurbished/Recertified products are sold on an AS IS basis with a 90-day Warranty or less in accordance with each vendor's policy.

VTB does not warrant uninterrupted or error-free operation of the Product and is under no obligation to support the Product for all computer operating systems or future versions of such operating systems.

If a defect should occur during the Warranty Period, Purchaser must contact VTB to obtain a Return Merchandise Authorization ("RMA") number on the basis of the dated purchase receipt. Purchaser will be responsible for shipping costs incurred in returning the defective Product to an authorized VTB service center, or to the repair facility located at VTB's corporate headquarters. VTB will not be responsible for other products or accessories included with the defective Product sent to VTB. The RMA number must be clearly indicated on the outside of the package. Packages without an RMA number will be refused by VTB or its representatives and returned to sender at the sender's expense.

In the event of a defect, Purchaser's sole and exclusive remedy, and VTB's sole liability, is expressly limited to the correction of the defect by adjustment, repair, or replacement of the Product at VTB's sole option and expense. VTB owns all Products it has replaced and all parts removed from repaired Products. VTB uses new and reconditioned parts made by various manufacturers in performing warranty repairs and building replacement products. If VTB repairs or replaces a product, the original Warranty Period is not extended, however, VTB warrants that repaired or replacement parts will be free from defects in material and workmanship for a period of thirty (30) days from the date of repair or replacement, or for the remainder of the Warranty Period, whichever is greater.

This warranty does not apply to any Product that has had its serial number altered, removed or defaced, or any Product damage caused by shipping, improper storage, accident, problems with electrical power, abuse, misuse, neglect, ordinary wear, acts of God (e.g. flood), failure to follow directions, improper maintenance, use not in accordance with product instructions, unauthorized modification or service of the Product or damage resulting from the use of the Product with hardware, software or other products not provided by or specifically recommended by VTB.

NOTES:

- Replacement Parts and accessories that are subject to "wear and tear" such as earpads, mic foam covers, talkback cables, etc. have a three (3) month Warranty.

- Replacement Parts for Discontinued Products are sold on an AS IS basis, they are not supported and come with a 30 day Warranty.

THIS LIMITED WARRANTY IS PURCHASER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. TO THE EXTENT PERMITTED BY APPLICABLE LAW, VTB HEREBY DISCLAIMS THE APPLICABILITY OF ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR USE FOR THE PRODUCT. IF SUCH A DISCLAIMER IS PROHIBITED BY APPLICABLE LAW, THE IMPLIED WARRANTY IS LIMITED TO THE DURATION OF THE FOREGOING LIMITED WRITTEN WARRANTY.

IN NO EVENT SHALL VTB BE LIABLE FOR ANY INDIRECT, INCIDENTAL, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES, OR DAMAGES, INCLUDING BUT NOT LIMITED TO ANY LOST PROFITS, DATA, OR LOSS OF USE, ANY THIRD PARTY CLAIMS, AND ANY INJURY TO PROPERTY OR BODILY INJURY (INCLUDING DEATH) TO ANY PERSON, ARISING FROM OR RELATING TO THE USE OF THIS PRODUCT OR ARISING FROM BREACH OF THE WARRANTY, BREACH OF CON-TRACT, NEGLIGENCE, TORT, OR STRICT LIABILITY, EVEN IF VTB HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This warranty supersedes all prior agreements or understandings, oral or written, relating to the Product, and no representation, promise or condition not contained herein will modify these terms. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion or limitation may not apply to you. This warranty gives you specific legal rights. You may also have other rights, which vary from state to state. Any action or lawsuit for breach of warranty must be commenced within eighteen (18) months following the purchase of the Product.



EXCLUSIONS FROM LIMITED WARRANTY:

This Limited Warranty shall not apply and VTB has no liability under this Limited Warranty if the Turtle Beach Product:

- is used for commercial purposes such as "LAN, Call Centers" (including rental or lease);

- is modified or tampered with;
- is damaged by Acts of God, power surge, misuse, abuse, negligence, accident, wear and tear, mishandling, misapplication, or other causes unrelated to defective materials or workmanship;
- serial number is defaced, altered or removed;
- is not used in accordance with the documentation and use instructions; or
- is repaired, modified or altered by other than authorized repair centers.
- is no longer available because it was discarded.



For: Xbox One™ I Mobile



Watch Turtle Beach product training videos at: youtube.com/TurtleBeachVideos



Product support and warranty information: **TurtleBeach.com/support**

© 2014 Voyetra Turtle Beach, Inc. (VTB, Inc) All rights reserved. TURTLE BEACH, The Palm Tree, Voyetra and Ear Force are either trademarks or registered trademarks of VTB, Inc. Skype is a trademark owned by its respective company. This service may not be available in some countries where this product is sold. All other trademarks are the property of their respective owners. Actual product appearance may differ from imagery.