**STEEL INCANDESCENT DESK LAMP**
**FIXING INSTRUCTIONS**

Thank you for buying this quality light fitting. Please read these instructions carefully prior to installation and retain them for future reference. **THIS PRODUCT IS FOR INDOOR USE ONLY.**


**This product is only suitable for connection to a 220-240V~ 50Hz supply and in accordance with I.E.E. Wiring Regulations.**

**If in doubt we recommend you consult a qualified electrician.**

## SAFETY

This fitting is double insulated and must not be earthed. If in doubt, we recommend you consult a qualified electrician.

This product is supplied complete with a 3-amp fuse plug. Our products should not be modified. If any modification is made, including tampering with the plug, it will invalidate the warranty and may render the product unsafe.

**The symbol** 

**on the product indicates that the lamp head must be at least 0.2m (20cm) from the lit surface.**

**THIS PRODUCT CAN GET EXTREMELY HOT DURING USE. CAUTION MUST BE TAKEN WHEN MAINTAINING, ADJUSTING OR CLEANING THE LUMINAIRE**



**WASTE ELECTRICAL PRODUCTS SHOULD NOT BE DISPOSED OF WITH HOUSEHOLD WASTE. PLEASE RECYCLE WHERE FACILITIES EXIST. CHECK WITH YOUR LOCAL AUTHORITY FOR RECYCLING ADVICE.**

## ASSEMBLY INSTRUCTIONS


1. Please note: Do not plug in the lamp until after assembly.
2. Put the upper unit into the base and screw the nut into base then adjust the desired angle by swivelling the arm, see fig.1.
3. Place the bulb (SES Max.40W not included) into the lamp holder, see fig.2.
4. Plug in the lamp. Then turn on the switch of the cable.
5. Carefully place the lamp in the desired location.


## BULB REPLACEMENT

1. Switch off the main power supply.
2. Before replacing the bulb, allow it to cool down for at least 10 minutes.
3. Never touch the bulb with your fingers directly, cover it with a cloth.
4. Loosen the bulb and remove it from the lamp.
5. Replace a new bulb with same voltage and wattage.

## CAUTION

1. Indoor use only.
2. Connect to 220 - 240V, ~ 50Hz.
3. If in doubt about fitting this product, please consult a suitable qualified electrician.
4. The temperature of the luminaire rises very quickly.
5. Do not touch the metal parts or glass of the shade after the light is turned on.
6. Please always adjust the direction by the handle underneath the lamp shade to avoid heat damage to your hand.
7. The external flexible cable or cord of this luminaire cannot be replaced. If the cord is damaged, the luminaire shall be destroyed.




**Model No. :DK-00198**
**Input Voltage: 220-240V~50Hz**
**Bulb: 40W SES (not included)**

**Argos Limited**
**Avebury, 489-499 Avebury Boulevard, Saxon Gate West, Central Milton Keynes,**
**MK9 2NW**

CE