

LET'S GET STARTED



LET'S TALK SAFETY Basic Safety Precautions

This appliance is intended for household use only and NOT for commercial or industrial use.

- Only use the appliance indoors and keep away from wet areas.
- Keep fingers, hair and loose clothing away from moving parts and openings whilst using the appliance.
- This appliance can be operated by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge, if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Always position the appliance on a flat, stable, solid surface and never over stretch the power cord.
- Position the appliance where dirty air is not drawn across your body or head while sitting or sleeping.

X Don't

- Place the appliance near sources of heat, such as stove tops, ovens, radiators, open fires, candles or computers.
- Move or tilt the appliance when in use.
- Use the appliance if the power cord or plug is damaged. Please contact our Customer Service Line on: 0330 026 8455 (Mon-Fri 08:30-18:30 Sat 09:00-17:00).
- Use the appliance if it has been dropped, damaged or left outdoors.
- Run the power cord under rugs, runners or carpets as it can be a trip hazard.
- Pull, carry or trap the power cord under doors or sharp edges.

- Handle the plug or appliance with wet hands.
- Unplug the appliance by pulling on the power cord.
- Use the appliance in an area with toxic/explosive vapours/liquids, oxygen water tanks or near to flammable, combustible materials (lighter fluid, petrol, kerosene, chlorine, bleach and ammonia drain cleaner etc).
- Use the appliance with incorrect voltage as this may result in damage or injury to the user. The correct voltage is listed on the ratings label.
- Use without all filters in place.

✓ Do


- Inspect the appliance regularly and remove any dust/dirt build up as this may affect the airflow.
- Keep all openings/grills clear and free from obstruction and sources of heat, and open flames (including candles). Don't attempt to remove blockages with sharp objects as this may cause damage to the appliance.
- Turn off all controls on the appliance before disconnecting or connecting the power cord.
- Always replace the fuse in the plug with a 13amp fuse. Always protect the power cable from heat.
- Use only CE approved 13amp extension cords, non-approved extension cords may overheat.
- Take care to arrange the extension cord as it can be a trip hazard.
- Always switch off and unplug the appliance before performing maintenance or troubleshooting checks.

Please keep instructions for further use.

Contents

Lets talk safety	2-3
Getting to know your machine	5-6
Air Quality Display	7
Getting started	8
Using your machine	9
Taking care of your machine	10-11
What to do if it goes wrong	12
Getting in touch	13
Technical specifications	14
Accessories	15

Getting to know your machine



Getting to know your machine



Night Mode

Switches power to low and dims the lights on the display panel

Auto mode


Switches fan speed to auto depending on the air quality indoors

Ioniser On/Off

Fan Speed Low/Mid/High

Timer 1/2/4/6/8 hours

Air Quality Display



	Green light	Yellow light	Red light
Status of air quality	Good	Fair	Bad

Dust sensor reading

Getting started

CHECK the air purifier has a filter. Be sure the supplied filter is properly in place and all plastic is removed before turning the unit on.

PLACE the air purifier on a hard surface such as the floor, a table or desk. Be sure the grilles are not blocked by other objects, and there are no candles or flames near the unit.

PLUG IN into nearest standard electrical outlet.

LIGHTLY TOUCH the power button to turn the air purifier on. Touch the power button again to turn the air purifier off.

SELECT THE FAN SPEED to select the speed, lightly touch and release the fan speed button until the desired speed is reached.

ADJUST THE TIMER the unit will turn off once it runs for the selected hours.

Note: The unit will run continuously if all the timer lights are off.

THE CHECK FILTER LIGHT the filter light will illuminate when the filter needs to be replaced. Once replaced, touch and hold the button for several seconds until the filter indicator light goes off.

Note: To order a replacement filter visit vax.co.uk

LIGHTLY TOUCH ION control to switch the ionisation on/off.

HOW THE AIR PURIFIER WORKS

An air purifier draws in room air from its air inlet, lets the air pass through the filter that consists of a pre-filter and HEPA filter inside of the unit, then releases clean purified air from its air outlet. The air purifier repeats this process by moving its internal fan. As air passes through the HEPA filter, it removes airborne particles such as smoke, dust, pollen, and other potentially harmful particles which could cause allergies, asthma and hay fever.

Choosing a Location

To maximize air circulation, position the air purifier at least 50cm away from walls, or any other large objects that could disrupt the airflow. For optimum results close all windows and doors. For more efficient air treatment, place the unit in a central location and make sure the control panel can easily be accessed.

IMPORTANT

This unit is equipped with a smart panel that senses your touch. Heavy pushing of buttons is not recommended.

Using your machine



Press on/off control to switch on/off.

Please note: The unit will automatically turn off once the filter cover is removed. The power button will flash and the unit will not turn on until the filter cover is replaced.



Press timer control. The timer light will illuminate showing the time selected: 1 hour, 2 hours, 4 hours, 6 hours or 8 hours.

The air purifier will turn off once the selected time has completed.

The air purifier will continuously run when all indicator lights are off.

CAUTION



Press fan control. The fan speed indicator light will illuminate displaying selected speed.

Auto = The fan speed is automatically adjusted.

Night mode = Low speed with limited light on the product for easy sleeping. Press the button for night mode. It takes 10 seconds for the lights to go off.

L = Low fan speed

M = Medium fan speed

H = High fan speed.



The control panel is touch sensitive, lightly press controls.



Press ION control to switch ioniser on/off.



Filter replacement indicator. Press for 5 seconds to reset filter replacement indicator once filter is changed.

Taking care of your machine: replacing the filter

Replace your main filter every 3-6 months depending on usage.



When the filter light is illuminated, turn the unit off and unplug it from the power outlet.



Remove filter cover.



Slide the filter lock to the left. (Unlock position).



Carefully pull the used filter out. Slide replacement filter into the unit.

Ensure the filter is in the upright position with the open end facing upwards as indicated above.



Lock the filter into place by sliding the filter lock to the right Refit the filter cover.



To reset the system, hold the filter replacement indicator down until you hear a beep.

IMPORTANT

Unplug and switch off the air purifier before performing maintenance or troubleshooting checks.

The filters will need replacing more often when using the air purifier in smoke filled or dusty environments.



DO NOT WASH FILTERS.

To reduce the risk of injury from moving parts, unplug before servicing.

CAUTION



What to do if it goes wrong

Problem

Solution

Why does my air purifier have no power?

- The plug may not be fully pushed into the electrical socket.
- Check the fuse in the plug. If this needs replacing, always replace with a 13amp British fuse.
- The filter cover may not be secure. Check the filter cover is securely fitted. Go to 'Taking care of your machine'.
- The filter may not be fitted correctly. Check the filter. Go to 'Taking Care of your machine'.
- Timer may have finished. Re-set the timer. Go to 'Using your machine'.

Why isn't my fan turning?

• Fan speed may be set to L = Low. Change fan speed to desired setting. Go to 'Using your machine'.

Why is my air purifier making an excessive noise?

- The air grills may be blocked. Make sure the air inlet is free from any obstruction.
- The filter may need replacing. Go to 'Taking care of your machine'.

Why isn't my remote control working?

- Aim the remote control towards the control panel on the front of the unit and press the power button.
- The battery may need replacing. Always replace with a lithium battery.

We're here if you need us

Online: vax.co.uk/support

Call: (UK) 0330 026 8455 (ROI) 1-800 928 308

Monday-Friday 8:30am to 6:30pm, Saturday 9:00am to 5:00pm*

Alternatively, you can write to us at:

Vax Ltd, Plot 302, Stonebridge Cross Business Park, Hampton Lovett, Droitwich, WR9 OLW, UK

Getting in touch...

It's quick and easy to register for your FREE guarantee[†]

Online at: vax.co.uk/guarantees

Please retain your original receipt for proof of purchase.

^{*} Calls are charged at the UK local rate. Please make a note of the serial number and model number of the air purifier before calling. † Registration required. Terms and conditions apply.

Technical specifications

Input voltage	AC220V-240V
Rated frequency	50Hz
Wattage	60W
Weight	8.25kg

Accessories

Filter Kit (Type 141) 1-1-137441



GET IN TOUCH

S 0330 026 8455 @ info@vax.co.uk vax.co.uk VaxVacuums ② @VaxUK

EEC Statement of Compliance: Manufacturer/EEC importer: Vax Limited, hereby on our own responsibility, declare that the ACAMV101 manufactured in compliance with the following Directives: Safety: 2006/95/EC Low Voltage Directive. EMC: 2004/108/EC Electromagnetic Compatibility Directive.

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice. © 2015 Vax Limited. All rights reserved. The VAX trade mark and Vax lozenge is the property of Techtronic Floor Care Technology Ltd and is registered in the EU and may be pending or registered in other countries.

