
High Back Cube Chair

Assembly Instructions - Please keep for future reference

459/4598

Please open all 3 boxes before commencing assembly of the set.
This box contains 2 chairs.



Important:
Do not fully tighten all nuts until assembly is complete.

Dimensions

Width - 53cm
Depth - 53cm
Height - 66cm

Important Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 0345 640 0800
For further assistance please visit http://www.argos-support.co.uk/
Retailer: Argos
Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW

Issue 2: 05/09/15

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product during assembly, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the chair or your floor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers for inserting screws , as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

• Maximum safe seated weight: 110kgs.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

• Make sure each studs matches the corresponding figure to ensure correct assembly.

• From time to time check that there are no loose nuts on this chair.


•Assemble all parts and nuts loosely during assembly,only once the product is complete should you fully tighten the nuts.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Components-Parts

If you have damaged or missing components, call the Customer Helpline: 03456 400 800
For further assistance please visit http://www.argos-support.co.uk/


Please check you have all the parts listed below




1 Left panel x 1




2 Back panel x 1




3 Right panel x 1




4 Seat panel x 1



5 Seat cushion x 1



6 Back x 1




7 Back cushion x 1

Components-Fittings

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly.In some cases more fittings may be supplied than are required.

Ⓐ	Ⓑ	Ⓒ	Ⓓ	Ⓔ
 Stud x 9 M6x45	 Washer x 11 M6	 Nut x 9 ∅ 6X1.0	 Screw x 2	 Screw cap x 2

Tools required




1xWrench



1 x Allen key

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step1

Fit seat panel to back panel

Use stud Ⓐ,washer Ⓑ, and nut Ⓒ to fix the seat panel 4 to back panel 2 by wrench.




Important:
Do not fully tighten nuts at this stage.

Step 2

Fit left and Right **panel to back panel**

Use stud Ⓐ,washer Ⓑ, and nut Ⓒ to fix the left panel 1 and right panel 3 to back panel 2 by wrench.




Important:
Do not fully tighten nuts at this stage.

Assembly Instructions

Step3

Fit back to the chair


Use screw Ⓓ washer Ⓑ to fix the back 6 to the chair, then cover the screw with the screw cap .



Step 4

Tighten all the nuts

Tighten all the nuts, place the cushion on the chair and turn the chair to its upright position.



Important:

After all the parts are positioned, you can now fully tighten all nuts fixed on previous steps.

Assembly is complete

If you need help or have damaged or missing parts, call the Customer Helpline: 0345 640 0800
For further assistance please visit http://www.argos-support.co.uk/
Retailer: Argos
Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW