


Luna TV Unit

Assembly Instructions - Please keep for future reference

464/9883

hygena



Dimensions

Width - 90cm
Depth - 40cm
Height - 45.5cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the

Customer Helpline: 0345 6400 800

Issue 1-15-10-15



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

Check you have all the components and tools listed on pages 2 and 3.

Remove all fittings from the plastic bags and separate them into their groups.

Keep children and animals away from the work area, small parts could choke if swallowed. Make sure you have enough space to layout the parts before starting.

Assemble the item as close to its final position (in the same room) as possible.

Assemble on a soft level surface to avoid damaging the unit or your floor.

Assembly requires 2 people.

Do not stand or put excessive weight on the product, this could cause damage.



We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers and Allen keys.

Dispose of all packaging carefully and responsibly.

Solid wood / Real wood veneers

This product has been finished using natural materials. As a living material, you may notice some variation in the grain and colour shade between the different components.

Unlike a synthetic or man-made material which has a uniform finish, a feature of natural wood is its variation in grain and colour. We wish to reassure you that this is quite normal and is not the result of any manufacturing fault.

Where sheets of wood are joined together, a line may be detected. Again, this is normal and is not an imperfection.

The natural finish should be cared for by the periodic application of a good quality 'wax' based domestic furniture polish (Not silicone!!). Occasional / small spills should be removed immediately using a damp cloth.

Do not allow hot articles to come into contact with the surface, as damage will occur!

Care and maintenance

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.


From time to time check that there are no loose screws on this unit.

This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Components - Parts

If you have damaged or missing components,
call the **Customer Helpline**: 0345 6400 800


Please check you have all the parts listed below




1 Top (90x40x2.5cm)



2 Side frame (left)
(43x37x5cm)



3 Side frame (right)
(43x37x5cm)




4 Back panel
(77.8x35.8x0.3cm)



5 Front stretcher
(74x5x1.5cm)




6 Rear stretcher
(74x5x1.5cm)




7 Drawer front (73.7x16x1.5cm)




8 Drawer back (70.6x12x1.2cm)



9 Shelf (74x36.5x1.5cm)




10 Drawer base
(71.3x29.7x0.3cm)



14 Apron
(74x5x2.5cm)



11 Drawer support
(28.8x4x1.2cm)



12 Drawer side (left)
(30x12x1.2cm)






13 Drawer side (right)
(30x12x1.2cm)

Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 0345 6400 800**

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A</p>  <p>Wooden dowel x 14 (6X30mm)</p>	<p>B</p>  <p>Metal dowel x 17</p>	<p>C</p>  <p>Large locking nut x 8</p>
<p>D</p>  <p>Small locking nut x 9</p>	<p>E</p>  <p>Screw x 19 (2.5x10mm)</p>	<p>F</p>  <p>Drawer runners x 2</p>
<p>G</p>  <p>Screw x 4 (3x12mm)</p>	<p>H</p>  <p>Handle x 2</p>	<p>J</p>  <p>Screw x 8 (4x30mm)</p>
<p>K</p>  <p>Screw x 2 (4x18mm)</p>	<p>L</p>  <p>Bolt x 2 (4x10mm)</p>	

Tools required




Ruler/tape measure



Phillips screwdriver
(Not supplied)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1

Preparing panels


Place top **1**, side frames **2** and **3**, and drawer front **7** flat onto the floor with the fixing holes facing up.

Screw metal dowels **B** into all panels as shown.

Note: Screw metal dowels as far as shown. Do not overtighten.

Insert wood dowels **A** into side frames **2** and **3** and top **1** as shown.

Assemble apron **14** to top **1** using screws **J**.




Step 2

Assembling drawer runners

Assemble drawer runners **F** to side frames **2** and **3** using screws **G**.

Note: The drawer runners should be fixed through the holes shown. It will be necessary to extend/close the runners to gain access to the holes.



Assembly Instructions

Step 3

Assembling shelf and stretchers



a: Locate shelf **9** into position

Note: Ensure the fixing holes are facing down.

Insert large locking nuts  into the underside of shelf **9** as shown.

Turn locking nuts clockwise to secure.

a:





b: Locate front and rear stretchers **5** and **6** in the locations shown.

Note: Ensure the fixing holes are facing down.

Insert large locking nuts  into both stretchers as shown.

Turn locking nuts clockwise to secure.

b:




Assembly Instructions

Step 4

Assembling side frame

Locate right side frame **3** into position.

Secure using large locking nuts **C** as shown.



Step 5

Assembling top


With help, carefully stand the unit upright.

Insert wood dowels **A** into the top of side frames **2** and **3**.

Locate top **1** into position.

Insert small locking nuts **D** into side frames **2** and **3**.

Turn locking nuts clockwise to secure.



Assembly Instructions


Step 6

Fitting back panel

Carefully turn the unit over onto its face.

Locate back panel **4** into position with the cable access hole at the top as shown.

Secure using screws **E**



Assembly Instructions

Step 7

Assembling drawer

a: Locate drawer sides **12** and **13** and support **11** onto drawer front **7**.

Note: Ensure the grooves on all panels align at the bottom.


Insert small locking nuts **D** into the drawer sides and support as shown.

Turn locking nuts clockwise to secure.

b: Slide drawer base **10** into the grooves.

c: Assemble drawer back **8** using screws **J**.

d: Fit handles **H** to drawer front **7** using screws **K**.



Assembly Instructions



Step 8

Locating drawer

With help, turn the whole unit upright.

Extend the drawer runners fully out.

Locate the drawer onto the runners and secure using screws **L** as shown.



Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline: 0345 6400 800**
Home Retail Group, 489-499 Avebury Boulevard, Saxon Gate West, Central Milton Keynes, MK9 2NW