
Amelie



Spare Parts

www.argos-support.co.uk

Help@ClickSpares.co.uk

0370 112 1928

Customer Support

0345 640 2020


Safety and Care Advice

Product Details

White: 470 / 4285
Grey: 502 / 9189

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- This product has been constructed to be used in the domestic environment only and not for commercial purposes.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.



- We do not recommend the use of power drill/drivers for inserting screws as this could damage the unit. Only use hand screwdrivers.
- Parts of the assembly will be easier with 2 people.
- Dispose of all packaging carefully and responsibly.

Care and maintenance


- Use a dry cloth to clean the product, furniture polish is not recommended.
- From time to time check that there are no loose screws, nuts or bolts. If there are please re-tighten.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Additional Guidance

- Assemble all parts and bolts loosely during assembly, only once the product is complete should youfully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightend properly.
- This product is compliant BS 4875-7 and EN 14749.

Sainsbury´s Supermarkets Ltd and Argos Limited, London EC1N 2HT, UK. Sainsbury´s (NI) Ltd and Argos (N.I.) Ltd, Forestside Shopping Centre, Upper Galwally, Belfast, BT8 6FX, UK.

Panels




1 Top panel
(450 x 353 mm)



2 Front left foot
(535 x 62 mm)



3 Back left foot
(535 x 52 mm)




4 Left side panel
(266 x 190 mm)



5 Front right foot
(535 x 62 mm)




6 Back right foot
(535 x 52 mm)




7 Right side panel
(266 x 190 mm)




8 Front rail
(340 x 60 mm)




9 Back rail
(340 x 190 mm)




10 Drawer front
(336 x 124 mm)




11 Drawer right side
(265 x 88 mm)



12 Drawer left side
(265 x 88 mm)




13 Drawer back panel
(285 x 88 mm)



14 Drawer bottom
(299 x 264 mm)

Fittings

A 

6X30 Wooden Dowel x 08

10000

B 

3,5x30 Screw x 04

9005

C 

3,5x14 Screw x 10


9001B

D 


Metal Dowel x 22

E 

Locking nut x 22

F 

Drawer runner x 01

G 


6,0x10 Screw x 04

9101

H 

3,5x12 Screw x 01

9000G

I 

Anti tipping x 01

3006

J 

M4X25 Screw x 01


9123

K 

Knob x 01


L 

Plastic Bracket x 02

M 

Plastic wedge x 03


Tools required



Ruler / tape measure




Phillips screwdriver (small & medium)



Small hammer

1



F





Drawer runner x 01


G



6,0x10 Screw x 04









2

D

Metal Dowel x 14






3

E

Locking Nut x 08




4

A

6X30 Wooden Dowel x 08

E

Locking Nut x 03




Rotate Product

5

E



Locking Nut x 03



6

D




Metal Dowel x 04

H





3,5x12 Screw x 01

I



Anti tipping x 01






7

E





Locking Nut x 04



WARNING!

IN ORDER TO PREVENT OVERTURNING THIS PRODUCT MUST BE USED WITH THE WALL ATTACHMENT DEVICE PROVIDED





A Guide to - Wall Monting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



-these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.

Important: When drilling into wall always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


Hints:

1. General rule Always use a larger screw and wall plug if you are not sure.
2. Ensure you use the recommended drill bit to the wall plug and hole size.
3. Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
4. Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
5. Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

Nº.1 **"General Purpose" wall plug**




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general porpose wall plugs can be used.

Nº.2 **"Plasterboard" wall plug**




For use when attaching light loads on to plasterboard partition.

Nº.3 **"Cavity fixing" wall plug**




For use with plasterboard partitions or hollow wooden doors.

Nº.4 **"Cavity Fixing-Heavy Duty" wall plug**




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

Nº.5 **"Hammer Fixing" wall plug**



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

Nº.6 **"Shield Anchor" wall plug Heavy Loads**



For use with heavier loads such as TV & Hifi speakers and satellite dishes etc.

Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.


Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.


9

D



Metal Dowel x 04






10


E



Locking Nut x 04




11



12


B

3,5x30 Screw x 04





13

C 
3,5x14 Screw x 06

F 
Drawer runner x 01

L 
Plastic Bracket x 02







14

J 
M4X25 Screw x 01


K 
Knob x 01




15



16






If necessary, use the plastic wedge (M) to level your product with the floor.

17


C




3,5x14 Screw x 04



Lateral adjustment



Height adjustment



After adjusting the height of the drawers, fix the drawer rails with the screws (C) as shown in the image above.