



MacBook Pro

Essentials

Contents

- 4 **Chapter 1: Welcome**
- 4 Say hello to MacBook Pro

- 5 **Chapter 2: MacBook Pro at a glance**
- 5 Take a tour
- 6 What's included
- 7 Trackpad
- 8 Keyboard

- 9 **Chapter 3: Get started**
- 9 Set up
- 11 Find your way around
- 13 Quickly open apps
- 13 Charge the battery
- 14 Migrate your data

- 15 **Chapter 4: MacBook Pro basics**
- 15 Use your MacBook Pro
- 15 Access all your content, anywhere with iCloud
- 16 Use your MacBook Pro and iOS devices together
- 19 Wirelessly share, print, and play
- 21 Make video calls with FaceTime
- 21 Use an external display
- 22 Back up and restore
- 23 Get answers

- 24 **Chapter 5: Apps**
- 24 About apps
- 24 Safari
- 25 Mail
- 26 Calendar
- 27 Notes
- 28 Messages
- 29 Maps
- 30 Spotlight
- 31 iTunes
- 32 Photos, iMovie, and GarageBand
- 33 Pages, Numbers, and Keynote

34	Chapter 6: Safety, handling, and support
34	Important safety information
37	Important handling information
38	Understanding ergonomics
38	Apple and the environment
39	Learning more, service, and support
40	FCC compliance
40	Canadian regulatory compliance
41	Europe—EU Declaration of Conformity
41	ENERGY STAR® Compliance Statement
42	Disposal and recycling information
43	Software License Agreement

Welcome

1

Say hello to MacBook Pro



Take a look around. Want a quick tour of the features of your MacBook Pro? Go to [Take a tour](#).

Get started. Press the power button and you're up and running. For tips, see [Set up](#).

See what you can do. Make video calls with FaceTime, share files with AirDrop, sync your important documents, photos, music, apps, contacts, and calendars across devices with iCloud and Handoff, and use your iOS device and your MacBook Pro together to make and receive phone calls and texts, or to create an instant hotspot. Learn more in [Use your MacBook Pro](#).

Unleash your creativity. Edit HD video with Final Cut Pro X, make music with GarageBand, create presentations with Keynote, and more. Go to [About apps](#) to get inspired.

MacBook Pro at a glance

2

Take a tour

The MacBook Pro with Retina display is packed with advanced technologies in a remarkably thin and light design. It's both powerful and portable, so you can take it with you and create when you're on the go. This guide is for both the 13-inch and 15-inch MacBook Pro with Retina display models.



- *MagSafe 2 power port:* Guide the MagSafe connector into the MagSafe 2 port for a fast and sure connection. The magnetic connector also allows the power cord to break away cleanly if there's undue tension.
- *Thunderbolt 2 ports:* This ultrafast and ultraflexible technology lets you connect high-speed peripherals such as RAID arrays, external displays, and docking stations. Thunderbolt to FireWire and Thunderbolt to Gigabit Ethernet adapters (sold separately) offer increased expandability and connectivity.
- *USB 3 ports:* Connect an iPad, iPhone, iPod, digital camera, camcorder, external storage, or printer quickly and easily. The MacBook Pro USB 3 ports support USB 3 and USB 2 devices.
- *Headphone port:* Plug in stereo headphones or a digital 5.1 surround-sound speaker system and experience high-quality sound while watching movies or listening to your favorite music.




- *SDXC card slot:* Easily transfer photos, videos, and data to and from your MacBook Pro, with the latest high-capacity SD cards.
- *HDMI port:* Allows easy connection to HDTVs and projectors. Play movies, presentations, and more, with HD resolution and multichannel audio on your HDTV.



- **FaceTime HD camera:** Make FaceTime video calls or take pictures and video. If the light is glowing, the camera is on.
- **Dual microphones:** The dual microphones reduce background noise and optimize microphone performance. On the 13-inch MacBook Pro, the microphones are located on the left side, next to the headphone port.
- **Power button:** Turn your MacBook Pro on or off, or put it to sleep.
- **Force Touch trackpad:** Control your MacBook Pro with gestures. The entire trackpad surface acts as a button so you can easily click anywhere. For more on using gestures, see [Trackpad](#).


What's included

To use your MacBook Pro, you need these two simple accessories, included in the box:



60W or 85W MagSafe 2 Power Adapter: To charge your MacBook Pro, use the included power adapter. Make sure the AC plug is fully inserted into the power adapter and the electrical prongs on the AC plug are fully extended, then plug the adapter into a power outlet. The magnetic connector helps guide the plug into the port and disconnects easily.

When the adapter is connected, an LED on the magnetic connector lights up. An amber light shows that your MacBook Pro is charging, and a green light shows that it has a full charge.



AC power cord: To extend the reach of your power adapter, attach the included AC power cord. Then plug the three-prong end of the AC power cord into a power outlet.









Adapters and other accessories are sold separately at store.apple.com or your local Apple Retail Store. Be sure to review the adapter or accessory documentation to make sure you're choosing the right product for your MacBook Pro.

Trackpad


You can do a lot on your MacBook Pro using simple trackpad gestures—scroll through webpages, zoom in on documents, rotate photos, and more. And now with the Force Touch trackpad, pressure-sensing capabilities add an entirely new level of interactivity.

The trackpad senses how hard you press, giving you more options and greater control with every touch. It also provides feedback—if you drag or rotate objects, you feel a subtle vibration when they're aligned, letting you work with greater precision.

Here are some common gestures:

	Click: Press anywhere on the trackpad. Or enable “Tap to click” in Trackpad preferences, and simply tap.
	Force click: Click and then press deeper. You can use Force click to look up more information—click a word to see its definition, an address to see a preview in Maps, and more.
	Secondary click (right click): Click with two fingers to open shortcut menus. If “Tap to click” is enabled, tap with two fingers.
	Two-finger scroll: Slide two fingers up or down to scroll.
	Pinch to zoom: Pinch your thumb and finger open or closed to zoom in or out of photos and webpages.
	Swipe to navigate: Swipe left or right with two fingers to flip through webpages, documents, and more—like turning a page in a book.
	Open Launchpad: Quickly open apps in Launchpad. Pinch closed with four or five fingers, then click an app to open it.
	Swipe between apps: To switch from one full-screen app to another, swipe left or right with three or four fingers.















Customize your gestures. Choose Apple menu () > System Preferences or click the System Preferences icon in the Dock, then click Trackpad.



Learn more about each gesture, set the pressure you prefer to use, select whether to use pressure-sensing features, and customize other trackpad features in Trackpad preferences.

Keyboard



- **Function (fn) key:** Hold this key while you press a function key (F1 to F12) to make the key do its assigned action. To learn how to customize function keys, click the Help menu in the menu bar, then search for “function keys” in Mac Help.
- **Brightness keys (F1, F2):** Press  or  to increase or decrease the brightness of the screen.
- **Mission Control key (F3):** Press  to view what’s running on your MacBook Pro, including all your spaces and open windows.
- **Launchpad key (F4):** Press  to instantly see all the apps on your MacBook Pro. Click an app to open it.
- **Keyboard illumination keys (F5, F6):** Press  or  to increase or decrease the brightness of the keyboard.
- **Media keys (F7, F8, F9):** Press  to rewind,  to play or pause, or  to fast-forward a song, movie, or slideshow.
- **Mute key (F10):** Press  to mute the sound coming from the built-in speakers and headphone port.
- **Volume keys (F11, F12):** Press  or  to increase or decrease the volume of sound coming from the built-in speakers and headphone port.
- **Power button:** Press and hold  for 3 seconds to turn your MacBook Pro on or off. Press  to put MacBook Pro to sleep.

Get started

3



Set up


The first time you turn on your MacBook Pro, Setup Assistant walks you through the simple steps needed to start using your new Mac.




To get the most out of MacBook Pro, be sure to connect to Wi-Fi and turn on Bluetooth®, get an Apple ID, and sign in to iCloud. You can do these steps quickly and easily with Setup Assistant—but if you want to do them later, here's how:



Connect to Wi-Fi. Click the Wi-Fi status icon  in the menu bar, then choose a Wi-Fi network and enter the password, if necessary.

If you don't see the Wi-Fi status icon , choose Apple menu () > System Preferences, then click Network. Select Wi-Fi in the list on the left, then select "Show Wi-Fi status in menu bar."





Turn off Wi-Fi. Click the Wi-Fi status icon  in the menu bar, then choose Turn Wi-Fi Off.

Turn Bluetooth on or off. Click the Bluetooth icon  in the menu bar, then choose Turn Bluetooth On or Turn Bluetooth Off.

If you don't see the Bluetooth icon , choose Apple menu () > System Preferences, click Bluetooth, then select "Show Bluetooth in menu bar."

Get an Apple ID. Your Apple ID is the account you use for just about everything you do with Apple, including buying music, movies, and TV shows from the iTunes Store, downloading apps from the App Store, and storing your content in iCloud.

If you don't already have an Apple ID, you can create one in iCloud preferences. Choose Apple menu () > System Preferences. Click iCloud, then click Create Apple ID.



Set up iCloud on your Mac. After you have an Apple ID, it's easy to set up iCloud on your Mac. Choose Apple menu () > System Preferences and click iCloud. In the window that appears, enter your Apple ID and password. Then select the features you want to use.

Important: Be sure to use the same Apple ID for iCloud on all your devices.

For more information about setting up iCloud, click the Help menu in the menu bar, then search for “set up iCloud” in Mac Help.



With iCloud, you can store all your content—documents, movies, music, photos, and more—in the cloud, and access them anywhere you go. To find out more about what you can do with iCloud and MacBook Pro, see [Access all your content, anywhere with iCloud](#).

Find your way around

Overview

Start at the desktop. It's home base for your Mac—where you can organize your files, quickly open apps, search for anything on your Mac and beyond, and more.



Finder

Use the Finder to organize and find all your files—including documents, images, movies, and music—or to quickly preview a file.

Open a Finder window. Click the Finder icon in the Dock, at the bottom of the screen.

Dock

The Dock, at the bottom of the screen, is a convenient place to keep the apps and documents you use frequently. You can make the Dock larger or smaller, add or remove items, move it to the left or right side of your screen, or even set it to hide when you're not using it.

Add an item to the Dock. Drag the item and drop it where you want it. Place apps to the left of the line in the Dock, and files or folders to the right.

Remove an item from the Dock. Drag it out of the Dock. The item isn't removed from your Mac—just from the Dock.

Change how the Dock looks. Choose Apple menu (🍏) > System Preferences, then click Dock.


System Preferences

Make your MacBook Pro perfect for you. You can use Energy Saver preferences to change sleep settings, use Desktop & Screen Saver preferences to add a desktop background or choose a screen saver, and more.




Open System Preferences. Choose Apple menu (🍏) > System Preferences, or click the System Preferences icon in the Dock. Then click the preference you want to set.

Spotlight

Find anything on your MacBook Pro—and beyond. Spotlight provides results from your Mac as well as other sources like Wikipedia, Maps, weather, stocks, and sports.

Search for anything. Click  at the top-right of the screen or press Command–Space bar, then start typing.

Menu bar

The menu bar runs along the top of the screen. Use the icons and menus there to connect to a Wi-Fi network, check your Wi-Fi status , change the volume , check your battery charge , and more.

Help

You can find answers to many of your questions in the Help menu.

Get help. Click the Help menu in the menu bar, then type a question or term in the search field. Choose a topic from the results list, or choose Show All Help Topics to see all results.

To get help using an app, just click the Help menu while you're using the app.

Quickly open apps

Your MacBook Pro comes with apps for all the things you love—browsing the web, checking email, creating documents and presentations, sharing photos, enjoying movies, and more. You can quickly open apps from Spotlight, from the Dock, or with Launchpad.



Open an app. Click the app's icon in the Dock, or click the Launchpad icon in the Dock and click the app you want. You can also search for the app using Spotlight, then open the app directly from your Spotlight search results.

Organize apps in Launchpad. Drag an app onto another app to create a folder. Drag more apps to the new folder to add them. To remove an app from a folder, just drag it out.

Get more apps. Click the App Store icon in the Dock. When you download apps from the Mac App Store, they appear in Launchpad. To quickly get updates to apps and OS X, click Updates in the Mac App Store.

Charge the battery

The battery in your MacBook Pro recharges whenever MacBook Pro is connected to power.



Charge the battery. Connect your MacBook Pro to a power outlet using the included cable and 60W (13-inch model) or 85W (15-inch model) MagSafe 2 Power Adapter. The battery recharges more quickly when the computer is shut down or in sleep.

Check the battery's charge. Look at the battery status icon at the right of the menu bar to see the battery level or charging status. Click the icon to show how much power you have left if you keep using the apps, peripheral devices, and system settings you're now using.



Charging



Charged

Conserve battery power. To extend battery life on a given charge, reduce the display brightness, close apps, and disconnect peripheral devices you're not using. You can change your power settings in Energy Saver preferences (click the System Preferences icon in the Dock, then click Energy Saver). If your MacBook Pro is in sleep or standby mode when a device is connected to it, the device's battery may drain.

For more information about the internal rechargeable battery in your MacBook Pro, and for conservation and performance tips, go to www.apple.com/batteries.



Migrate your data



It's easy to move your files and settings from another Mac or a PC to your MacBook Pro. You can transfer the data when you first set up your MacBook Pro, using Setup Assistant. If you want to transfer data later, you can use Migration Assistant to wirelessly copy your files from another Mac, a PC, or a Time Machine backup, using an AirPort base station (available separately).

You can transfer data over a wireless network if both computers are connected to the same network.

Use Migration Assistant. Open a Finder window, then go to Applications > Utilities and double-click Migration Assistant. Follow the onscreen instructions to transfer information using Wi-Fi. For more information, see [Move your content to your new Mac](#).

Copy files from a storage device. Connect the device to the USB port  or Thunderbolt port  on your MacBook Pro, then manually drag files to your MacBook Pro.

For more information about Time Machine backups, see [Back up and restore](#).

MacBook Pro basics

4

Use your MacBook Pro

MacBook Pro is built to go everywhere you go. And its built-in features—along with iCloud and OS X El Capitan—make it easy to bring your content wherever you are. You can video chat, share, print, and back up your data—and do it all wirelessly. Find out more about how to make the most of your MacBook Pro.

Access all your content, anywhere with iCloud



iCloud is the easiest way to make sure all your important content is everywhere you are. iCloud stores your documents, photos, music, apps, contacts, calendars, and more, so you can access them anytime you're connected to Wi-Fi.

iCloud also keeps everything up to date on all your devices. So if you have an iPhone or iPad, just sign in to iCloud using the same account and you'll have everything you need on any device.



Here's some of what you can do with iCloud.

Save your files in iCloud Drive. Store any file in iCloud Drive, then access it anywhere—from work or home, or on the road. To save a file to iCloud Drive, open a Finder window, then drag the file to iCloud Drive in the sidebar. You can organize and tag files in iCloud Drive just like the files on your MacBook Pro. And when you edit a file in iCloud Drive, your edits show up on any device you use with iCloud.

Share purchases with Family Sharing. Let up to six family members share their iTunes Store, App Store, and iBooks Store purchases—even if they all use different iCloud accounts. Pay for family purchases with one credit card, and approve kids' spending right from your MacBook Pro or iOS device. Plus, share photos, a family calendar, reminders, and locations. To set up Family Sharing, click the System Preferences icon in the Dock, click iCloud, then click Set Up Family.

Share photos using iCloud Photo Sharing. Share photos and video with just the people you choose, and let them add their own photos, video, and comments. To get started, click the System Preferences icon in the Dock, click iCloud, then click Photos.

Enjoy your purchases anywhere. When you're signed in to iCloud, purchases you've made from the iTunes Store, Mac App Store, and iBooks Store are available on your MacBook Pro at any time. So all your music, movies, books, and more are available wherever you go.

Locate your MacBook Pro with Find My Mac. If your MacBook Pro is stolen, you can easily locate it on a map, lock its screen, or even erase its data remotely. To turn on Find My Mac, click the System Preferences icon in the Dock, click iCloud, then click Find My Mac.


Your iCloud account comes with 5 GB of free storage, and your purchased music, apps, TV shows, and books don't count against your available space.

For more information about what you can do with iCloud, go to Mac Help and search for iCloud, or go to www.apple.com/icloud.

Use your MacBook Pro and iOS devices together


Overview

Your MacBook Pro and iOS devices work together seamlessly, expanding the power and portability of your MacBook Pro even more. Just sign in to your iCloud account on your MacBook Pro and your iOS devices, and whenever your MacBook Pro and devices are near each other, you can use them together in amazing ways.



Phone calls

You can take calls—and make them—right from your MacBook Pro.




Take a call. When someone calls your iPhone, click the notification that appears on your Mac screen. Your Mac becomes a speakerphone.

Make a call. Click a phone number in a Spotlight search, or in an app such as FaceTime, Contacts, Safari, or Calendar.


Text messages

Send and receive SMS and MMS text messages right from your MacBook Pro. When friends text you, you can respond with whichever device is closest. All the messages that appear on your MacBook Pro also appear on your iPhone or iPad.



Instant Hotspot

If you're on the go and don't have a Wi-Fi connection, your MacBook Pro can connect to the Internet using Personal Hotspot on your iPhone (with iOS 8 or later) or iPad (cellular models with iOS 8 or later).

Connect to your device's Personal Hotspot. Click the Wi-Fi status icon  in the menu bar, then choose your iPhone or iPad from the list of devices that appear. (You don't need to do anything on your device—MacBook Pro can connect automatically.)

Check the status of your connection. Look in the Wi-Fi status menu to see the strength of the cellular signal.

When you're not using Personal Hotspot, your iOS device automatically disconnects to save battery life.

Handoff

With Handoff, you can pick up on one device where you left off on another. Work on a presentation on your MacBook Pro, then continue on your iPad. Or start an email message on your iPhone, then finish it on your MacBook Pro. When your MacBook Pro and devices are near each other, an icon appears in the Dock whenever an activity is being handed off; click it to pick up right where you left off.



Turn on Handoff on your MacBook Pro. Click the System Preferences icon in the Dock, click General, then select "Allow Handoff between this Mac and your iCloud devices."

Turn on Handoff on your iOS device. Go to Settings > General > Handoff & Suggested Apps, then tap to turn on Handoff. If you don't see the option, your iOS device doesn't support Handoff.

Note: To use Handoff, you need an iPhone 5 or later, iPod touch (5th generation) or later, or iPad (4th generation) or later with iOS 8 or later installed. Make sure your MacBook Pro and iOS device are signed in to the same iCloud account.

Handoff works with Safari, Mail, Calendar, Contacts, Maps, Messages, Notes, Reminders, Keynote, Numbers, and Pages.

To learn more about using Instant Hotspot, messages, phone calls, and Handoff with your MacBook Pro, open Mac Help. Or go to www.apple.com/osx/continuity.


Wirelessly share, print, and play

Overview


Quickly share your files, clippings, and webpages using AirDrop. Print wirelessly to an AirPrint-enabled printer from apps such as Mail and Safari. Stream your music, photos, and video to Apple TV with AirPlay.

AirDrop

AirDrop makes sharing files between Mac and iOS devices easy.



Send a file from the Finder. Click the Finder icon in the Dock, then click AirDrop in the sidebar on the left. When the person you want to send a file to appears in the window, drag the file to them.

Send files from an app. While using an app like Pages or Preview, click the Share button  and choose AirDrop.

Control who can send items to you using AirDrop. Click the Finder icon in the Dock, click AirDrop in the sidebar, then click the "Allow me to be discovered by" menu and choose an option.

When you send a file to someone, they can choose whether to accept the file. When someone sends you a file, you can find it in the Downloads folder on your MacBook Pro.

Print wirelessly

When you print from an app, just select a printer from the Nearby Printers list in the Print dialog. You can use AirPrint to print wirelessly to:

- An AirPrint-enabled printer on your Wi-Fi network
- A network printer or printer shared by another Mac on your Wi-Fi network
- A printer connected to the USB port of an AirPort base station


Print to an AirPrint printer. To print from any app, select an AirPrint printer in the list of printers.

Can't find the printer you're looking for? Make sure it's connected to the same Wi-Fi network as your MacBook Pro. If it is and you still don't see it, try adding it: click the System Preferences icon in the Dock, click Printers & Scanners, then click Add \oplus . (You may have to connect the printer to your MacBook Pro using USB.)

For a list of AirPrint-enabled printers and other supported printers, see [About AirPrint](#) and [OS X: Printer and scanner software available for download](#).

AirPlay

Display your MacBook Pro screen on your TV using AirPlay Mirroring. If your HDTV is connected to Apple TV and Apple TV is on the same Wi-Fi network as your MacBook Pro, you can mirror the MacBook Pro display on your TV screen or use the HDTV as a second display.

Use AirPlay Mirroring. Click the AirPlay icon  in the menu bar, then choose your Apple TV. When an AirPlay display is active, the icon turns blue.

In some cases, you can use an AirPlay display even if you're not on the same Wi-Fi network as Apple TV (called peer-to-peer AirPlay). To use peer-to-peer AirPlay, you need an Apple TV (3rd generation rev A, model A1469 or later) with Apple TV software 7.0 or later.

Apple TV and AirPort base stations are sold separately at store.apple.com or your local Apple Retail Store.

To learn more about AirDrop, AirPrint, and AirPlay, go to Mac Help. To learn more about using a second display with your MacBook Pro, see [Use an external display](#).

Make video calls with FaceTime



Your MacBook Pro has a built-in FaceTime HD camera that you can use to make FaceTime video calls.

Make a video call. Click the Launchpad icon in the Dock, then click FaceTime. Start typing a name or number—if it's in your contacts list, FaceTime completes it for you. Then click the camera button by the person's name to make the call.

FaceTime HD camera
Make video calls, capture video, and take snapshots.



You can also use your camera to take pictures and video using Photo Booth. To learn more, open Mac Help and search for FaceTime or Photo Booth.

Use an external display

The Thunderbolt 2 and HDMI ports on your MacBook Pro support video output. You can use an external display, a projector, or an HDTV with your MacBook Pro.

Connect an Apple Thunderbolt Display. Plug the display's cable directly into the Thunderbolt port ⚡ on your MacBook Pro.

Connect a VGA display or projector. Use a Mini DisplayPort to VGA Adapter to connect the display to the Thunderbolt port ⚡ on your MacBook Pro.

Connect an HDMI display or an HDTV. Plug the HDMI cable directly into the HDMI port on your MacBook Pro.



Adapters and other accessories are sold separately at store.apple.com or your local Apple Retail Store. Review the documentation or check with the manufacturer to make sure you're choosing the right adapter.

Back up and restore



To keep your files safe, it's important to back up your MacBook Pro regularly. The easiest way to back up is to use Time Machine—which is built into your MacBook Pro—with a wireless AirPort Time Capsule (sold separately) or an external storage device connected to your MacBook Pro.

Set up Time Machine. Make sure your MacBook Pro is on the same Wi-Fi network as your AirPort Time Capsule, or connect your storage device to MacBook Pro. Then click the System Preferences icon in the Dock, click Time Machine, and click On. Select the drive you want to use for backup, and you're all set.



Time Machine:

- Automatically backs up your entire MacBook Pro, including system files, apps, accounts, preferences, music, photos, movies, and documents.
- Remembers how your computer looked on any given day, so you can revisit your MacBook Pro as it appeared in the past or retrieve an older version of a document.
- Lets you restore your entire system from a Time Machine backup. So if anything happens to your MacBook Pro, your files are safe and sound.

To learn more about backing up and restoring your MacBook Pro, go to Mac Help and search for Time Machine, external storage device, backup, or restore. To learn more about AirPort Time Capsule, go to www.apple.com/airport-time-capsule.

AirPort Time Capsule is sold separately at store.apple.com or your local Apple Retail Store.

Get answers



Much more information about using your MacBook Pro is available in Mac Help.

Get help. Click the Finder icon in the Dock, then click the Help menu in the menu bar and type a question or term in the Search field. Choose a topic from the results list or choose Show All Help Topics to see all topics.

To learn about	Do this
MacBook Pro support	Go to www.apple.com/support/macbookpro .
MacBook Pro specifications	Go to www.apple.com/macbook-pro/specs-retina .
Using MacBook Pro safely	See Important safety information .
Important MacBook Pro information	Choose Apple menu () > About This Mac. Then click Support and choose Important Information > Product Information Guide.

Apps

5

About apps

Your MacBook Pro comes with apps for creativity and apps for productivity. It also comes with a collection of great apps for things you do every day, like surfing the web, sending mail and messages, and organizing your calendar.

Take your MacBook Pro to the next level with pro apps like Final Cut Pro X and Logic Pro X. You can purchase these and other professional and creative apps from the Mac App Store. To find out more, click the App Store icon in the Dock.


To get help using any app, just click the Help menu (in the menu bar at the top of the screen) when you're using the app.

Safari



Safari is the best way to surf the web on your Mac. Just click the Smart Search field to see icons for your favorite websites, or type a search term or web address—Safari can tell the difference and will send you to the right place. You can save pages to your Reading List to read later, and pin the websites you visit often so they are open, up to date, and easy to access. In tab view you can see all your open tabs—even ones on your iOS devices.

<p>Pinned sites Create pinned sites to keep favorite websites open, active, and easily accessible.</p>	<p>Favorites view Click the Smart Search field to see icons for your favorite websites.</p>	<p>Share Easily send webpages or share them with your social networks.</p>
---	--	---



The screenshot shows the Safari browser window with the URL www.pinterest.com. The page content includes several pins with images and text. Annotations with lines pointing to specific features are present: 'Pinned sites' points to a pin about '10 Ways to Take Gray from Neutral to Dramatic'; 'Favorites view' points to the Smart Search field; and 'Share' points to the share icon in the top right corner of the browser window.

Mail




Mail lets you manage all your email accounts from a single app. It works with most popular email services, such as iCloud, Gmail, Yahoo Mail, and AOL Mail.

You can send large attachments using Mail Drop—your attachments are uploaded to iCloud, and recipients get a link to them. And with Markup, you can fill out and sign forms or annotate a PDF. You can even delete messages or mark them as read or unread with a swipe on your trackpad. To get started, just open Mail and Setup Assistant helps you set up your accounts.

One-stop email
View all your accounts in Mail.

Smart Suggestions
Add names or events in an email to your contacts or calendar with a single click.

Search
Quickly narrow search results to find exactly what you want.



Calendar



Keep track of your busy schedule with Calendar. You can create separate calendars—one for home, another for school, and a third for work. See all your calendars in a single window, or see just the ones you want. Create and send invitations to events, then see who has responded. Add a location to an event and Calendar includes a map and the weather forecast, calculates travel time, and alerts you when it's time to leave. Use iCloud to automatically update your iCloud calendars on all your Macs and iOS devices, or share calendars with other iCloud users.

You can share iCloud calendars and add Google and Yahoo calendars.

Add an event
Click + to quickly create a calendar event.

Event inspector
Calendar shows an event's location on a map and calculates travel time.

Calendar view
Select the view you prefer—day, week, month, or year.

Notes



Now your notes can include more than just text—add photos, videos, and content from other apps, such as web links from Safari and addresses from Maps. Make checklists and check off items as you complete them. When your devices are signed in to the same iCloud account, your notes are kept up to date on all your devices—so you can create a to-do list on your Mac, then check off items on your iPhone while you're on the go.

Checklists Create handy lists for yourself.	Photos Drag photos and other items into your notes.
---	---

The screenshot shows the Notes app interface. On the left is a sidebar with a list of notes, each with a title, date, and a small thumbnail. The notes include: 'Kitchen remodel ideas' (9:41 AM), 'Carson's birthday party' (9:41 AM), 'Reference letter for Lee' (9:02 AM), 'Contractor meeting' (8:37 AM), 'Tropical vacation ideas' (Sunday), 'Miami conference notes' (Sunday), 'Landscaping' (Saturday), 'NYC dining greatest hits' (Thursday), 'Team-building activities' (Thursday), 'Story idea' (Wednesday), and 'Local ramen joints'. The main pane on the right displays the selected note, 'Kitchen remodel ideas', dated 'Today at 9:41 AM'. The note content includes a title, a paragraph of text, a 'Things to do' checklist with three items (two checked), a photo of a modern kitchen island, and a product link for a faucet with a small image of the faucet.

Messages



Messages gives you many ways to stay in touch. Just sign in with your Apple ID, and you can send and receive both iMessage and SMS messages—including text, photos, video, and more—to anyone with a Mac, iPad, iPhone, or iPod touch. With iMessage, you can even start a conversation on your iOS device and continue it on your MacBook Pro. You can easily start and manage group conversations, including adding a title and new participants. And if you want to talk to someone face to face, you can start a FaceTime video call right from a conversation in Messages.

Manage conversations
Click Details to start a FaceTime call or see the attachments from your conversation.

Replies in progress
Three dots mean your friend is typing a reply.

Delivery receipts
See when your message has arrived.

Note: To use FaceTime video calling, both the caller and recipient need a FaceTime-enabled device. This feature is not available in all areas.

Maps



Explore new destinations and get directions on your Mac with Maps. View locations using standard or satellite imagery, or use Flyover to soar through select cities in photorealistic 3D. You can also see transit options for select cities around the world. You can look up information for local points of interest like restaurants and hotels, and Maps shows you phone numbers, photos, and even Yelp reviews. Once you find your destination, Maps provides point-to-point directions for driving, walking, or even taking mass transit (in select cities) that you can send to your iPhone for navigation on the go.

Directions


Maps provides detailed directions, including traffic information.

Transit

Map your route using bus, train, subway, or ferry.

Send to iPhone


Send directions to your iPhone for voice navigation on the way there.




WARNING: For important information about navigation and avoiding distractions that could lead to dangerous situations, see [Important safety information](#).

Spotlight



Spotlight is an easy way to find anything on your Mac. Just click the Spotlight icon  in the menu bar or press Command–Space bar, then start typing. Spotlight finds results on your Mac—including documents, contacts, and email messages—as well as Wikipedia, Bing, maps, movies, weather, stocks, sports, and more. You can take action right from your search results: make a call, send an email message, get directions, even convert currencies.

Results See a variety of Spotlight results, including weather, stocks, sports, transit information, and more.	Previews Interact with previews right from Spotlight.
---	---



Documents I worked on last week Iceland Geography Field Trip

TOP HITS

Iceland Geography Field Trip

DOCUMENTS

- Calligraphy
- Coffee
- Origami
- Peru
- Wood Craft

PRESENTATIONS

- Discovering Galapagos
- Music Academy
- Space
- Numbers

Show all in Finder...

DAY 2: VOLCANOES AND LAVA FIELDS

AREAS OF STUDY ON DAY 2

- Craters, lava tubes, and lava fields
- Volcanic formation
- Eruptions, fissures, and structure
- Black sand beach formation
- Impacts lava fields and volcanoes have on the land.

DAY 1: AURORA BOREALIS

HOW THE AURORA BOREALIS IS FORMED

1. Charged particles are pulled from the sun by the sun's magnetic field.
2. These particles produce aurora by colliding with atoms and molecules in the atmosphere.
3. The collision energy warms the atoms and causes them to glow.

WHERE AND WHAT TO LOOK FOR

Note: Not all features are available in all areas.

iTunes



iTunes makes it easy to enjoy your music, movies, TV shows, and more. The iTunes app on your Mac includes the iTunes Store, where you can discover classics or new favorites. It also features Apple Music—a revolutionary music service, Beats 1 live radio, and Connect, where fans can interact with their favorite artists.

Your library


Organize and enjoy your music, movies, TV shows, podcasts, and more.

Apple Music

Subscribe to choose from millions of songs. Listen to Beats 1 live radio. Connect with your favorite artists.

iTunes Store

Discover and buy new music, movies, TV shows, and more.



Photos, iMovie, and GarageBand



Photos, iMovie, and GarageBand give you amazing ways to create and share your photos, movies, and music. Photos automatically keeps your library organized and helps you create gorgeous photo books, cards, and calendars. And with iCloud Photo Library, you can keep your entire collection of photos and videos in iCloud and view them on all your devices. iMovie lets you turn your home videos into beautiful movies and epic Hollywood-style trailers. And GarageBand has everything you need to learn to play an instrument, write music, or record a song.

Photos


Photos are automatically organized by date and location.

Projects

Easily create and order personalized books, cards, and calendars.

Share

Post your favorites to Facebook or share them with iCloud or Messages.



Pages, Numbers, and Keynote



Create stunning documents, spreadsheets, and presentations on your Mac. Beautiful templates give you a great head start—simply add your own words and photos. And customizing your work is a snap—just select any text or object, and you see all your options in the Format panel on the right. Open and edit Microsoft Office files, and easily share a link to your work in Mail or Messages, right from the toolbar.

Add graphics and more
Create media-rich documents with images, movies, charts, and more.

Share
Easily share a link to your work with Mail or Messages.

Format Panel
Your tools are just a click away with the intelligent Format Panel.



Safety, handling, and support

6

Important safety information



WARNING: Failure to follow these safety instructions could result in fire, electric shock, or other injuries, or damage to your MacBook Pro or other property. Read all safety information below before using your MacBook Pro.

Built-in battery. Don't attempt to replace or remove the battery yourself—you may damage the battery, which could cause overheating and injury. The lithium-ion battery in MacBook Pro should be replaced by Apple or an authorized service provider, and must be recycled or disposed of separately from household waste. Don't expose your MacBook Pro to extreme heat sources, such as radiators or fireplaces, where temperatures might exceed 212°F (100°C). Don't incinerate the battery.

For information about battery service and recycling, go to www.apple.com/batteries/service-and-recycling.

Handling. Handle your MacBook Pro with care. It is made of metal, glass, and plastic and has sensitive electronic components inside. Set up your MacBook Pro on a hard, stable work surface that allows for adequate air circulation under and around the computer. MacBook Pro can be damaged if dropped, burned, punctured, or crushed, or if it comes in contact with liquid. Don't use a damaged MacBook Pro, such as one with a cracked screen, as it may cause injury.

Water and wet locations. Keep your MacBook Pro away from sources of liquid, such as drinks, washbasins, bathtubs, shower stalls, and so on. Protect your MacBook Pro from dampness or wet weather, such as rain, snow, and fog.

Repairing. Your MacBook Pro doesn't have any user-serviceable parts. Do not open or disassemble MacBook Pro or attempt to repair it or replace any components. Disassembling MacBook Pro may damage it or may cause injury to you. If MacBook Pro needs service, is damaged, malfunctions, or comes in contact with liquid, contact Apple or an Apple-authorized repair center, such as an Apple Authorized Service Provider. If you attempt to open it, you risk damaging your computer, and such damage isn't covered by the limited warranty on your MacBook Pro.

Navigation. Maps, directions, and location-based apps depend on data services. These data services are subject to change and may not be available in all areas, resulting in maps, directions, or location-based information that may be unavailable, inaccurate, or incomplete. Compare the information provided on MacBook Pro to your surroundings and defer to posted signs to resolve any discrepancies. Do not use these services while performing activities that require your full attention. Always comply with posted signs and the laws and regulations in the areas where you are using MacBook Pro and always use common sense.

Charging. Charge MacBook Pro only with the included 60W or 85W MagSafe 2 Power Adapter, or with other third-party cables and power adapters that are compatible with MagSafe 2 and are compliant with applicable regulations.

Using damaged cables or chargers, or charging when moisture is present, can cause fire, electric shock, injury, or damage to MacBook Pro or other property. When you use the included 60W or 85W MagSafe 2 Power Adapter to charge MacBook Pro, make sure that the AC plug or AC power cord is fully inserted into the power adapter before you plug the adapter into a power outlet.

Prolonged heat exposure. MacBook Pro and its 60W or 85W MagSafe 2 Power Adapter may become very warm during normal use. MacBook Pro and its 60W or 85W MagSafe 2 Power Adapter comply with applicable surface temperature standards and limits defined by the International Standard for Safety of Information Technology Equipment (IEC 60950-1). However, even within these limits, sustained contact with warm surfaces for long periods of time may cause discomfort or injury.

Use common sense to avoid situations where your skin is in prolonged contact with a device or its power adapter when it's operating or plugged into a power source. For example, don't sleep with a device or power adapter when it's plugged into a power source. Don't operate your MacBook Pro on a pillow, blanket, or other soft material that can block ventilation openings. It's important to keep MacBook Pro and its 60W or 85W MagSafe 2 Power Adapter in a well-ventilated area when in use or charging.

Never push anything into the ventilation openings, as doing so may be dangerous and cause your computer to overheat. Never place anything over the keyboard when operating your MacBook Pro. If your MacBook Pro is on your lap and gets uncomfortably warm, remove it from your lap and place it on a stable, well-ventilated work surface. Take special care if you have a physical condition that affects your ability to detect heat against the body.

60W or 85W MagSafe 2 Power Adapter. To operate the 60W or 85W MagSafe 2 Power Adapter safely and reduce the possibility of heat-related injury or damage, do one of the following:

- Plug the 60W or 85W MagSafe 2 Power Adapter directly into a power outlet.
- If you're using the AC power cord, place the power adapter on a desk, table, or on the floor in a well-ventilated location.

Disconnect the power adapter and any other cables if any of the following conditions exists:

- You want to clean the case (use only the recommended procedure described in [Important handling information](#)).
- The power cord or plug becomes frayed or otherwise damaged.
- Your MacBook Pro or its 60W or 85W MagSafe 2 Power Adapter is exposed to rain, excessive moisture, or liquid spilled into the case.
- Your MacBook Pro or its 60W or 85W MagSafe 2 Power Adapter has been dropped, the case has been damaged, or you suspect that service or repair is required.

The MagSafe 2 power port on your MacBook Pro (where you plug in the MagSafe 2 power connector) contains a magnet that can erase data on a credit card, iPod, or other device. To preserve your data, do not place these or other magnetically sensitive material or devices within 1 inch (25 mm) of this port.

If debris gets onto the MagSafe 2 port, remove it gently with a dry cotton swab.

60W MagSafe 2 Power Adapter specifications:

- *Frequency:* 50 to 60 Hz, single phase
- *Line Voltage:* 100 to 240 V
- *Output Voltage:* 16.5 V DC, 3.65 A

85W MagSafe 2 Power Adapter specifications:

- *Frequency:* 50 to 60 Hz, single phase
- *Line Voltage:* 100 to 240 V
- *Output Voltage:* 20 V DC, 4.25 A

Hearing loss. Listening to sound at high volumes may damage your hearing. Background noise, as well as continued exposure to high-volume levels, can make sounds seem quieter than they actually are. Use only compatible earbuds, headphones, or earpieces with your MacBook Pro. Turn on the audio and check the volume before inserting anything into your ear. For more information about hearing loss, see www.apple.com/sound.



WARNING: To prevent possible hearing damage, do not listen at high volume levels for long periods.

Radio frequency exposure. MacBook Pro uses radio signals to connect to wireless networks. For information about radio frequency (RF) energy resulting from radio signals and steps you can take to minimize exposure, see www.apple.com/legal/rfexposure.

Medical device interference. MacBook Pro contains components and radios that emit electromagnetic fields, which may interfere with pacemakers, defibrillators, or other medical devices. Maintain a safe distance of separation between your medical device and MacBook Pro. Consult your physician and medical device manufacturer for information specific to your medical device. If you suspect MacBook Pro is interfering with your pacemaker or any other medical device, stop using MacBook Pro.

Medical conditions. If you have a medical condition that you believe could be affected by using MacBook Pro (for example, seizures, blackouts, eyestrain, or headaches), consult with your physician prior to using MacBook Pro.

Repetitive motion. When you perform repetitive activities such as typing or playing games on MacBook Pro, you may experience discomfort in your hands, arms, wrists, shoulders, neck, or other parts of your body. If you experience discomfort, stop using MacBook Pro and consult a physician.

Choking hazard. Some MacBook Pro accessories may present a choking hazard to small children. Keep these accessories away from small children.

High-consequence activities. MacBook Pro is not intended for use where the failure of the computer could lead to death, personal injury, or severe environmental damage.

Explosive atmospheres. Charging or using MacBook Pro in any area with a potentially explosive atmosphere, such as areas where the air contains high levels of flammable chemicals, vapors, or particles (such as grain, dust, or metal powders), may be hazardous. Obey all signs and instructions.

Important handling information

Operating environment. Operating your MacBook Pro outside these ranges may affect performance:

- *Operating temperature:* 50° to 95° F (10° to 35° C)
- *Storage temperature:* -13° to 113° F (-25° to 45° C)
- *Relative humidity:* 0% to 90% (noncondensing)
- *Operating altitude:* Tested up to 10,000 feet (0 to 3048 meters)

Carrying your MacBook Pro. If you carry your MacBook Pro in a bag or briefcase, make sure that there are no loose items (such as paper clips or coins) that could accidentally get inside the computer through vent openings or get stuck inside a port. Also, keep magnetically sensitive items away from the MagSafe 2 power port.

Using connectors and ports. Never force a connector into a port. When connecting a device, make sure the port is free of debris, that the connector matches the port, and that you have positioned the connector correctly in relation to the port.


Storing your MacBook Pro. If you are going to store your MacBook Pro for an extended period of time, keep it in a cool location (ideally, 71° F or 22° C) and discharge the battery to 50 percent. When storing your computer for longer than five months, maintain the capacity of the battery by charging the battery to 50 percent every six months or so.

Cleaning your MacBook Pro. When cleaning the outside of your MacBook Pro and its components, first shut down your MacBook Pro, and then unplug the 60W or 85W MagSafe 2 Power Adapter. Then dampen a clean, lint-free cloth to wipe the MacBook Pro exterior. Avoid getting moisture in any openings. Don't spray liquid directly on the computer. Don't use aerosol sprays, solvents, abrasives, or cleaners containing hydrogen peroxide that might damage the finish.


Cleaning the MacBook Pro screen. To clean your MacBook Pro screen, first shut down your MacBook Pro and unplug the 60W or 85W MagSafe 2 Power Adapter. Dampen a clean, lint-free cloth with just water and wipe the screen. Don't spray liquid directly on the screen.

Understanding ergonomics

When you use the keyboard and trackpad, your shoulders should be relaxed. Your upper arm and forearm should form an angle that is slightly greater than a right angle, with your wrist and hand in roughly a straight line.



Use a light touch when typing or using the trackpad and keep your hands and fingers relaxed. Avoid rolling your thumbs under your palms.



Change hand positions often to avoid fatigue. Some computer users might develop discomfort in their hands, wrists, or arms after intensive work without breaks. If you begin to develop chronic pain or discomfort in your hands, wrists, or arms, consult a qualified health specialist.

External mouse. If you use an external mouse, position the mouse at the same height as the keyboard and within a comfortable reach.

Chair. An adjustable chair that provides firm, comfortable support is best. Adjust the height of the chair so your thighs are horizontal and your feet are flat on the floor. The back of the chair should support your lower back (lumbar region). Follow the manufacturer's instructions for adjusting the backrest to fit your body properly.

Built-in display. Adjust the angle of the display to minimize glare and reflections from overhead lights and windows. Do not force the display if you meet resistance. The display is not designed to open past 135 degrees.

You can adjust the brightness of the screen when you take the computer from one work location to another, or if the lighting in your work area changes.

For more information about ergonomics, see www.apple.com/about/ergonomics.

Apple and the environment

At Apple, we recognize our responsibility to minimize the environmental impacts of our operations and products.

For information, go to www.apple.com/environment.

Learning more, service, and support

You can find more information about your MacBook Pro through Mac Help, System Report, Apple Hardware Test, and online resources.

Mac Help. You can often find answers to your questions, as well as instructions and troubleshooting information, in Mac Help on your Mac. Click the Finder icon in the Dock, click Help in the menu bar, and choose Mac Help.

System Report. To get information about your MacBook Pro, use System Report. It shows you what hardware and software is installed, the serial number and operating system version, how much memory is installed, and more. To open System Report, choose Apple menu () > About This Mac, then click System Report.

Apple Hardware Test. You can use Apple Hardware Test (AHT) to help determine if there's a problem with one of the computer's components, such as the memory or processor.

To use Apple Hardware Test, disconnect all external devices except the power adapter. Restart your MacBook Pro and hold down the D key as it starts up. When the AHT chooser screen appears, select the language for your location. Press the Return key or click the right arrow button. When the AHT main screen appears (after about 45 seconds), follow the onscreen instructions. If AHT detects a problem, it displays an error code. Make a note of the error code before pursuing support options. If AHT doesn't detect a hardware failure, the problem might be software related.

Online resources. For online service and support information, go to www.apple.com/support. You can learn about Apple products, view online manuals, and check for software updates. Connect with other Apple users, and get service, support, and professional advice from Apple.

AppleCare support. If you need assistance, AppleCare representatives can help you with installing and opening apps, and with troubleshooting. Call the support center number nearest you (the first 90 days are complimentary). Have the purchase date and your MacBook Pro serial number ready when you call.

Your 90 days of complimentary telephone support begins on the date of purchase.

Country	Phone number	Web address
United States	1-800-275-2273	www.apple.com/support
Australia	(61) 1-300-321-456	www.apple.com/au/support
Canada	1-800-263-3394	English: www.apple.com/ca/support French: www.apple.com/ca/fr/support
Ireland	1-800-804-062	www.apple.com/ie/support
New Zealand	00800-7666-7666	www.apple.com/nz/support
United Kingdom	(44) 0844 209 0611	www.apple.com/uk/support

Telephone numbers are subject to change, and local and national telephone rates may apply. A complete list is available on the web at www.apple.com/support/contact/phone_contacts.html.

FCC compliance

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important: Changes or modifications to this product not authorized by Apple could void the electromagnetic compatibility (EMC) and wireless compliance and negate your authority to operate the product.

This product has demonstrated EMC compliance under conditions that included the use of compliant peripheral devices and shielded cables (including Ethernet network cables) between system components. It is important that you use compliant peripheral devices and shielded cables between system components to reduce the possibility of causing interference to radios, television sets, and other electronic devices.

Responsible party (contact for FCC matters only):

Apple Inc. Corporate Compliance
1 Infinite Loop, MS 91-1EMC
Cupertino, CA 95014

Canadian regulatory compliance

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Operation in the band 5150–5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

Users are advised that high-power radars are allocated as primary users (that is, priority users) of the bands 5250–5350 MHz and 5650–5850 MHz and these radars could cause interference and/or damage to LE-LAN devices.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

La bande 5150–5250 MHz est réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux.

Les utilisateurs êtes avisés que les utilisateurs de radars de haute puissance sont désignés utilisateurs principaux (c.-à-d., qu'ils ont la priorité) pour les bandes 5250–5350 MHz et 5650–5850 MHz et que ces radars pourraient causer du brouillage et/ou des dommages aux dispositifs LAN-EL.

CAN ICES-3 (B)/NMB-3(B)

Europe—EU Declaration of Conformity



Hereby, Apple Inc. declares that this wireless device is in compliance with the essential requirements and other relevant provisions of R&TTE Directive.

A copy of the EU Declaration of Conformity is available at www.apple.com/euro/compliance.

Apple's EU representative is Apple Distribution International, Hollyhill Industrial Estate, Cork, Ireland.

This device can be used in the European Community.

European Community Restrictions

This device is restricted to indoor use in the 5150 to 5350 MHz frequency range.

ENERGY STAR® Compliance Statement



As an ENERGY STAR partner, Apple has determined that standard configurations of this product meet the ENERGY STAR guidelines for energy efficiency. The ENERGY STAR program is a partnership with electronic equipment manufacturers to promote energy-efficient products. Reducing energy consumption of products saves money and helps conserve valuable resources.

MacBook Pro is shipped with power management enabled with the computer set to sleep after 10 minutes of user inactivity. To wake your computer, click the trackpad or press any key on the keyboard. To change this setting, click the System Preferences icon in the Dock, then click Energy Saver.

For more information about ENERGY STAR, go to www.energystar.gov.

Disposal and recycling information



This symbol indicates that this product and/or battery should not be disposed of with household waste. When you decide to dispose of this product and/or its battery, do so in accordance with local environmental laws and guidelines.

For information about Apple's recycling program, recycling collection points, restricted substances and other environmental initiatives, visit www.apple.com/environment.

European Union—Disposal Information



The symbol above means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

Türkiye

Türkiye Cumhuriyeti: AEEE Yönetmeliğine Uygundur.

Brasil—Informações sobre descarte e reciclagem



O símbolo indica que este produto e/ou sua bateria não devem ser descartadas no lixo doméstico. Quando decidir descartar este produto e/ou sua bateria, faça-o de acordo com as leis e diretrizes ambientais locais. Para informações sobre o programa de reciclagem da Apple, pontos de coleta e telefone de informações, visite www.apple.com/br/environment.

Información sobre eliminación de residuos y reciclaje



El símbolo indica que este producto y/o su batería no debe desecharse con los residuos domésticos. Cuando decida desechar este producto y/o su batería, hágalo de conformidad con las leyes y directrices ambientales locales. Para obtener información sobre el programa de reciclaje de Apple, puntos de recolección para reciclaje, sustancias restringidas y otras iniciativas ambientales, visite www.apple.com/la/environment.

Battery disposal information

The battery in MacBook Pro should be serviced, replaced, or recycled by Apple or an authorized service provider, and must be recycled or disposed of separately from household waste according to your local environmental laws and guidelines. For information about battery service and recycling, go to www.apple.com/batteries/service-and-recycling.

Taiwan disposal information



廢電池請回收

Taiwan battery statement

警告：請勿戳刺或焚燒。此電池不含汞。

China battery statement

警告：不要刺破或焚燒。該電池不含水銀。

注意：電池只能由Apple或Apple授權服務商進行更換，用錯誤型號電池更換會有爆炸危險。

中国

有害物质	零部件				
	电路板	显示屏	电池组	附件	电源适配器
铅 (Pb)	X	X	X	X	X
汞 (Hg)	O	O	O	O	O
镉 (Cd)	O	O	O	O	O
六价铬 (Cr, VI)	O	O	O	O	O
多溴联苯 (PBB)	O	O	O	O	O
多溴二苯醚 (PBDE)	O	O	O	O	O

O: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572-2011 规定的限量要求以下。

X: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572-2011 规定的限量要求。

根据中国电子行业标准 SJ/T 11364-2014 和相关的中国政府法规，本产品及其某些内部或外部组件上可能带有环保使用期限标识。取决于组件和组件制造商，产品及其组件上的使用期限标识可能有所不同。组件上的使用期限标识优先于产品上任何与之相冲突的或不同的环保使用期限标识。



Battery Charger Energy Efficiency



Software License Agreement

Use of MacBook Pro constitutes acceptance of the Apple and third-party software license terms found at www.apple.com/legal/sla.

🍏 Apple Inc.

© 2015 Apple Inc. All rights reserved.

Use of the “keyboard” Apple logo (Option-Shift-K) for commercial purposes without the prior written consent of Apple may constitute trademark infringement and unfair competition in violation of federal and state laws.

Apple, the Apple logo, AirDrop, AirPlay, AirPort, AirPort Time Capsule, Apple TV, FaceTime, Final Cut Pro, Finder, GarageBand, iMessage, iMovie, iPad, iPhone, iPod touch, iTunes, Keynote, Launchpad, Logic, Mac, MacBook Pro, Mission Control, Numbers, OS X, Pages, Photo Booth, Photos, Retina, Safari, Spaces, Spotlight, and Time Machine are trademarks of Apple Inc., registered in the U.S. and other countries.

AirPrint, Flyover, and Handoff are trademarks of Apple Inc.

AppleCare, Apple Store, iCloud, and iTunes Store are service marks of Apple Inc., registered in the U.S. and other countries.

App Store, iBooks Store, and iTunes Radio are service marks of Apple Inc.

Apple
1 Infinite Loop
Cupertino, CA 95014-2084
408-996-1010
www.apple.com

iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Apple Inc. is under license.

ENERGY STAR® is a U.S. registered trademark.

Other company and product names mentioned herein may be trademarks of their respective companies.

Every effort has been made to ensure that the information in this manual is accurate. Apple is not responsible for printing or clerical errors.

Some apps are not available in all areas. App availability is subject to change.

019-00203/2015-10